

FUJI
ELECTRIC

FUJI PROGRAMMABLE CONTROLLER

MICREX-F


F55 Series


USER'S MANUAL HARDWARE

Safety Precautions

Before mounting, wiring, operation, maintenance and inspection of the device, be sure to read the operating instructions carefully to ensure proper operation. The operating instructions should be furnished to the maintenance supervisors of final users.

- Here, the safety precaution items are classified into "Warning" and "Caution".

 **WARNING** : Incorrect handling of the device may result in death or serious injury.

 **CAUTION** : Incorrect handling of the device may result in minor injury or physical damage.

- Even some items indicated by "Caution" may also result in a serious accident.

WARNING

- Never touch any part of charged circuits as terminals and exposed metal portion while the power is turned ON. It may result in an electric shock to the operator.
- Turn OFF the power before mounting, dismantling, wiring, maintaining or checking, otherwise, electric shock, erratic operation or troubles might occur.
- Place the emergency stop circuit, interlock circuit or the like for safety outside the PC. A failure of PC might break or cause problems to the machine.
- Do not connect in reverse polarity, charge (except rechargeable ones), disassemble, heat, throw in fire or short-circuit the batteries, otherwise, they might burst or take fire.

CAUTION

- Do not use one found damaged or deformed when unpacked, otherwise, failure or erratic operation might be caused.
- Do not shock the product by dropping or tipping it over, otherwise, it might be damaged or troubled.
- Follow the directions of the operating instructions when mounting the product. If mounting is improper, the product might drop or develop problems or erratic operations.
- Use the rated voltage and current mentioned in the operating instructions and manual. Use beyond the rated values might cause fire, erratic operation or failure.
- Operate (keep) in the environment specified in the operating instructions and manual. High temperature, high humidity, condensation, dust, corrosive gases, oil, organic solvents, excessive vibration or shock might cause electric shock, fire, erratic operation or failure.
- Select a wire size to suit the applied voltage and carrying current, and carry out wiring according to the operating instructions and manual. Poor wiring might cause fire.
- Contaminants, wiring chips, iron powder or other foreign matter must not enter the device when installing it, otherwise, erratic operation or failure might occur.
- Connect the ground terminal to the ground, otherwise, an erratic operation might occur.
- Periodically make sure the terminal screws and mounting screws are securely tightened. Operation at a loosened status might cause fire or erratic operation.
- Put the furnished connector covers on unused connectors, otherwise, failure or erratic operation might occur.
- Install the furnished terminal cover on the terminal block, otherwise, electric shock or fire might occur.
- Sufficiently make sure of safety before program change, forced output, starting, stopping or anything else during a run.
The wrong operation might break or cause machine problems.
- Replace the fuse with a designated one, otherwise, fire or failure might occur.
- Engage the loader connector in a correct orientation, otherwise, an erratic operation might occur.
- Do not remodel or disassemble the product, otherwise, a failure might occur.
- Follow the regulations of industrial wastes when the device is to be discarded.

Preface

This User's Manual explains the system configurations, specifications, and handling procedure for the MICREX-F F55 Series. Read this manual thoroughly for correct handling and normal operation of the programmable controller.

This manual is an English version based on the Japanese User's Manual No. FH150a.

Notes

1. This manual may not be reproduced in whole or part in any form without prior written approval by the manufacturer.
2. The contents of this manual (including specifications) are subject to change without prior notice.
3. If you find any ambiguous or incorrect descriptions in this manual, please write them down (with the manual No. shown on the cover) and contact FUJI.

CONTENTS

Page

Section 1	1.1	How to Use This Manual	1-2
General	1.2	Important Precautions	1-3
	1.3	Features	1-4
	1.4	Type List	1-5

Section 2	2.1	Introducing the F55 Series	2-2
System Configuration	2.2	Types of System Configuration	2-3
	2.3	Address Assignment	2-8
	2.4	Peripheral Devices	2-11

Section 3	3.1	Basic Specifications	3-2
Specifications	3.2	Specifications	3-5
	3.3	I/O Specifications	3-6
	3.4	I/O Card Specifications	3-19
	3.5	Specifications of Function Cards	3-29
	3.6	I/O Capsule (Unit) Specifications	3-42
	3.7	T-link Specifications	3-49

Section 4	4.1	Name and Function of Each Part	4-2
Name and Function of Each Part	4.2	Dimensions	4-22
	4.3	Simulated Input Switch	4-26

Section 5	5.1	Precautions on Installation	5-2
Installation and Wiring	5.2	Before Installing the Unit	5-4
	5.3	Installing the Unit on the Control Panel	5-6
	5.4	Wiring	5-13

Section 6	6.1	Preliminary Check	6-3
Test Operation	6.2	Test Operation	6-4

Section 7	7.1	Troubleshooting	7-2
Troubleshooting	7.2	Reduction of Repair Time	7-3
	7.3	General Trouble Recovery Procedure	7-4
	7.4	LED Indication of the Basic Unit	7-5
	7.5	Meaning of ALM LED Indication	7-6
	7.6	Diagnostic Procedure for Alarms	7-7
	7.7	Diagnosis of Fatal Faults	7-8
	7.8	Diagnosis of Nonfatal Fault	7-14

Section 8	8.1	General Inspection Notes	8-2
Maintenance and Inspection	8.2	Battery Replacement	8-4
	8.3	Maintenance Services	8-5

Section 1 General

	Page
1.1 How to Use This Manual	1-2
1.2 Important Precautions	1-3
1.3 Features	1-4
1.4 Type List.....	1-5
1.4.1 Type number nomenclature	1-5
1.4.2 Type table	1-6

Section 1 General

1.1 How to Use This Manual

This manual describes the system configuration, specifications, and handling of the MICREX-F F55 Series programmable controller (referred to as PC hereafter) from Fuji Electric.

When using this manual, please read the Sections in the table below according to the type of the work to be performed.

Section	Item	Contents	Type of work				
			System design	Software design	Installation	Test operation	Maintenance
1	General	Describes the features of the F55 series and notes on using it.	●	●	●	●	●
2	System Configuration	Introduces various systems which can be built using the F55 series and discusses components and peripheral devices required.	●	●			
3	Specifications	Explains the format and specifications of each component and notes on use.	●	●	●	●	●
4	Name and Function of Each Part	Describes the name and function of each component.	●		●	●	●
5	Installation and Wiring	Covers the installation and wiring procedures for the F55 series and provides relevant notes.	●		●	●	●
6	Test Operation	Provides the check points and the procedure for test operation.				●	●
7	Troubleshooting	Presents troubles which can occur during operation and possible countermeasures.				●	●
8	Maintenance and Inspection	Provides the information on daily and periodical inspections, parts replacement procedure, and maintenance services.					●

1.2 Important Precautions

When using the PC, observe the following points in addition to the ones in "Safety Precautions".

■ Ground the PC

- Connect the frame ground terminal (FG) of each component to a good ground (grounding resistance of 100Ω or less). Avoid connecting it to a ground line used by any power circuits.

■ Replace the battery before it runs out

- Pay attention to the life expectancy of the battery for memory (RAM) backup. If the ROM is used as program memory, the battery is necessary to backup the contents of the data memory.
- It is recommended that the battery be prepared as one of maintenance parts, taking the life expectancy into account. (See Section 7 for details.)

■ Be aware of wiring dust or other conductive foreign materials

- Perform wiring work with the main unit covered by the anti-dust paper. When starting operation after wiring, be sure to remove the paper.

■ Observe the version number of the program loader

- The following models of program loaders can be used; however, they must be upgraded as required. Use a program loader with the specified version number or later versions.

Loader type	Correct version (F55 basic unit case version: 0001 to 0999)	Correct version (F55 basic unit case version: 1001 or later)
D10S	V0.11 or later	V0.30 or later
D20	V7.12 or later	V7.50 or later
D25 (LITE)	V0.07 or later	V2.50 or later
PC loader	PC98 disk version V1.00P or later EMS version V1.00P or later FMR disk version V1.00P3 or later EMS version V1.00P3 or later IBM PC/AT disk version V1.00P3 or later EMS version V1.00P3 or later J3100 disk version V1.00P3 or later EMS version V1.00P3 or later	PC98 disk version Not available EMS version V2.50P1 or later FMR disk version Not available EMS version Not available IBM PC/AT disk version Not available EMS version V2.50P1 or later J3100 disk version Not available EMS version Not available

■ Notes on using the relay output card

The relay output card does not use a surge absorbing element (varistor) therefore connect an external CR surge absorber (0.1μF + 100Ω) to protect the internal circuit; otherwise, leakage current may occur resulting in malfunction of external output devices.

In such a case, connecting a bleeder resistor is required.

If the load connected does not have a capacity of 12V DC/3 mA or more, the contact reliability may be reduced, resulting in malfunction, e.g., the load does not operate even when the built-in relay is turned on.

■ Notes on dielectric strength test

A surge absorber is installed between the power input terminal and the LG terminal on the power supply terminal block. Therefore, when performing dielectric strength test, open the LG terminal, using caution not to damage or burn the surge absorber.

1.3 Features

The MICREX-F F55 series is a PC series in the MICREX-F family which is suitable for small scale system configuration. The series is a high-performance and compact-size version of the F50/50H series.

■ PC with high execution speed

The PC realizes high execution speed of 0.8 μ s per basic sequence instruction (for basic unit case versions 0001 to 0999) or 0.5 μ s per basic sequence instruction (for basic unit case version 1001 or later).

■ Large data memory capacity

The capacity of the internal data memory is 4096 words (1 word = 32 bits).

■ Peripheral tool groups used commonly with the MICREX-F series

With the MICREX-F series, unified programming language (FPL) and common programming tools can be used, allowing upward-compatibility of software.

■ Versatile PC

- 76 different data instructions
- Handling of large amount of data:
Allows operation data format and signed BCD 8-digit data.
- Flexible programming control:
Multitasking control allows external interrupt and fixed-cycle interrupt programs to interrupt into ordinary cyclic program.
- Calendar function:
Calendar is built in the T-link master interface card (NV1L-TL1) (basic unit case version 1001 or later).
- Direct access processing
Allows high-speed I/O response.

■ Compact size

In spite of the built-in power supply, the unit size is 380 x 95 x 97 (mm) allowing one T-link master card and up to 8 other cards to be mounted.

■ T-link available

When the optional T-link master interface card (NV1L-TL1) is implemented, the T-link can be used. The card can be implemented into one of the option card slots of the basic unit.

■ LED indicators


- I/O status LED indicators:
Indicates I/O status for each unit. I/O statuses for two systems each with 32 points can be displayed.
- Data position LED indicators:
There are two LEDs for indicating the current data position (slot and slot data position).
- User LED indicators:
Indicates user information defined in the user display area (W124) to the 8 x 8 LED array and two 7-segment LEDs (basic unit case version 1001 or later).
- Maintenance LED indicators:
Indicates the detail information on the current failure factors (fatal and nonfatal failures) (basic unit case version 1001 or later).

■ Extension connector


Only one expansion unit can be installed with a cable of up to 1m. The extension cables are available in three lengths: 0.3m, 0.6m and 1m (basic unit case version 1001 or later).

1.4.1 Type number nomenclature


(1) Basic unit




(2) Expansion unit




(3) Input card




(4) Relay output card




(5) Transistor output card




(6) Special card




(7) Communication card



(8) F55 series common supplies



(9) EPROM



1.4 Type List

1.4.2 Type table

Product name	Type	Description	Supplied accessory		
			Accessory	Qty.	
Basic unit (rack type)	NV1P-042	1 T-link master card (option) + 4 I/O cards	<ul style="list-style-type: none"> • CPU built in • Up to 1600 I/O control points • Program memory with 10.5k steps • EEPROM with 10.5k steps Memory card installed directly (basic unit case version 1001 or later).	Instruction manual	1
	NV1P-062	1 T-link master card (option) + 6 I/O cards			
	NV1P-082	1 T-link master card (option) + 8 I/O cards			
Expansion unit (rack type)	NV1E-042	4 I/O cards can be installed.	<ul style="list-style-type: none"> • Can be used as directly connected I/O area • Up to 256 words including the basic unit can be used (basic unit case version 1001 or later). *1 	Instruction manual Extension cable (NJ-EC0030)	1
	NV1E-062 <i>(Under development)</i>	6 I/O cards can be installed.			1
	NV1E-082	8 I/O cards can be installed.			
Input card	NV1X1604	12 to 24V DC, 10ms, 3/7mA, 16 points (source type)	Instruction manual Instruction manual Instruction manual Connector Cover	1	
	NV1X1604-W	12 to 24V DC, 10ms, 3/7mA, 16 points (for source and sink)		1	
	NV1X3204	12 to 24V DC, 10ms, 2/4mA, 32 points (source type)		1	
	NV1X3204-W	12 to 24V DC, 10ms, 2/4mA, 32 points (for source and sink)		1	
	NV1X3206	24V DC, 10ms, 4mA, 32 points (source)		1	
Output card	NV1Y08R-00	264V AC maximum (2A/point), 140V DC (0.2A/point), Ry 8 points (all points independent)	Instruction manual Instruction manual Instruction manual Instruction manual Connector Cover	1	
	NV1Y16R-08	264V AC maximum (2A/point), 140V DC (0.2A/point), Ry 16 points (8 points common)		1	
	NV1Y16T05P5	12 to 24V DC, 1ms, 0.5A/point, Tr 16 points (16 points common)		1	
	NV1Y32T05P1	5 to 24V DC, 1ms, 0.1A/point, Tr 32 points (32 points common)		1	
T-link master interface	NV1L-TL1	<ul style="list-style-type: none"> • One T-link system is configured by installing the T-link master interface into the dedicated slot in the basic unit rack. • The calendar function is built in (basic unit case version 1001 or later). 	Instruction manual T-link connector set T-link termination resistor (for connector) T-link termination resistor (for terminal block) Name plate (T-link) Address number seal Screwdriver	1 1 2 1 2 1 1	
Function card	T-link slave	NV1L-TS1	I/O: 1/1, 2/2, 4/4, 7/8 words and message communication	Instruction manual T-link connector set T-link termination resistor Cover	1 1 1 1
	High-speed counter	NV1F-HC1	50kHz, 1 channel, 5V/12V/24V DC count input (direct access only)	Instruction manual Connector Cover	1 1 1
		NV1F-HC2	50kHz, 1 channel, 5V/12V/24V DC count input (4 words)	Instruction manual Connector Cover	1 1 1
	General-purpose interface	NV1L-RS2	Mounts RS-232C interface.	Instruction manual	1
	External interrupt	NV1F-YP1 <i>(Under development)</i>	8 channel, 12 to 24V DC input (direct access only)	Instruction manual	1
Option	Simulation input switch	NV1V-SW16	Simulation input switch for 16 point card (24V DC)	Power cord	1
	EPROM card	NV1VMP-10	Mounts EPROM chip for the F55 series. (EPROM chip type: HN27C256AG-15, Hitachi)	Light shield	1
	EEPROM card	NV1VME-10	Mounts EEPROM chip for the F55 series. (Basic unit case version 1001 or later)	Instruction manual	1
	Spare battery	NL8V-BT	Lithium battery (5 years at 25°C)	Operating life seal	1

*1 Note that the following cards cannot be mounted.
 • High-speed counter card (NV1F-HC1)
 • External interrupt card (NV1F-YP1)

1.4 Type List

■ Combination table

With standard I/O arrangement, the PC can be shipped with I/O cards installed at the factory.

Type	Description	Supplied accessory	
		Accessory	Qty.
NV0P056R-042	Basic unit (NV1P-042) 56 I/O points (DCI:32, Ry:24) Input card: NV1X1604 x 2 Output card: NV1Y16R-08 x 1 NV1Y08R-00 x 1	Basic unit instruction manual Input card instruction manual Output card instruction manual	1 1 1
NV1P064R-042	Basic unit (NV1P-042) 64 I/O points (DCI:32, Ry:32) Input card: NV1X1604 x 2 Output card: NV1Y16R-08 x 2	Basic unit instruction manual Input card instruction manual Output card instruction manual	1 1 1
NV1P064T-042	Basic unit (NV1P-042) 64 I/O points (DCI:32, Ry:32) Input card: NV1X1604 x 2 Output card: NV1Y16T05P5 x 2	Basic unit instruction manual Input card instruction manual Output card instruction manual	1 1 1
NV1P096R-062	Basic unit (NV1P-062) 96 I/O points (DCI:48, Ry:48) Input card: NV1X1604 x 3 Output card: NV1Y16R-08 x 3	Basic unit instruction manual Input card instruction manual Output card instruction manual	1 1 1
NV1P096T-062	Basic unit (NV1P-062) 96 I/O points (DCI:48, Ry:48) Input card: NV1X1604 x 3 Output card: NV1Y16T05P5 x 3	Basic unit instruction manual Input card instruction manual Output card instruction manual	1 1 1
NV1P128R-082	Basic unit (NV1P-082) 128 I/O points (DCI:64, Ry:64) Input card: NV1X1604 x 4 Output card: NV1Y16R-08 x 4	Basic unit instruction manual Input card instruction manual Output card instruction manual	1 1 1
NV1P128T-082	Basic unit (NV1P-082) 128 I/O points (DCI:64, Tr:64) Input card: NV1X1604 x 4 Output card: NV1Y16T05P5 x 4	Basic unit instruction manual Input card instruction manual Output card instruction manual	1 1 1
NV1P128C-042	Basic unit (NV1P-042) 128 I/O points (DCI:64, Tr:64) Input card: NV1X3204 x 2 Output card: NV1Y32T05P1 x 2	Basic unit instruction manual Input card instruction manual Output card instruction manual Connector cover	1 1 1 4
NV1P192C-062	Basic unit (NV1P-062) 192 I/O points (DCI:96, Tr:96) Input card: NV1X3204 x 3 Output card: NV1Y32T05P1 x 3	Basic unit instruction manual Input card instruction manual Output card instruction manual Connector cover	1 1 1 6
NV1P256C-082	Basic unit (NV1P-082) 256 I/O points (DCI:128, Tr:128) Input card: NV1X3204 x 4 Output card: NV1Y32T05P1 x 4	Basic unit instruction manual Input card instruction manual Output card instruction manual Connector cover	1 1 1 8

■ Extension cable type

Dedicated cable for connecting the basic unit of version 1001 or later and expansion unit.

Type	Description	Supplied accessory	
		Accessory	Qty.
Extension cable	NJ-EC0030 0.3m cable (straight cord)	Screwdriver	1
	NS-EC0060 0.6m cable (straight cord)	Screwdriver	1
	NS-EC0100 1.0m cable (straight cord)	Screwdriver	1

Section 2 System Configuration


	Page
2.1 Introducing the F55 Series	2-2
2.2 Types of System Configuration	2-3
2.2.1 Independent system	2-4
2.2.2 Expansion system	2-5
2.2.3 Distribution system (T-link system)	2-6
2.2.4 T-link slave system	2-7
2.3 Address Assignment	2-8
2.3.1 Memory map	2-8
2.3.2 Address assignment	2-9
2.4 Peripheral Devices	2-11
2.4.1 Types of peripheral devices	2-11
2.4.2 D10S	2-11
2.4.3 D20	2-12
2.4.4 D25 (LITE)	2-13

Section 2 System Configuration

2.1 Introducing the F55 Series

The F55 series comes in various forms which are suitable for system expansion, e.g., independent, distribution, and expansion systems. By using the FPL (F-series Programming Language) which is commonly

used by the MICREX-F series and the field network system (T-link system) which is developed by Fuji Electric, high-performance systems can be configured with low cost while satisfying customer needs.




*When configuring a T-link system, the T-link master interface card (NV1L-TL1) must be installed in the basic unit.

2.2 Types of System Configuration

In addition to stand-alone system, the F55 series can be configured as a distributed system (T-link system) using the unique field network system. **However, when**

configuring a T-link system, the T-link master card (NV1L-TL1) must be installed in the basic unit interface.





System name	Description
Independent system	Mounts one to eight I/O cards inside the basic unit.
Distribution and expansion system (T-link system)	Allows distribution and expansion of I/O level by connecting I/O units on remote locations and the PC via the T-link. This system allows configuration of remote I/O and T-link slave systems.

Note: With the T-link system, an optical link system (using optical fibers) can be configured by relaying optical converter.

2.2 Types of System Configuration

2.2.1 Independent system

An example stand-alone system and restrictions on the system are shown in the following table.

Basic unit	NV1P-042	NV1P062	NV1P-082																														
Maximum number of cards mounted	4	6	8																														
Example system configuration	<div style="text-align: center;"> <table border="1" style="margin: auto;"> <tr> <td></td> <td></td> <td>WB0</td> <td>WB1</td> <td>WB2</td> <td>WB3</td> <td>WB4</td> <td>WB5</td> <td>WB6</td> <td>WB7</td> <td>← Word address</td> </tr> <tr> <td rowspan="2" style="vertical-align: middle;">F55</td> <td rowspan="2" style="writing-mode: vertical-rl; transform: rotate(180deg);">Mount location dedicated for the T-link master card</td> <td>B0</td> <td>B10</td> <td>B20</td> <td>B30</td> <td>B40</td> <td>B50</td> <td>B60</td> <td>B70</td> <td rowspan="2" style="vertical-align: middle;">← Bit address</td> </tr> <tr> <td>to BF</td> <td>to B1F</td> <td>to B2F</td> <td>to B3F</td> <td>to B4F</td> <td>to B5F</td> <td>to B6F</td> <td>to B7F</td> </tr> </table> <p style="text-align: center; margin-top: 10px;">I/O cards</p> </div> <p>* The above example shows eight 16-point I/O cards mounted.</p>					WB0	WB1	WB2	WB3	WB4	WB5	WB6	WB7	← Word address	F55	Mount location dedicated for the T-link master card	B0	B10	B20	B30	B40	B50	B60	B70	← Bit address	to BF	to B1F	to B2F	to B3F	to B4F	to B5F	to B6F	to B7F
		WB0	WB1	WB2	WB3	WB4	WB5	WB6	WB7	← Word address																							
F55	Mount location dedicated for the T-link master card	B0	B10	B20	B30	B40	B50	B60	B70	← Bit address																							
		to BF	to B1F	to B2F	to B3F	to B4F	to B5F	to B6F	to B7F																								
Restrictions	<p>Install I/O cards from the leftmost position toward the right. Avoid making any empty slots between cards.</p> <div style="display: flex; justify-content: space-around; align-items: flex-end;"> <div style="text-align: center;"> <p>Incorrect</p>  </div> <div style="text-align: center;"> <p>Correct</p>  </div> </div> <p>* Presence of empty slots is regarded as a fatal fault when the power is turned on. When the system is diagnosed by means of a loader (D20), the following screen appears.</p> <div style="border: 1px solid black; padding: 10px; margin: 10px auto; width: fit-content;"> <pre style="font-family: monospace; font-size: 0.9em;"> DIRECT I/O FAULT (BUS ERROR) (F120) F10 MENU MONITORING SLOT NO. ERR INF (-3 TIMES) (-2 TIMES) (-1 TIMES) (0 TIMES) 3 UNUSED SLOT </pre> </div> <p>The 5V DC power for internal circuit in each card is supplied from the processor via the rack. For power consumption and other operating conditions of each card, see Section 3, "Specifications".</p>																																
Word address assignment for each card	<p>Each of I/O and function cards has different number of occupied words. (See Section 3.) Inside the unit, word address is assigned in order of WB0, WB1, and WB2 from the processor side. (For details, see subsection 2.3.2, "Address Assignment".) When direct access is defined, word addresses from W24 on are occupied. For details, see the user's manual <Instructions> (FEH160).</p>																																

2.2 Types of System Configuration

2.2.2 Expansion system

An example expansion system and restrictions on the system are shown in the following table. (Basic unit case version 1001 or later)

Basic unit	NV1P-042	NV1P-062	NV1P-082
Expansion unit	NV1E-042	NV1E-062 <i>Under development</i>	NV1E-082
Maximum number of cards mounted	4	6	8
Example system configuration	<p>The diagram illustrates the system configuration. It shows two racks connected by an extension cable. The top rack is the 'Basic unit' (F55 processor rack) with 8 word banks (WB0-WB7). Each word bank has 16-bit addresses (B0-B7F). The bottom rack is the 'Expansion unit' (F55 expansion unit with power supply) with 8 word banks (WB8-WB15). Each word bank has 16-bit addresses (B80-B15F). An extension cable (1m max.) connects the two racks. A note indicates that all addresses shown are example addresses for 16-point I/O cards.</p>		
	* Address assignment is made continuously from the basic unit to expansion unit.		
Maximum number of I/O points	512 (Basic unit: 32 x 8 slots, Expansion unit: 32 x 8 slots)		
Restrictions	<p>Install I/O cards from the leftmost position toward the right. Avoid making any empty slots between cards. The 5V DC power for internal circuit in each card is supplied from the processor via the rack. For power consumption and other operating conditions of each card, see Section 3, "Specifications".</p> <p>Note that some cards (using interrupt) cannot be mounted on the expansion unit.</p> <ul style="list-style-type: none"> • High-speed counter card (NV1F-HC1) • External interrupt card (NV1F-YP1) <p>Be sure to turn on the power of the expansion unit first and then the power of the basic unit. (They can be turned on at the same time.)</p> <p>If the power of the basic unit is turned on first, the following conditions result.</p> <ul style="list-style-type: none"> • The system operates only with the basic unit with the expansion unit not recognized. • In some cases, some I/O slots on the expansion unit are recognized as empty slots, resulting in direct connection I/O failure. • Be sure to turn off the power of the basic unit and then the power of the expansion unit. (They can be turned off at the same time.) If the power of the expansion unit is turned off first, a bus error may occur. 		
Word address assignment for each card	<p>Each of I/O and function cards has different number of occupied words. (See Section 3.) Inside the unit, word address is assigned in order of WB0, WB1, and WB2 from the processor side. (For details, see subsection 2.3.2, "Address Assignment".)</p> <p>When direct access is defined, word addresses from W24 on are occupied. For details, see the user's manual <Instructions> (FEH160).</p>		


2.2 Types of System Configuration

2.2.3 Distribution system (T-link system)

An example distribution system and restrictions on the system are shown in the following table.

When configuring a T-link system, the T-link master interface card (NV1L-TL1) must be installed in the basic unit.

Example system configuration



Note: *2 The I/O modules for the F55 series cannot be used on the T-link I/F module base board.

Maximum number of I/O points	1600
Restrictions	Install I/O cards from the leftmost position toward the right. Avoid making any empty slots between cards. The 5V DC power for internal circuit in each card is supplied from the processor via the rack. For power consumption and other operating conditions of each card, see Section 3, "Specifications". Each of I/O and function cards has different number of occupied words. (See Section 3.)
Word address assignment for T-link devices	Inside the unit, word address is assigned in order of WB0, WB1, and WB2 from the processor side. (For details, see subsection 2.3.2, "Address Assignment".) When direct access is defined, word addresses from W24 on are occupied. For details, see the user's manual <Instructions> (FEH160). For T-link devices, the word address consists of the address set by the address setting device and a trailing word address.


2.2 Types of System Configuration

2.2.4 T-link slave system

An example T-link slave system and restrictions on the system are shown in the following table.

When configuring a T-link slave system, the T-link slave card (NV1L-TS1) must be installed in the basic unit.

Example system configuration



- All addresses shown are example addresses for 16-point I/O cards and I/O capsules.
- Addresses without () are addresses viewed from processor ① and addresses with () are addresses viewed from processor ②.

Word address assignment for T-link devices

On the front side, the T-link slave card is provided with an I/O word address setter for setting addresses viewed from the master processor. The following describes the address assignment for the system configuration above.

- The address for the T-link slave card installed in the rack of processor ② is set to "30".
- With the above example, processor ② is a slave processor and processor ① master processor, and the address relationship is as follows:


Address viewed from the slave processor	Address viewed from the master processor
WB002 (input)	WB032 (output)
WB003 (input)	WB033 (output)
WB004 (output)	WB030 (input)
WB005 (output)	WB031 (input)

- The number of I/O words can be changed by the T-link slave card setting. With the above example, 2 words are set for input and output.
- The address set with the address setter is assigned from the input side viewed from the master processor (or output side viewed from the slave processor).

2.3 Address Assignment

2.3.1 Memory map

The memory map of the F55 series processor is as follows:



2.3 Address Assignment

2.3.2 Address assignment





The F55 series is provided with up to 100 words (WB000 to WB099, 1 word = 16 bits) on the T-link, to

each address a card capsule or other PIO (I/O data operating on the F55 processor) is assigned.

(1) Address conventions (on the T-link)

- ① Address assignment is made automatically from the top of the I/O area, depending on the number of points occupied by each slot. However, it is made on a 16 point (1 word) basis. For 8 point I/O areas, 8 points from bits 8 to F are regarded as empty points.
- ② When a card occupying two or more words is connected, the address for the next card is shifted by the excessive amount of words.
- ③ Addresses for the capsule type are set using the setter mounted on the front side. Addresses can be set in an arbitrary way, but address duplication is inhibited.
- ④ The address for the module to the right of the T-link interface module is equal to the number set in the setter which is mounted on the front side of the T-link interface module. Subsequent address assignment is made in order of installation toward the right.

● Example setting of the address setting switch on the FTK/FTL

Upper dial		
Lower dial		
Set value	05	35

- ⑤ The number of connection words in the I/O area is 1600 points (100 words) maximum.
- ⑥ The number of connectable capsules is as follows:

Processor	Program loader	I/O capsule T-link interface T-link equipment
1 unit	2 units per link	Up to 32 units

(2) Address assignment in the same unit as processor

① Simultaneous scan mode (Example)

		0	1	2	3	4	5	6	7
F55	T-link master (option)	WB 0	WB 1 · 2	WB 3	WB 4	WB 5 · 6	WB 7 · 8	WB 9	WB 10
		16	32	16	16	32	32	16	16

The B area channel is fixed to "0" and address assignment is made from slot No.0 on. Address assignment for the expansion unit is made continuously with that for the basic unit (basic unit case version 1001 or later).

← Number of I/O points

② Direct access mode (fixed)

		0	1	2	3	4	5	6	7
F55	T-link master (option)	W24.0 to 15	W24.16 to 31	W24.32 to 47	W24.48 to 63	W24.64 to 79	W24.80 to 95	W24.96 to 111	W24.112 to 127

A total of 16 words are fixed to each slot. Address assignment is made within a range from W24.000 to W24.127. In this case, address assignment for the T-link interface module can be started from WB0.

2.3 Address Assignment

- ③ Direct access mode (fixed)
(Basic unit case version 1001 or later)

		1	2	3	4	5	6	7	8	
F55 (processor rack)	T link master (option)	W24.0	W24.16	W24.32	W24.48	W24.64	W24.80	W24.96	W24.112	■
		to 15	to 31	to 47	to 63	to 79	to 95	to 111	to 127	

Basic unit

		8	9	10	11	12	13	14	15	
F55 (expansion rack)	Blank cover (unused)	W24.128	W24.144	W24.160	W24.176	W24.192	W24.208	W24.224	W24.240	■
		to 143	to 159	to 175	to 191	to 207	to 223	to 239	to 255	

Expansion unit

Additional
1 unit
installed

A total of 16 words are fixed to each slot. Address assignment is made within a range from W24.000 to W24.255. In this case, address assignment for the T-link interface module can be started from WB0.

2.4 Peripheral Devices

2.4.1 Types of peripheral devices


The following types of program loader are offered for the F55 series. Select a type which best suits your application.

Name	Typical type, () indicates old type	Remarks
D10S	NL1H (FLD010S-A10)	Handy type
D20	NL2H (FLD020A-A10)	Hand-held type
Hardware: LITE Software: D25	NH3H (FLT-SS-A10)	Laptop type
Personal computer loader	NL4N-98SS□ (FLT-FD98P□) : NEC PC-98 series NL4N-ATSS□ (FLT-FDIAT□) : IBM PC/AT series NL4N-J3SS□ (FLT-FD31J□) : Toshiba J3100 series NL4N-FMSS□ (FLT-FDFM□) : Fujitsu FMR series	Operates on a personal computer

* For version numbers accommodating each personal computer, see subsection 1.2.

2.4.2 D10S

■ System configuration




■ Component

Name	Typical type, () indicates old type	Remarks
Data recorder	Use a commercial data recorder. Recommended: PQ8030, RQ8030, Matsushita MR-22DR, Sanyo DR-20, Aiwa	Used to store user programs on CMT (cassette magnetic tape). If the program capacity exceed 5kW, use of floppy disks is recommended.
PROM writer	NL2V-PRW (FRW100A)	Used to write user programs to ROMs.

2.4 Peripheral Devices

2.4.3 D20

■ System configuration




■ Component

Name	Typical type, () indicates old type	Remarks
Data recorder	Use a commercial data recorder. Recommended: PQ8030, RQ8030, Matsushita MR-22DR, Sanyo DR-20, Aiwa	Used to store user programs on CMT (cassette magnetic tape). If the program capacity exceed 5kW, use of floppy disks is recommended.
PROM writer	NL2V-PRW (FRW100A)	Used to write user programs to ROMs.
Printer	NL2V-PRT (FLP100A)	Used to print user programs.
3.5" micro floppy disk unit	NL2V-FFD (FFD100A-A10)	Used to store user programs in floppy disks.

2.4 Peripheral Devices

2.4.4 D25 (LITE)

■ System configuration




■ Component

*PROM writer and floppy disk drive are built in.

Name	Typical type	Remarks
Data recorder	Use a commercial data recorder. Recommended: PQ8030, RQ8030, Matsushita MR-22DR, Sanyo DR-20, Aiwa	Used to store user programs on CMT (cassette magnetic tape). If the program capacity exceed 5kW, use of floppy disks is recommended.
JIS keyboard	Use a commercial product. For details, see the USER'S MANUAL of PROGRAM LOADER LITE <LEH915>.	Used to enter comments from outside the loader.
Printer		Used to print user programs.
External CRT		Used to provide large screen display.

2.4 Peripheral Devices



Name	Typical type, () indicates old type	Remarks	
Personal computer	NEC : PC-98 series	For details on personal computers, see each individual user manual.	
	IBM : PC/AT series		
	Toshiba : J3100 series		
	Fujitsu : FMR series		
Personal computer interface board	NH3L-TB198H (FFU098B)	For PC-98 series	Installed in an expansion slot of the personal computer to transfer data between the personal computer and the PC via the T-link.
	NH3L-TB1ATH (FFU080A)	For PC/AT series For J3100 series	
	NH3L-TB1FMH (FFU050A)	For FMR series	
General-purpose interface capsule	NH2L-RS1 (FFK120A-C10)	Connected to the personal computer through the RS-232C interface to transfer data between the personal computer and the PC via the T-link.	
Loader conversion adapter	NL4V-ADT (FLT-ASFK)	Connected to the personal computer through the RS-232C interface to transfer data between the personal computer and the PC via the T-link.	

Section 3 Specifications


	Page
3.1 Basic Specifications	3-2
3.1.1 Power supply specification	3-2
3.1.2 General specifications	3-2
3.2 Specifications	3-5
3.3 I/O Specifications	3-6
3.3.1 Notes on selecting I/O devices	3-6
3.3.2 Life curve of relays	3-11
3.3.3 Load types and inrush current	3-11
3.3.4 Protection of contacts	3-12
3.3.5 Contact transfer	3-12
3.3.6 Derating	3-13
3.4 I/O Card Specifications	3-19
3.5 Specifications of Function Cards	3-29
3.6 I/O Capsule (Unit) Specifications	3-42
3.6.1 I/O terminal	3-42
3.7 T-link Specifications	3-49

Section 3 Specifications

3.1 Basic Specifications

3.1.1 Power supply specification

Item		Description
Power supply	Rated voltage (operating voltage range)	100 to 200V AC (85 to 264V AC)
	Rated frequency (operating frequency range)	50/60Hz (47 to 63Hz)
	Allowable instantaneous power failure period	AC: 1 cycle or less
	Waveform distortion	5% or less (square wave not applicable)
	Power consumption	AC: 40VA max.
	Inrush current	AC: 40A or less (10ms or less)
	Leakage current	1mA or less



Used to connect 24V DC for relay card driving (19.2 to 26.4V DC)
*Be sure to apply this voltage when using the relay card.

3.1.2 General specifications

The specifications common to the main unit, I/O cards, and function cards are shown in the table below.

Item		Specification
Dielectric strength		1500V AC, 1 minute, between external terminals and ground
Insulation resistance		5MΩ or more with a 500V DC megger, between external terminals and ground
Physical environment	Operating temperature	0 to +55°C
	Storage temperature	-20 to +70°C
	Relative humidity	20 to 90%RH (without condensation)
	Dust	No conductive dust present.
	Corrosive gas	No corrosive gas present. No organic solvent, leaked cutting oil, or water droplets present.
Mechanical conditions	Resistance to vibration	JIS C 0911, crossover frequency 57Hz, 19.6m/s ² (2G), 2 hours in 3 axis directions*
	Resistance to shock	JIS C 0912, test procedure 1-No. 3, malfunction shock 147 m/s ² (15G), endurance shock 294 m/s ² (30G), 2 times in 3 axis directions*
Electrical conditions	Noise immunity	1500V by noise simulator, rising time 1ns, pulse width 1μs, 10 minutes
	Resistance to discharge of static electricity	JIS B 3501 ESD-4, 8kV contact discharge, 16kV gaseous discharge
Installation conditions	Structure	Mounted on a rack or built-in panel
	Cooling system	Self cooling
	Ground	Resistance of 100Ω or less
	Mass	Approx. 2300 g (with 16-point output card x 8 and T-link master card)
	Dimensions	380mm (W) x 95mm (H) x 97mm (D) (with output card x 8) (See subsection 4.2.)

* With the unit mounted on the control panel using mounting screws. When attaching the rail, be careful not to apply vibration or shock.

3.1 Basic Specifications

The capacity of the basic unit, expansion unit, and T-link master card is shown in the table below.

Unit type	Supply voltage	Output voltage	
		5V DC *1	24V DC external power supply *2
NV1P-042	100 to 200V AC	2.5A	None
NV1P-062			
NV1P-082			
NV1E-042			
NV1E-062			
NV1E-082			

*1 Note that the output current for 5V DC includes the current consumption of the basic unit and the T-link master interface card. Take this point into account when calculating the current capacity.

*2 The 24V DC supply is used for a relay output card and other relay driving devices or input devices (proximity and photoelectric switches). If this power supply is not present, supply 24V DC power externally through the dedicated terminal.

Calculating the current capacity that can be supplied to I/O cards

The current capacity that can be supplied to I/O cards is calculated by subtracting the current consumed by internal logic of the basic unit and the current consumed by the D10S program loader or NL4V-ADP loader adapter* from the current capacity of the 5V DC power supply.

When the D10S program loader or NL4V-ADP loader adapter is connected to the PC or T-link interface, it is

powered from the processor or T-link. Therefore, if these devices are not to be used, subtracting the current consumption is not necessary. A loader LITE or D20 program is provided with a power supply, subtraction of current consumption need not be taken into account. The current consumption of the basic unit is shown in the table below.

Type	5V DC current consumption
Basic unit NV1P-042/062/082 (case versions 0001 to 0999)	430mA
Basic unit NV1P-042/062/082 (case version 1001 or later)	475mA
Basic unit NV1E-042/062/082 (case version 1001 or later)	400mA
T-link master interface card NV1L-TL1 (basic unit case versions 0001 to 0999)	60mA
T-link master interface card NV1L-TL1 (basic unit case version 1001 or later)	90mA
Program loader NL1H (D10S)	600mA
Loader adapter NL4V-ADP*	300mA

* For connection to a personal computer loader

Selecting power supply

When selecting 5V DC and 24V DC power supply units and I/O cards to be mounted on the same unit, observe the following conditions:

$$(\text{Current consumption of basic unit or expansion unit}) + (\text{Current consumption of T-link master interface card}) + (\text{Current consumption of I/O cards}) \leq \text{Current capacity of power supply}$$

3.1 Basic Specifications

The weight of the basic unit, expansion unit, and the T-link master interface card is as follows:

Unit, card	Mass
Basic unit NV1P-042/062/082 (case versions 0001 to 0999)	Approx. 790/860/930g *1
Expansion unit NV1P-042/062/082 (case version 1001 or later)	Approx. 1000/1170/1340g *1
Expansion unit NV1E-042/062/082	Approx. 860/1230g *2
T-link master card NV1L-TL1	Approx. 80g

*1 With no option or I/O cards mounted on the basic unit
(blank covers on slots for T-link master interface card and I/O cards)

*2 With no I/O cards mounted on the expansion unit
(blank covers on slots for T-link master card and I/O cards)
The NV1E-062 is under development.

3.2 Specifications

Item	Specification	Remarks	
Control system	Cyclic operation, fixed-cycle interrupt, external interrupt	Stored program system	
I/O connection system	Direct connection I/O, remote I/O (T-link)		
I/O control system	Scan synchronization refresh, direct refresh		
CPU	Processor specialized for sequence, 16 bit general-purpose processor		
Memory type	1M byte CMOS RAM standard 1M byte EPROM for expansion (basic unit case versions 0001 to 0999)	*1	
Programming language	Ladder diagram (control-oriented language: FPL)	F-series Programming Language	
Instructions	Sequence instructions: 22 Data instructions: 76	Sequence instruction: Used for contacts Data instruction: Used for transfer	
Word length of instructions	Sequence instructions (contacts): 1 step/instruction Data instructions (transfer): 3 steps/instruction		
Execution speed	Sequence instructions (contacts): 0.8 μ s/instruction Data instructions (transfer): 189 μ s/instruction	*2	
Program memory capacity	10578 steps		
Number of I/O points	1600 points maximum (when T-link system is used)	*3	
Relay	I/O relay (B)	1600 points (B0000 to B099F) 4800 points (B1000 to B399F)	Can be used as an auxiliary relay. Can be used only as an auxiliary relay.
	Direct I/O (W24)	160 words (basic unit case versions 0001 to 0999)	1 word = 16 bits *4
	Auxiliary relay (M)	4096 points (M0000 to M255F)	
	Keep relay (K)	1024 points (K0000 to K064F)	
	Differential relay (D)	1024 points (D0000 to D064F)	
	Special relay (F)	1120 points (F0000 to F069F)	
	Annunciator relay (A)	320 points (A0000 to A019F)	
	Timer (T)	0.01 sec 256 points (T0000 to T0255) 0.1 sec 256 points (T512 to 767)	BCD 8 digit
	Counter (C)	256 points (C0000 to C0255)	
	Step control relay (S)	100 steps x 100 sets (S00.00 to S99.99)	
	Data memory (BD)	4k double words	1k: 1024 double words 1 double word = 32 bits
	File memory (W30)		
Memory backup	Backup range: program memory and data memory Battery used: Lithium battery (life expectancy 5 years) Backup period: 5 years (at 25°C)		
Available memory	EPROM (ROM card required)	*1	
Data type	BCD: -7999 to 7999 (16 bits), -79999999 to 79999999 (32 bits) Binary: -32768 to 32767 (16 bits)		
Diagnostic functions	Execution slow-down monitoring, battery voltage drop detection, program syntax check, system configuration monitoring, module fault monitoring		
Security functions	By password (4 digit number, program monitoring not allowed at setting)	4 digit hexadecimal (0 to F)	
Other functions	Calendar function	*5	

*1 For basic unit case version 1001 or later, optional EPROM and EEPROM cards can be installed.

*2 The execution time for basic unit case version 1001 or later is 0.5 μ s/sequence instruction (contact) or 120 μ s/data instruction (transfer).

*3 For basic unit case versions 0001 to 0999, up to 256 points (32 points x 8 slots) for basic unit only; for basic unit case version 1001 or later, up to 512 points (32 points x 8 slots + 32 points x 8 slots) for basic and expansion units

*4 For basic unit case version 1001 or later, 256 words for basic and expansion units

*5 The calendar function can be used only when the T-link master interface card (NV1L-TL1) is installed on the basic unit. (Basic unit case version 1001 or later)

3.3 I/O Specifications

3.3.1 Notes on selecting I/O devices

The following notes describe the selection of I/O devices of card and capsule types used with the F55 series. I/O devices of the card type are mounted on the


rack, and those of the capsule type are installed alone on the T-link.

(1) Notes on selecting input devices (card type and capsule type)

① Input power supply specifications

Because the DC input of the capsule type incorporates a rectifier circuit, it can be used either with positive common or negative common.


- Example circuit of input devices with sink-type transistor output



Input devices Sink-type (negative common) transistor output

Remarks: Commonly used in Japan.

- Example circuit of input devices with source-type transistor output



Input devices Source-type (positive common) transistor output

Remarks: Commonly used in Europe

When the input DC voltage of the PC is 24V DC, the 24V DC power supply mounted on the following I/O capsules can be used.

- Input cards and capsules whose 24V DC power supply can be used

24V DC power supply	Input card/capsule
Power supply mounted	NH2X1613 (FTK110A-C10), NH2X1604 (FTK113A-C10) NH2X3213 (FTK120B-C10), NH2X3204 (FTK123B-C10) NH2W32 (FTK611B-C10), NH2W1613 (FTK616A-C10)
Auxiliary power supply module	All 24V instruments

* With the NH2X3213/3204/NH2W32, the number of ON points is limited when using the 24V power supply mounted on I/O capsules.

3.3 I/O Specifications

• External power supply specifications for input cards and capsules


Input specifications	Response time	Type	Power supply specifications	
			DC voltage: average value	AC voltage: rms value
12 to 24V AC/DC	10ms	NH2X1613 (FTK110A-C10), NH2X3213 (FTK120B-C10), NH2W1613 (FTK616A-C10)	Smoothing DC power supply Single-phase full-wave rectified DC power AC power supply	9.6 to 26.4 (30)V 9.6 to 26.4 (30)V 9.6 to 26.4 (30)V
12 to 24V DC	3ms	NH2X1604 (FTK113A-C10), NH2X3204 (FTK123B-C10), NH2W32 (FTK611B-C10)	Smoothing DC power supply	9.6 to 26.4 (30)V Note: NHSX1613, NH2W1613, NH2X1694, maximum input voltage for 16-point input is 30V.
	10ms	NV1X1604, NV1X1604-W NV1X3204, NV1X3204-W	Smoothing DC power supply	8.4 to 26.4V
48V AC/DC	10ms	NH2X1614 (FTK130A-C10)	Smoothing DC power supply Single-phase full-wave rectified DC power AC power supply, 50/60Hz	38 to 60V 38 to 60V 38 to 60V
48V DC	3ms	NH2X1607 (FTK133A-C10)	Smoothing DC power supply	38 to 60V
110V AC/DC	10ms	NH2X0816 (FTK140A-C10)	Smoothing DC power supply Single-phase full-wave rectified DC power AC power supply, 50/60Hz	80 to 140V 80 to 140V 80 to 140V
110V DC	3ms	NH2X0809 (FTK143A-C10)	Smoothing DC power supply	80 to 140V
24V DC	10ms	NV1X3206	Smoothing DC power supply	15 to 26.4V

Note: The type in () in the type column indicates the conventional type.

② Input power supply

As shown in the figure below, the AC input circuit is the capacitor-input type for the purpose of reducing heat in the internal circuit. When an external input

device is turned on, inrush current flows, which may cause contact welding of lead switches having a small current capacity.



Use switches with an appropriate current capacity, referring to the following table.

• External power supply specifications for input capsules

Input specifications	Type	Input current	
		Nominal current	Inrush current (peak value)
100V AC	NH2X1610 (FTK150A-C10)	Approx. 10mA	150mA or less, time constant of 0.4ms or less (100V AC input)
200V AC	NH2X1611 (FTK160A-C10)	Approx. 10mA	300mA or less, time constant of 0.2ms or less (200V AC input)

Note: The type in () in the type column indicates the conventional type.

3.3 I/O Specifications



(2) Notes on selecting output devices (card type and capsule type)

① Transistor output

When using transistor output, supply DC power for transistor driving, as shown in the figure below.

• Example circuit of 16-point sink-type transistor output

• Example circuit of 16-point source-type transistor output



When 16 points are all ON: 16 x (load current + 3mA)

- Normally an identical power supply is used both for transistor driving and the load. However, if separate power supply units are used, countermeasures for preventing sneak-circuit formation are required. (See page 3-12.)

- For 32 point transistor output, supply the power externally.
- Specifications of the DC power supply for transistor driving are shown in the table below.

Output specifications		Type *3	Power supply specifications
5 to 12 to 24V DC	Sink	NH2W32 (FTK611B-C10), NV1Y16T05P5, NV1Y32T05P1	Smoothing DC power supply (4.75) 9.6 to 26.4V *1 (Single-phase full-wave rectified DC power supply is not applicable.)
24 to 48V DC	Sink	8NH2Y16T01P2 (FTK210A-C10), NH2Y16T0120 (FTK211A-C10), NH2Y32T (FTK220B-C10)	Smoothing DC power supply (10.2) 19 to 60V *2 Single-phase full-wave rectified DC power supply (10.2) 19 to 60V
	Source	NH2Y16U01P2 (FTK215A-C10), NH2Y16U0120 (FTK216A-C10), NH2Y32U (FTK225B-C10)	Same as above
110V DC	Sink	NH2Y16T02 (FTK240A-C10)	Smoothing DC power supply (40.8) 90 to 140V *2 Single-phase full-wave rectified DC power supply (40.8) 90 to 140V
	Source	NH2Y16U02 (FTK245A-C10)	Smoothing DC power supply (40.8) 90 to 140V *2 (Single-phase full-wave rectified DC power supply is not applicable.)

*1 For 5 to 12 to 24V DC output, the maximum load current becomes 30mA (NH2W32) or 16mA (NV1Y32T05P1) with the voltage in ().

*2 Although 24 to 48V DC output and 110V DC output operate on the voltage in (), the maximum load current must be reduced as shown in the following section.

*3 The type in () in the type column indicates the conventional type.

3.3 I/O Specifications

- ② Use with a low-voltage power supply with transistor output


If the maximum load current is reduced, capsule-type transistor output can be used with a low-voltage power supply that supplies voltages lower

than the rated operating voltage. (See the following figure and table.)

- Maximum load current when a low-voltage power supply is used


Rated operating voltage and maximum load current	Maximum load current when a low-voltage power supply is used
24 to 48V (19 to 60V) DC 0.2A	10.2V (12V x 0.85) DC 0.15A
24 to 48V (19 to 60V) DC 2A	10.2V (12V x 0.85) DC 1.5A
110V (90 to 140V) DC 0.2A	40.8V (48V x 0.85) DC 0.15A

- Example of current reduction ratio



- ③ High-frequency on/off operation
For applications with high-frequency on/off operation or applications with on/off operation of the inductive load such as operation coil of the electromagnetic contactor, use of triac output is recommended if the operating life of relay output is a crucial factor.

- ④ Relay output (cards and capsules)
When card-type relay output is used, supply 24V DC externally for relay driving as shown below.



In this case, power must be supplied from the 24V DC input terminal of the basic unit. For capsule-type relay output, supplying this voltage is not necessary because the power supply is built-in.


The relay used for a relay output card is suitable for power driving. With light loads of 12V DC and 3mA or less (low voltage and small current), contact reliability is reduced. In this case use of a DC output card (transistor output type) is recommended.

If relay (contact) output must be used for connection, miniature relays with a contact having high contact reliability (low voltage and small current) are recommended.

Because the relay output card does not incorporate any surge absorbing element (varistor), connect an external CR surge absorber (0.1 μ F + 100 Ω) to protect the internal circuits.

3.3 I/O Specifications

- ⑤ Common terminal (supply pin)
Because the common terminals for relay output, triac output, DC input, and AC input are electrically isolated, different power supply units can be used for each common terminal.




Capsule-type transistor output cannot be used in the same manner as above because the common terminals are not isolated.

3.3.2 Life curve of relays


The life expectancy of contacts depends on the voltage, current and the type of load connected. Determine the electrical life of contacts and replacement period of cards by taking the following graphs into account.

[Electrical life curve for card relay RB1]



Test conditions

On/off frequency: 1800 times/hour
 On load factor: 40%
 Time constant L/R=15ms (inductive load)



3.3.3 Load types and inrush current


The load types and inrush current characteristics have remarkable effects on relay contacts. In particular,

- Motors, electromagnetic contactors, and solenoid valve
 With these loads, the value of inrush current is 3 to 10 times that of the rated current. In addition, when inrush current lasts for a long time, such as under a motor load, breaking of inrush current may cause contact welding.
- Lamp loads
 With lamp loads, the value of inrush current is 5 to 15 times that of the rated current. Because the inrush current may cause contact welding, in particular when a lamp with a large current capacity is to be turned on and off, it is recommended that confirmation test be performed using the actual load. The figures as shown at right are examples of the relationship between current waveform and time for each load. (I_p : Inrush current, I_o : Rated current)


inrush current can cause contact welding, and must be taken into account together with the rated current.

[Relationship between current waveform and time for each load]

- Motor loads
 $I_p/I_o=5$ to 10 times



- Halogen lamp loads
 $I_p/I_o=5$ to 15 times



3.3 I/O Specifications

3.3.4 Protection of contacts







When an inductive load such as motors, clutches, and solenoids is turned off, counter electromotive forces of several hundreds to thousands volts are generated, which may greatly shorten the electrical life of contacts. This is because the energy $1/2Li^2$ accumulated in the coil (L: inductance of coil) is consumed by discharge between contacts when an inductive load is turned off. Therefore, to absorb the counter

electromotive force, use of a contact protection circuit is recommended.

The following shows some examples of contact protection circuits; in each case AC or DC voltage must be used appropriately.

Note that using a contact protection circuit may slightly extend the recovery time.


[Contact protection circuit]

Example circuit	Judgment	Notes on use
	No good	(1) The contact tends to be welded when the contact is closed. (2) With AC voltage, leakage voltage may occur at the load.
	No good	(1) The contact tends to be welded when the contact is closed.
	Good	(1) $C = 0.1$ to $1 \mu F$, r nearly equals R (2) With AC voltage: • Not applicable if the load impedance (R) is larger than the impedance of C or R • Applicable if the load impedance (R) is sufficiently small compared with the impedance of C or R
	Good	(1) $C = 0.1$ to $1 \mu F$, r nearly equals R (2) AC and DC voltages applicable
	Good	(1) DC voltage only (2) AC voltage not applicable
	Good	(1) AC and DC voltages are applicable.

3.3.5 Contact transfer

Contact transfer refers to a phenomena in which one side of contact melts or evaporates and is transferred to the other side because of on/off operation of the DC load. As the number of on/off times increases, the protruded portion on one contact grows and the embossed portion on other contact becomes correspondingly larger. Eventually the two contacts are locked as if contact melting occurred. This phenomena

may occur within the ratings of relay contacts. In particular, when a relay is used to turn on and off a capacitive load, this phenomena may occur. In this case, use a resistor to suppress inrush current.




3.3 I/O Specifications

3.3.6 Derating


With input and output cards, the number of points that can be ON simultaneously is restricted by the input

- 16 point input (NV1X1604/1604-W)




voltage and ambient temperature. Therefore, derating is necessary as shown in the figures below.


- 32 point input (NV1X3204/3204-W/3206)




- 8 point output (NV1Y08R-00)




- 16 point output (NV1Y16R-08)




- 16 point output (NV1Y16T05P5)



- 32 point output (NV1Y32T05P1)



ONE-POINT ADVICE Tips for Preventing I/O Malfunctions



Example of malfunction of I/O circuit and its countermeasure


When digital I/O (DIO) is used, malfunction of the I/O circuit may occur. For example, even if an external input device (such as a sensor) is turned off, the PC input remains turned on; or even if the PC output is turned off, an external output device (such as a lamp) remains turned on.

The following table shows the causes and countermeasures for each case of malfunction, which should be taken into account in designing hardware.

(1) Input circuit malfunctions

Status	Cause	Countermeasures
<p>—Case 1— The input signal does not go off.</p>	<ul style="list-style-type: none"> Leakage current from external equipment (driven by a proximity switch) 	<ul style="list-style-type: none"> Connect an appropriate resistor and capacitor so that the voltage between terminals of the input card is lower than the recovery voltage value.
<p>—Case 2— The input signal does not go off. (The neon lamp remains on in some cases.)</p>	<ul style="list-style-type: none"> Leakage current from external equipment (driven by a limit switch with a neon lamp) 	<ul style="list-style-type: none"> The CR value is determined by the leakage current value. Recommended value C: 0.1 to 0.47μF R: 47 to 120Ω (1/2W) Alternatively, a display circuit is installed separately as an independent circuit.
<p>—Case 3— The input signal does not go off.</p>	<ul style="list-style-type: none"> Leakage current due to stray capacitance between cables 	<ul style="list-style-type: none"> Same as case 1. The power supply is installed outside the external equipment as shown below.
<p>—Case 4— The input signal does not go off.</p>	<ul style="list-style-type: none"> Leakage current from external equipment (driven by a switch with an LED indicator) 	<ul style="list-style-type: none"> Connect an appropriate resistor so that the voltage between the input card terminal and the common line is higher than the OFF voltage.
<p>—Case 5— The input signal does not go off.</p>	<ul style="list-style-type: none"> Sneak-circuit formed by the use of two independent power supplies. <p>• When E1>E2, a sneak-circuit is formed.</p>	<ul style="list-style-type: none"> Use only one power supply. Connect a diode to prevent sneak-circuit formation.


ONE-POINT ADVICE Tips for Preventing I/O Malfunctions










(2) Output circuit malfunctions

Status	Cause	Countermeasures
<p>—Case 1— When the output circuit is turned off, excessive voltage is applied to the load.</p>	<ul style="list-style-type: none"> • Half-wave rectification is made inside the load, as is the case with solenoids. • When the polarity of the power supply is as in ① below, capacitor C is charged. When it is changed as in ②, the sum of the voltage charged and the power voltage is applied to both sides of diode D₁. In this case the maximum voltage value is about 2√2 E. <p>Note: With this usage, the output element has no problem but the diode (D₁) built into the load is deteriorated, which may cause burn or other failures.</p>	<ul style="list-style-type: none"> • Connect a resistor with several ten to hundred kΩ in parallel with the load.
<p>—Case 2— The load does not go off.</p>	<ul style="list-style-type: none"> • Leakage current due to the surge absorbing circuit being connected in parallel with the output element. 	<ul style="list-style-type: none"> • Connect a resistor of several ten kΩ or CR with the same impedance in parallel with the load. <p>Note: When the wiring distance between the output card and the load is long, there may be leakage current due to stray capacitance between leads.</p>
<p>—Case 3— When the load is a CR timer, timer operates incorrectly.</p>	<p>Same as case 2.</p>	<ul style="list-style-type: none"> • Drive the CR timer by means of a relay. • Use a timer of other than the CR type. <p>Note: Follow the note in case 1, because some timers perform half-wave rectification.</p>
<p>—Case 4— The load does not go off.</p>	<ul style="list-style-type: none"> • Loop-back circuit formed by the use of two power supply units <ul style="list-style-type: none"> • When E₁ > E₂, a sneak-circuit is formed. • When E₁ is off and E₂ is on, a sneak-circuit is also formed. 	<ul style="list-style-type: none"> • Use only one power supply. • Connect a diode to prevent sneak-circuit formation. <p>Note: When a relay is used as a load, connect a diode for absorbing counter electromotive force in parallel with the load, as shown by the dotted lines below.</p>

ONE-POINT ADVICE Tips for Preventing I/O Malfunctions




Status	Cause	Countermeasures
<p>—Case 5— The off response time of the load is excessively long.</p>	<ul style="list-style-type: none"> • Transient current when the load turned OFF. When a solenoid or other large current inductive load (with a large time constant L/R) is directly driven by transistor output.  <ul style="list-style-type: none"> • When transistor output is off, current flows through the diode and therefore the off response time may be delayed by 1 second or more. 	<ul style="list-style-type: none"> • As shown below, connect a control relay or magnetic contactor having a short time constant to drive the load. 
<p>—Case 6— The output transistor is destroyed. (Transistor output)</p>	<ul style="list-style-type: none"> • Inrush current of an incandescent lamp  <ul style="list-style-type: none"> • When an incandescent lamp lights up, inrush current more than 10 times rated current may flow. 	<ul style="list-style-type: none"> • To suppress inrush current, allow preheating current that is 1/5 to 1/3 times the rated current of the incandescent lamp to flow.  <p style="text-align: center;">Sink-type transistor output</p> <p style="text-align: center;">Source-type transistor output</p>
<p>—Case 7— The output triac is destroyed. (SSR output)</p>	<ul style="list-style-type: none"> • Excessive voltage is applied to the output element.  <ul style="list-style-type: none"> • When the output of the forwarding coil side is on, voltage is induced in the reversing coil, and excessive voltage (induced voltage + power voltage) is applied to the output of the reversing coil side that is off. • Voltage almost two times the power supply voltage may be applied. • The surge absorber may burn out before the triac is damaged. 	<ul style="list-style-type: none"> • Provide a magnetic contactor to drive the load.  <ul style="list-style-type: none"> • External interlock circuit is required.



(3) Example of calculating bleeder resistance

The following is example of calculating bleeder resistance, which is provided as a countermeasure for input malfunction due to leakage current of the LED circuit.

① Example malfunction



When $r=2.6\text{ k}\Omega$, leakage current I is as follows:


$$I = \frac{24}{(2.6 + 3.6) \times 10^3} \doteq 3.9 \times 10^{-3}(\text{A}) (= 3.9\text{mA})$$

In this case, the voltage given by the following expression is applied between input terminals of the input module.

$$3.9 \times 10^{-3} \times 3.6 \times 10^3 \doteq 14 (\text{V})$$


Because the voltage exceeds the OFF voltage of the input module (5.5 V), if a switch with LED is turned off, the input module remain on.

② Countermeasure



Insert a bleeder resistor (R) between the input terminals of the NV1X1604-W input module so that the voltage applied between them is reduced to 5.5 V or less.

ONE-POINT ADVICE Tips for Preventing I/O Malfunctions



③ Example calculation

- When the voltage applied to the bleeder resistor is 5.5 V, the current given by the following expression flows.

$$I = \frac{24 - 5.5}{2.6 \times 10^3} = 7.1 \times 10^{-3} \text{ (A)} (= 7.1\text{mA})$$

- R can be obtained from the following expression, by taking into account the input resistance and the bleeder resistance.

$$\frac{5.5}{R} > 7.1 \times 10^{-3} - \frac{5.5}{3.6 \times 10^3} \Rightarrow R < 990 \text{ } (\Omega)$$

- When R=820 (Ω), the capacity (P) of the bleeder resistor can be obtained from the following expression. (When a switch with LED is turned on, 24V DC is applied to the bleeder resistor.)

$$P = \frac{24^2}{820} \doteq 0.702 \text{ (W)}$$

Assuming a margin that is normally 3 to 4 times the above value, the capacity of the resistor is determined to be 3W.


Conclusion: Connect a bleeder resistor with 820 Ω /3W.

Note: Because of the connector terminal, a bleeder resistor cannot be connected to the 32-point type. When a limit switch with LED is to be used for 24V DC power supply, use the NV1X3206, which has a high OFF level (0 to 7.0V). When the input switch is off, the NV1X3204-W, which has a low OFF level (0 to 5.5V), is regarded as ON by the module side because of leakage current.

3.4 I/O Card Specifications

(1) Digital input (NV1X1604)


Item	Specifications		
Type	NV1X1604		
Number of input points (common configuration)	16 points (8 points/common, 2 circuits)		
Input signal	Rated voltage (allowable voltage range)	12 to 24V DC (10.2 to 26.4V DC)	
	Allowable ripple percentage	5% or less	
Input circuit characteristics	Input form	Source type	
	Rated current	3mA/point (12 V), 7mA/point (24V)	
	Input impedance	Approx. 3.6kΩ	
	Input operating voltage	OFF→ON	8.4 to 26.4V
		ON→OFF	0 to 5.5V
	Response time	OFF→ON	10ms or less
ON→OFF		10ms or less	
Connections	External connection	Detachable terminal block M3.5 screw (18 poles)	
	Applicable wire size (tightening torque)	0.75 mm ² or less (0.8 to 0.9 N·m [8 to 9 kgf·cm]) Common terminal: 1.25 mm ² or less	
Input signal display	When input circuit is on, LED lights point by point, logic side (displayed on the processor main unit)		
Insulation	Photocoupler		
Dielectric strength	1500V AC, 1 minute, between input terminals and ground		
Insulation resistance	10MΩ or more between input terminals and ground (at 500V DC megger)		
Derating conditions	Maximum simultaneous ON percentage: 75% maximum (26.4V DC/55°C)		
Current consumption	5V DC, 25mA or less (when all points are turned on)		
Number of words occupied	1 word		
Mass	Approx. 100g		



3.4 I/O Card Specifications

(2) Digital input (NV1X1604-W)


Item		Specifications	
Type		NV1X1604-W	
Number of input points (common configuration)		16 points (8 points/common, 2 circuits)	
Input signal	Rated voltage (allowable voltage range)	12 to 24V DC (10.2 to 26.4V DC)	
	Allowable ripple percentage	5% or less	
Input circuit characteristics	Input form	Source and sink types	
	Rated current	3mA/point (12V), 7mA/point (24V)	
	Input impedance	Approx. 3.6kΩ	
	Input operating voltage	OFF→ON	8.4 to 26.4V
		ON→OFF	0 to 5.5V
Response time	OFF→ON	10ms or less	
	ON→OFF	10ms or less	
Connections	External connection	Detachable terminal block M3.5 screw (18 poles)	
	Applicable wire size (tightening torque)	0.75mm ² or less (0.8 to 0.9 N·m [8 to 9 kgf·cm]) Common: 1.25mm ² or less	
Input signal display		When input circuit is on, LED lights point by point, logic side (displayed on the processor main unit)	
Isolation		Photocoupler	
Dielectric strength		1500V AC, 1 minute, between input terminals and ground	
Insulation resistance		10MΩ or more between input terminals and ground (at 500V DC megger)	
Derating conditions		Maximum simultaneous ON percentage: 75% maximum (26.4V DC/55°C)	
Current consumption		5V DC, 25mA or less (when all points are turned on)	
Number of words occupied		1 word	
Mass		Approx. 100g	



3.4 I/O Card Specifications

(3) Digital input (NV1X3204)


Item		Specifications	
Type		NV1X3204	
Number of input points (common configuration)		32 points (32 points/common, 1 circuit)	
Input signal	Rated voltage (allowable voltage range)	12 to 24V DC (10.2 to 26.4V DC)	
	Allowable ripple percentage	5% or less	
Input circuit characteristics	Input form	Source type	
	Rated current	2mA/point (12V), 4mA/point (24V)	
	Input impedance	Approx. 5.6kΩ	
	Input operating voltage	OFF→ON	8.4 to 26.4V
		ON→OFF	0 to 5.5V
Response time	OFF→ON	10ms or less	
	ON→OFF	10ms or less	
Connections	External connection	40 pin connector (FCN-361J040-AU)	
	Applicable wire size	AWG#23 (0.25mm ²) or less	
Input signal display		When input circuit is on, LED lights point by point, logic side (displayed on the processor main unit)	
Isolation		Photocoupler	
Dielectric strength		1500V AC, 1 minute, between input terminals and ground	
Insulation resistance		10MΩ or more between input terminals and ground (at 500V DC megger)	
Derating conditions		Maximum simultaneous ON percentage: 65% maximum (26.4V DC/55°C)	
Current consumption		5V DC, 45 mA or less (when all points are turned on)	
Number of words occupied		2 words	
Mass		Approx. 80g	



3.4 I/O Card Specifications

(4) Digital input (NV1X3204-W)


Item		Specifications	
Type		NV1X3204-W	
Number of input points (common configuration)		32 points (32 points/common, 1 circuit)	
Input signal	Rated voltage (allowable voltage range)	12 to 24V DC (10.2 to 26.4V DC)	
	Allowable ripple percentage	5% or less	
Input circuit characteristics	Input form	Source and sink types	
	Rated current	2mA/point (12V), 4mA/point (24V)	
	Input impedance	Approx. 5.6kΩ	
	Input operating voltage	OFF→ON	8.4 to 26.4V
		ON→OFF	0 to 5.5V
Response time	OFF→ON	10ms or less	
	ON→OFF	10ms or less	
Connections	External connection	40 pin connector (FCN-361J040-AU)	
	Applicable wire size	AWG#23 (0.25mm ²) or less	
Input signal display		When input circuit is on, LED lights point by point, logic side (displayed on the processor main unit)	
Isolation		Photocoupler	
Dielectric strength		1500V AC, 1 minute, between input terminals and ground	
Insulation resistance		10MΩ or more between input terminals and ground (at 500V DC megger)	
Derating conditions		Maximum simultaneous ON percentage: 65% maximum (26.4V DC/55°C)	
Current consumption		5V DC, 45mA or less (when all points are turned on)	
Number of words occupied		2 words	
Mass		Approx. 80g	



3.4 I/O Card Specifications

(5) Digital input (NV1X3206)


Item		Specifications	
Type		NV1X3206	
Number of input points (common configuration)		32 points (32 points/common, 1 circuit)	
Input signal	Rated voltage (allowable voltage range)	24V DC (19.2 to 26.4V DC)	
	Allowable ripple percentage	5% or less	
Input circuit characteristics	Input form	Source type	
	Rated current	4mA/point (24V)	
	Input impedance		Approx. 5.6kΩ
		Input operating voltage	OFF→ON: 15 to 26.4V ON→OFF: 0 to 7V
	Response time	OFF→ON	10ms or less
ON→OFF		10ms or less	
Connections	External connection	40 pin connector (FCN-361J040-AU)	
	Applicable wire size	AWG#23 (0.25mm ²) or less	
Input signal display		When input circuit is on, LED lights point by point, logic side (displayed on the processor main unit)	
Isolation		Photocoupler	
Dielectric strength		1500V AC, 1 minute, between input terminals and ground	
Insulation resistance		10MΩ or more between input terminals and ground (at 500V DC megger)	
Derating conditions		Maximum simultaneous ON percentage: 65% maximum (26.4V DC/55°C)	
Current consumption		5V DC, 45 mA or less (when all points are turned on)	
Number of words occupied		2 words	
Mass		Approx. 80g	



3.4 I/O Card Specifications

(6) Digital output (NV1Y08R-00)


Item	Specifications		
Type	NV1Y08R-00		
Number of output points (common configuration)	8 points (all points are independent)		
Output power	Rated voltage (allowable voltage range)	264V DC or less, 140V DC or less	
Output circuit characteristics	Output form and output type	Relay	
	Maximum load current	2A/point (30V DC/264V AC), 0.2A/point (110V DC)	
	Min. operating voltage and current	5V DC, 1mA	
	Response time	OFF→ON	10ms or less
		ON→OFF	10ms or less
Leakage current (OFF state)	0.1mA maximum (200V AC, 60Hz)		
Output protection	Built-in fuse	None	
	Surge suppression circuit	Varister	
Maximum operating frequency	3600 times/hour		
Connections	External connection	Detachable terminal block M3.5 screw (18 poles)	
	Applicable wire size (tightening torque)	0.75mm ² or less (0.8 to 0.9 N·m [8 to 9 kgf·cm]) Common terminal: 1.25mm ² or less	
Output signal display	When output circuit is on, LED lights point by point, logic side (displayed on the processor main unit)		
Isolation	Relay		
Dielectric strength	1500V AC, 1 minute, between output terminals and ground		
Insulation resistance	10MΩ or more between output terminals and ground (at 500V DC megger)		
Derating conditions	None		
Relay exciting current	70mA (at 24V DC), supplied from the processor power supply terminal		
Current consumption	5V DC, 70mA or less (when all points are turned on)		
Number of words occupied	1 word		
Mass	Approx. 130g		



3.4 I/O Card Specifications

(7) Digital output (NV1Y16R-08)


Item		Specifications	
Type		NV1Y16R-08	
Number of output points (common configuration)		16 points (8 points/common, 2 circuits)	
Output power	Rated voltage (allowable voltage range)	264V DC or less, 140V DC or less	
Output circuit characteristics	Output form and output type	Relay	
	Maximum load current	2A/point, 8A/common (30V DC/264V AC), 0.2A/point, 1.6A/common (110V DC)	
	Min. operating voltage and current	5V DC, 1mA	
	Response time	OFF→ON	10ms or less
		ON→OFF	10ms or less
Leakage current (OFF state)	0.1mA maximum (200V AC, 60Hz)		
Output protection	Built-in fuse	None	
	Surge suppression circuit	Varister	
Maximum operating frequency		3600 times/hour	
Connections	External connection	Detachable terminal block M3.5 screw (18 poles)	
	Applicable wire size (tightening torque)	0.75mm ² or less (0.8 to 0.9 N·m [8 to 9 kgf·cm]) Common terminal: 1.25mm ² or less	
Output signal display		When output circuit is on, LED lights point by point, logic side (displayed on the processor main unit)	
Insulation		Relay	
Dielectric strength		1500V AC, 1 minute, between output terminals and ground	
Insulation resistance		10MΩ or more between output terminals and ground (at 500V DC megger)	
Derating conditions		Simultaneous ON percentage: 50% maximum (26.4V DC/ 55°C)	
Relay exciting current		140mA (at 24V DC), supplied from the processor power supply terminal	
Current consumption		5V DC, 105mA or less (when all points are turned on)	
Number of words occupied		1 word	
Mass		Approx. 160g	



3.4 I/O Card Specifications

(8) Digital output (NV1Y16T05P5)


Item	Specifications		
Type	NV1Y16T05P5		
Number of output points (common configuration)	16 points (16 points/common, 1 circuit)		
Output power	Rated voltage (allowable voltage range)	12 to 24V DC or less (10.2 to 26.4V DC)	
Output circuit characteristics	Output form and output type	Sink-type transistor	
	Maximum load current	0.5A/point	
	Output voltage drop	1.2V or less (0.5A load)	
	Response time	OFF→ON	1ms or less
		ON→OFF	1ms or less
	Leakage current (OFF state)	0.1mA maximum	
Allowable surge current	2A, 10ms		
Output protection	Built-in fuse	None	
	Surge suppressor	Fly-wheel diode	
Connections	External connection	Detachable terminal block M3.5 screw (18 poles)	
	Applicable wire size (tightening torque)	0.75mm ² or less (0.8 to 0.9 N·m [8 to 9 kgf·cm]) Common terminal: 1.25mm ² or less	
Output signal display	When output circuit is on, LED lights point by point, logic side (displayed on the processor main unit)		
Isolation	Photocoupler		
Dielectric strength	1500V AC, 1 minute, between output terminals and ground		
Insulation resistance	10MΩ or more between output terminals and ground (at 500V DC megger)		
Derating conditions	Simultaneous ON percentage: 62% maximum (26.4V DC/55°C)		
External power supply	12 to 24V DC, 20mA (for transistor driving)		
Current consumption	5V DC, 50mA or less (when all points are turned on)		
Number of words occupied	1 word		
Mass	Approx. 110g		



3.4 I/O Card Specifications


(9) Digital output (NV1Y32T05P1)

Item	Specifications		
Type	NV1Y32T05P1		
Number of output points (common configuration)	32 points (32 points/common, 1 circuit)		
Output power	Rated voltage (allowable voltage range)	5 to 24V DC (4.5 to 26.4V DC)	
Output circuit characteristics	Output form and output type	Sink-type transistor	
	Maximum load current	16mA/point (4.5V DC), 0.1A/point (26.4V DC)	
	Output voltage drop	1.0V or less (16mA load), 1.2V or less (0.1A load)	
	Response time	OFF→ON	1ms or less
		ON→OFF	1ms or less
	Leakage current (OFF state)	0.1mA maximum	
Allowable surge current	0.3A, 10ms		
Output protection	Built-in fuse	None	
	Surge suppressor	Zener diode	
Connections	External connection	40 pin connector (FCN-361J040-AU)	
	Applicable wire size	AWG#23 (0.25mm ²) or less	
Output signal display	When output circuit is on, LED lights point by point, logic side (displayed on the processor main unit)		
Isolation	Photocoupler		
Dielectric strength	1500V AC, 1 minute, between output terminals and ground		
Insulation resistance	10MΩ or more between output terminals and ground (at 500V DC megger)		
Derating conditions	Simultaneous ON percentage: 62% maximum (26.4V DC/55°C)		
External power supply	5 to 24V DC, 40mA (for transistor driving)		
Current consumption	5V DC, 70mA or less (when all points are on)		
Number of words occupied	2 words		
Mass	Approx. 90g		




ONE-POINT ADVICE

Tips for Connecting 32 Point I/O Card to External Equipment




The following introduces how to connect the 32-point I/O card to external equipment.

- The standard connection between the 32-point I/O card to external equipment is made with the supplied 40-pin connector (FCN-365P040-AU from Fujitsu).




- When connecting cables from external I/O equipment through screw terminals, use of the FUJI relaying connector terminal (AU-CW series) is recommended.



3.5 Specifications of Function Cards

(1) General-purpose interface card (NV1L-RS2: RS-232C interface)

Item	Specifications		
Type	NV1L-RS2		
External interface	Port	RS-232C (1 channel)	
	Transmission mode	Half-duplex/full-duplex (depends on operating mode)	
	Synchronization mode	Start-stop synchronization	
	Transmission speed	300/600/1200/2400/4800/9600/19200 baud	
	Transmission distance	15m or less	
	Number of connectable units	1:1 (1 external device)	
	Connector	D-SUB 25 pin, mounting screw M2.6	
Transmission specifications	Transmission procedure	Start-stop synchronization (non-protocol) / command setting start-stop synchronization (non-protocol)	
	Transmission control code	JIS 7/8 units, EBCDIC 8 units	
	Transmission code system	Binary data (arbitrary)	
	Error control	Hardware	Vertical parity, flaming, overrun
		Software	Horizontal parity
	Extended transmission function	Selection of transparent mode by code conversion	
	Bit transmission order	From the lowest bit upward	
	Message length	Fixed or variable length: 220 bytes maximum (depends on operating mode)	
	Starting code	None, STX, :, or ::	
	Ending code	ETX, CR, LF, CR·LF, or DLE·ETX	
Character configuration	Start bit: 1 bit, Data bit: 7 or 8 bits, Parity bit: none/odd/even Stop bit: 1/1, 5/2 bits		
Occupied I/O configuration	16 points (1 word), area WB is occupied		
Number of slots occupied	1 slot		
LED display	Operating status display	RUN: Normal operation (data transmission possible) (green) SND: Transmitting data to external device (green) RCV: Receiving data from external device (green) DVE: Module failure (hardware failure) (red)	
Internal current consumption	Approx. 300mA		
Mass	Approx. 150g		



3.5 Specifications of Function Cards

① Status indicator LEDs

Indicates operating status of the NV1L-RS2.

Symbol	Color	Meaning	Description
RUN	Green	Normal operation	Lights when data transmission is possible.
SND	Green	Transmitting	Lights when the RS2 is transmitting data to external equipment.
RCV	Green	Receiving	Lights when the RS2 is receiving data from external equipment.
DVE	Red	Module failure	Lights if a hardware failure occurs (such as RAM failure of the RS2).

② Operating mode setting switch (MODE)

Used to set the transmission mode.



No. 1: Command setting (start-stop synchronization, non-protocol)

No. 4: Start-stop synchronization, non-protocol


Notes:

1. Avoid make setting for other than Nos. 1 and 4.
2. Switch setting is recognized when the power is turned on.

③ RS-232C connector

D-sub 25 pin female connector.

④ Character configuration setting switch




* Each switch setting is recognized when the power is turned on.

Note: Change the switch setting only when the power is turned off. An attempt to remove the card and change the switch setting when the power is on will result in a system error.

3.5 Specifications of Function Cards

• Pin layout and signal name

(Viewed from the front)



Pin No.	Signal name	Signal direction NV1L-RS2 ↔ External equipment	Description
1	FG		Protective ground
2	SD	→	Send data
3	RD	←	Receive data
4	RS	→	Request to send
5	CS	←	Clear to send
6	DR	→	Dataset ready
7	SG		Signal ground
8	CD	←	Data channel reception carrier detect
20	ER	→	Data terminal ready


- Notes:
1. For the NV1L-RS2, a female connector is used. For the cable, a male connector is used.
 2. The RS-232C interface of the NV1L-RS2 uses DTE specifications.
 3. Pins No. 9 to 19 and 21 to 25 are not used.

3.5 Specifications of Function Cards

(2) High-speed counter card (NV1F-HC1)

Item	Specifications	
Type	NV1F-HC1	
Count input signal	Phase	Two-phase signal (90° phase difference), single-phase + directional signal, single-phase addition (subtraction) signal (switched by software)
	Level	Square wave. 0/5V, 0/12V or 0/24V (voltage signal)
Counter	Type	Up-down counter (preset possible)
	Number of channels	1
	Counting speed	50kbps (external preset signal: 5kHz)
	Countable range	Signed BCD 4/8-digit (-79999999 to 79999999), signed binary 16/32-bit (80000000 to 7FFFFFFF)
	Multiplication	x1, x2, x4 (two-phase signal only)
	Reset (preset) input	By external input signal and software command
Comparison	Number of points	1
	Comparison range	Same as countable range
	Comparison target	<, >, =
	Comparison output	Transistor output (sink type), 12/24V DC, 0.2A, isolated by photocoupler
Special function	Sectional count function	Sectional count by time interval (function to clear the counter automatically after latching it in a resistor using an external signal)
Isolation	Photocoupler	
Current consumption	5V DC, 150mA	
Number of words occupied	Direct access area (from W24 on): 16 words	
Mass	Approx. 140g	

Structure



(Pin layout of external signal connector)


	B	A
20	Phase A (+24V input)	Phase A (+24V input)
19	Phase A (+12V input)	Phase A (+12V input)
18	Phase A (+5V input)	Phase A (+5V input)
17	Phase A (0V input)	Phase A (0V input)
16		
15	Phase B (+24V input)	Phase B (+24V input)
14	Phase B (+12V input)	Phase B (+12V input)
13	Phase B (+5V input)	Phase B (+5V input)
12	Phase B (0V input)	Phase B (0V input)
11		
10	Phase C (+24V input)	Phase C (+24V input)
9	Phase C (+12V input)	Phase C (+12V input)
8	Phase C (+5V input)	Phase C (+5V input)
7	Phase C (0V input)	Phase C (0V input)
6		
5	current value > reference value	current value > reference value
4	current value = reference value	current value = reference value
3	current value < reference value	current value < reference value
2	12/24V DC	12/24V DC
1	0V DC	0V DC

3.5 Specifications of Function Cards

• Function of the interrupt program number setting switch

When using an interrupt program, this switch is used to set the program number of the interrupt program to be activated within an MICREX-F F55 application


program. Only one program number can be set. When no interrupt program is used, set all positions to OFF.



Position	Interrupt program number
1	7 (PROG67)
2	6 (PROG66)
3	5 (PROG65)
4	4 (PROG64)
5	3 (PROG63)
6	2 (PROG62)
7	1 (PROG61)
8	0 (PROG60)

• Function of the operating mode setting switch

This switch is used to set the operating mode of the NV1F-HC1. Each position setting is shown in the table below.



Position	Function	Selection mode	
		OFF	ON
1	Sectional count mode selection	Sectional count mode	Ordinary count mode
2	External output exclusive use selection	Outputs > and < output during matching (=) output	Does not output > and < output during matching (=) output
3	Count range selection	32 bit length	16 bit length
4	Matching output clear timing selection	When comparison result is mismatched	By application (when bit No. 3 of the command resistor rises)


* Cannot be mounted on expansion units for basic unit case version 1001 or later.

3.5 Specifications of Function Cards


(3) High-speed counter card (NV1F-HC2)

Item		Specifications
Type		NV1F-HC2
Count input signal	Phase	Two-phase signal (90° phase difference), single-phase + directional signal, single-phase addition (subtraction) signal (switched by software)
	Level	Square wave 0/5V, 0/12V or 0/24V (voltage signal)
Counter	Type	Up-down counter (preset possible)
	Number of channels	1
	Counting speed	50kHz maximum (reset signal: 5kHz)
	Countable range	Signed BCD 4-digit (-7999 to 7999), signed binary 16-bit (8000H to 7FFFH)
	Multiply	x1, x2, x4 (two-phase signal only)
	Reset (preset) input	By external input signal
Comparison	Number of points	1
	Comparison range	Same as countable range
	Comparison target	<, >, =
	Comparison output	Transistor output (sink type), 12/24V DC, 0.2 A, isolated by photocoupler
Special function	Sectional count function	Sectional count by time interval (function to clear the counter automatically after latching it in a resistor using an external signal)
Isolation		Photocoupler
Current consumption		5V DC, 110 mA
Number of words occupied		4 words
Mass		Approx. 140 g

Structure




(Viewed from the front side)



(Pin layout of external signal connector)

	B	A
20	Phase A (+24V input)	Phase A (+24V input)
19	Phase A (+12V input)	Phase A (+12V input)
18	Phase A (+5V input)	Phase A (+5V input)
17	Phase A (0V input)	Phase A (0V input)
16		
15	Phase B (+24V input)	Phase B (+24V input)
14	Phase B (+12V input)	Phase B (+12V input)
13	Phase B (+5V input)	Phase B (+5V input)
12	Phase B (0V input)	Phase B (0V input)
11		
10	Phase C (+24V input)	Phase C (+24V input)
9	Phase C (+12V input)	Phase C (+12V input)
8	Phase C (+5V input)	Phase C (+5V input)
7	Phase C (0V input)	Phase C (0V input)
6		
5	current value > reference value	current value > reference value
4	current value = reference value	current value = reference value
3	current value < reference value	current value < reference value
2	12/24V DC	12/24V DC
1	0V DC	0V DC




3.5 Specifications of Function Cards

• Function of the input pulse mode setting switch

This switch is used to set the input pulse type, multiply, and reset condition.

- Count mode setting (SW8)
Specifies binary or BCD.
ON : BCD
OFF: Binary



- Input pulse type setting (SW7, 6)
Specifies the input pulse type.

SW7	SW6	Pulse type
OFF	OFF	Single-phase addition
OFF	ON	Single-phase subtraction
ON	OFF	Single-phase directional command (Phase B OFF: addition ON: subtraction)
ON	ON	Two-phase

- Multiplication setting (SW5, 4)
Specifies the multiplication of the input pulse.

SW5	SW4	Multiplication
OFF	—	1
ON	OFF	2
ON	ON	4 (effective only when two-phases)


- External reset input condition setting (SW3)
Specifies the reset condition.
ON : Falling edge of phase C
OFF: Rising edge of phase C

- External reset (SW2, 1)
Specifies the reset timing with respect to issuance of the external reset condition.

SW2	SW1	Reset timing
OFF	OFF	UP count
OFF	ON	DOWN count
ON	OFF	UP/DOWN count
ON	ON	Upon issuance (asynchronous)

• Function of the count external output mode setting switch

This switch is used to set the count mode and comparison external output mode.




Position	Function	Selection mode	
		OFF	ON
1	Sectional count mode selection	Sectional count mode	Ordinary count mode
2	External output exclusive use selection	Outputs > and < output during matching (=) output	Does not output > and < output during matching (=) output
3	Not used	—	—
4	Not used	—	—

3.5 Specifications of Function Cards

• Register configuration of the NV1F-HC1 and NV1F-HC2

1) NV1F-HC1

Starting address
W24.***




Using position 3 of the operating mode switch, 16/32 bit mode switching is possible for the count registers of the NV1F-HC1. In 32 bit mode, 2 words (higher-order and lower-order registers) are used; in 16 bit mode, only 1 word (higher-order register) is used.

- Notes:
1. The configuration data is used by the F55 processor and cannot be accessed by the user.
 2. When the write only area is used by the source operand of an instruction in a user program, write data cannot be read out or monitored normally during monitoring with the program loader or I/O status indicator.

2) NV1F-HC2


Starting address



3.5 Specifications of Function Cards


• **Connection example**

- ① Single-phase pulse (addition) and single-phase pulse (subtraction)..... When single-phase encoder is used (example with 12 V signal level)



- When an external reset signal is used, make the connections drawn with dotted lines.
Phase C SW 1 (rising)
Phase C SW 2 (falling)
Reset at rising or falling edge, depending on the input mode setting for phase C.

- ② Single-phase pulse + directional command signal..... When single-phase encoder and external signal for directional signal are used together (example with 12 V signal level)




- Directional signal — OFF: Subtraction ON: Addition
- When an external reset signal is used, make the connections drawn with dotted lines.
Phase B SW1: Subtraction
Phase B SW2: Addition

Phase C SW 1 (rising)
Phase C SW 2 (falling)
Reset at rising or falling edge, depending on the input mode setting for phase C.


3.5 Specifications of Function Cards

③ Two-phase pulse When two-phase encoder is used (example with 12 V signal level)



- When an external reset signal is used, make the connections drawn with dotted lines.
 Phase C SW 1 (rising)
 Phase C SW 2 (falling)
 Reset at rising or falling edge, depending on the input mode setting for phase C.

④ Connection of comparison external output



3.5 Specifications of Function Cards

(4) T-link master card (NV1L-TL1)

① Overview


This card, mounted on the basic unit, makes it possible to use various T-link equipment. With this card, one T-link system can be configured. (It can be mounted on the main unit only; it cannot

be mounted on expansion units.) Basic unit case version 1001 or later is provided with a calendar function. (For details, see User's Manual <Instructions> FEH160.)

② Specifications

Item	Specifications
Type	NV1L-TL1
Transmission mode	Half duplex, serial transmission
Data exchange mode	1:N (polling/selecting)
Transmission speed	500kbps
Connections	Up to 35 units Master processor x 1 Capsule or slave module/unit x 32 Program loader x 2
	} 35 units maximum
Transmission line	Multi-drop
Current consumption	5V DC, 60mA or less
Mass	Approx. 90g

③ Structure



3.5 Specifications of Function Cards

(5) T-link slave card (NV1L-TS1)

① Overview

The NV1L-TS1 is a communication card that is mounted on the basic unit and expansion units of the MICREX-F F55 series. It is connected to another processor (with the T-link master function) via the T-link for data transmission. The card is provided with three transmission modes: I/O transmission

which uses I/O area (area B), message communication by means of message module registration (system defined), and message communication using message communication instructions (MSGT, MSGR).

② Specifications


Item	Specifications
Type	NV1L-TS1
Number of T-link I/O points *1	I/O: 1/1, 2/2, 4/4, or 7/8 word mode can be selected by the mode setting switch *2
Message communication function	Message communication (up to 110 words) by message module registration Data exchange (up to 108 words) by message communication instructions (MSGT and MSGR) (Whether this function is used or not is selected by the mode setting switch.)
Status indicators	RUN (green) ALM (red)
T-link connection	By the T-link connector
Current consumption	5V DC, 350mA
Number of words occupied *1	Selected by the mode setting switch (1/1=2 words, 2/2=4 words, 4/4=8 words, 7/8=16 words) *3
Number of slots occupied	1 I/O slot
Mass	Approx. 150g

Notes: *1. Depends on the switch setting on the card.

*2. When 7/8 words are selected as the number of T-link I/O points, data exchange by message communication is not allowed. Set the mode selection switch so that message communication is not performed.

*3. When 7/8 words are selected as the number of T-link I/O points, TS1 occupies 16 words in the I/O area (area B).

③ Structure



3.5 Specifications of Function Cards


- ④ Configuration and example operation
 The address of the T-link slave card connected to the slave processor is assigned in the same manner as general I/O modules/cards.

Example)

Connect the one end of the T-link cable to the master processor and the other end to the slave processor. Then make setting as follows:

- 1) Set the station number of the slave processor viewed from the master processor to "20".

- 2) Install the slave module in slot No. 3 on the slave processor.
- 3) Set the mode setting switch so that message communication is not performed, and set the number of T-link I/O points to 2/2 words.




- When the address setting knob is set to "20", assignment of the T-link I/O areas of the slave and master processors is as follows:


Address viewed from the slave processor	Address viewed from the master processor
WB003 (Input)	WB022 (Output)
WB004 (Input)	WB023 (Output)
WB005 (Output)	WB020 (Input)
WB006 (Output)	WB021 (Input)

To connect the B0 switch of the master processor and turn on the lamp connected to B20 of the slave processor using this switch, the program is as follows:

Master processor program



Slave processor program



3.6 I/O Capsule (Unit) Specifications

3.6.1 I/O terminal

(1) Overview

This unit is a secondary remote I/O station of the independent type that can be connected to the MICREX-F. The number of I/O points is 16 or 32. It can

be mounted easily on the operation panel or terminal box by means of a rail and screws, and used like a terminal block.

(2) Specifications

① General specifications

Item		Specifications
Physical conditions	Operating temperature	0 to +55°C
	Relative humidity	20 to 90%RH (without condensation)
	Storage temperature/humidity	-20 to 70°C/20 to 90%RH (without condensation)
	Dust	No conductive dust present
	Corrosive gas	No corrosive gas present
Mechanical conditions	Resistance to vibration	JIS C 0911, crossover frequency 57Hz, Screw mounting: 19.6m/s ² (2G), when relay output is provided: 9.8m/s ² (1G)* Rail mounting : 9.8m/s ² (1G), including the case when relay output is provided For 2 hours in 3 axis directions *
	Resistance to shock	JIS C 0912, test method 1-No. 3, 2 times in 3 axis directions
		Malfunction shock: 147m/s ² (15G) * Endurance shock: 294m/s ² (30G) *
Electrical conditions	Noise immunity	1500Vp-p by noise simulator, rising time 1ns, pulse width 1μs
	Dielectric strength	1500V AC, 1 minute, between external terminals and ground
	Insulation resistance	10MΩ or more between external terminals and ground (at 500V DC megger)
Installation conditions	Grounding	Ground resistance of 100Ω or less
	Structure	Installed in the panel
	Cooling system	Self cooling
	Mounting method	JIS/IEC standard, by means of 35mm width rail or M4 screws

* When the unit is mounted by means of a rail, be careful not to apply vibration or shock.

② Unit specifications

Item		Specifications			
Unit type		FTT1604-G02	FTT3204-G02	FTT16R0-G02	FTT32R0-G02
Supply voltage		24VDC±20%		24VDC±15%	
Power consumption		5W or less	8W or less	8W or less	10W or less
Inrush current		30A maximum, 10ms or less			
Allowable time of instantaneous power failure		3ms or more (from 24V to 0V)			
Number of I/O points	Input	16 points	32 points	—	—
	Output	—	—	16 points	32 points
Number of words occupied		1 word	2 words	1 word *1	2 words *1
Mass		Approx. 330g	Approx. 460g	Approx. 390g	Approx. 590g

Item		Specifications			
Unit type		FTT16T0-G02	FTT32T0-G02	FTT16T4-G02	FTT32T4-G02
Supply voltage		24VDC±20%			
Power consumption		5W or less	8W or less	5W or less	8W or less
Rush current		30A maximum, 10ms or less			
Allowable time of instantaneous power failure		3ms or more (from 24V to 0V)			
Number of I/O points	Input	—	—	8 points	16 points
	Output	16 points	32 points	8 points	16 points
Number of words occupied		1 word	2 words	1 word *1	2 words *1
Mass		Approx. 330g	Approx. 480g	Approx. 320g	Approx. 460g

*1 See the next page (3-43).

3.6 I/O Capsule (Unit) Specifications

③ Input/output section specifications


Item	Specifications			
Type	FTT1604	FTT3204	FTT16T4	FTT32T4
Number of points, number of common points	8 point common x 2 circuits	8 point common x 4 circuits	8 point common x 1 circuit	8 point common x 2 circuits
Polarity	Source input			
Rated input voltage	24V DC			
Rated input current	7mA or less/point (24V)			
Operating voltage range	0 to 26.4V DC (single-phase full-wave rectification not available)			
Number of points that can be ON at the same time	See the next page.			
Input operating voltage	ON level	15 to 26.4V		
	OFF level	0 to 5V		
Internal impedance	3.3kΩ			
Input filtering time	ON→OFF	10ms or less		
	OFF→ON	10ms or less		
Number of words occupied	1 word	2 words	1/2 words **	1 word **
Isolation	Photocoupler			
Operating indication	LED (green): Lights when ON.			
External connections	Detachable terminal block			

④ Output section specifications


Item	Specifications					
Type	FTT16T0	FTT32T0	FTT16T4	FTT32T4	FTT16R0	FTT32R0
Output	Transistor (sink type)				Relay	
Number of points, number of common points	8 point common x 2 circuits	8 point common x 4 circuits	8 point common x 1 circuit	8 point common x 2 circuits	8 point common x 2 circuits	8 point common x 4 circuits
Rated voltage (allowable voltage range)	5/12/24V DC (4.75 to 30 V)				264V AC max. 30V DC	
Maximum load current	0.2 A/point, 0.8 A/8 points				2 A/point, 8 A/8 points	
Minimum load current	—				2 mA (5V DC)	
Number of points that can be ON at the same time	—				See the next page.	
Allowable surge current	1 A, 10 ms				—	
Leakage current (OFF state)	1 mA or less (24 V)				—	
Voltage drop when ON	1.5 V or less (0.2 A load)				—	
Response time	OFF→ON	1 ms or less			10 ms or less	
	ON→OFF	1 ms or less			10 ms or less	
Surge suppressor	Zener diode clamp				—	
Operating indication	LED (green): Lights when ON.					
Number of words occupied	1 word	2 words	1/2 words**	1 word**	1 word	2 words
Isolation	Photocoupler				Photocoupler + Relay	
External connections	Detachable terminal block					
Remark	When an inductive load is connected to transistor output, be sure to connect a fly-wheel diode in parallel with the load.					

*1 I/O memory assignment

1) 16 point I/O hybrid unit (FTT16T4) ⇔ Bit address




2) 32 point I/O hybrid unit (FTT32T4) ⇔ Bit address




3.6 I/O Capsule (Unit) Specifications

⑤ I/O section derating


1) Input section (types: FTT1604/FTT3204/FTT32T4)



2) Output section (type: FTT16R0)






3) Output section (type: FTT32R0)



(3) External wiring diagrams

① Internal circuit configuration



3.6 I/O Capsule (Unit) Specifications


② External wiring diagrams for each type

1) FTT1604-G02


- The size of terminal screws is M3.5. Tighten them with the specified tightening torque (0.8 to 1.0 Nm [8 to 10 kgf-cm]).
- When the unit is used as a T-link termination, short-circuit terminals T1 and T1R indicated by

(*) with a lead. When they are short-circuited, a termination resistor is connected.


- Use the T-link cables recommended by Fuji Electric. (See subsection 1.4.2.)




2) FTT3204-G02



3) FTT16T0-G02




4) FTT32T0-G02




3.6 I/O Capsule (Unit) Specifications


5) FTT16R0-G02




6) FTT32R0-G02



7) FTT16T4-G02




8) FTT32T4-G02



3.6 I/O Capsule (Unit) Specifications


(4) External view and structure




- ① Mounting hole: Mount the unit with an M4 screw.
- ② Status indicator LED: Indicates the operating conditions of the I/O terminal.

Name	Status	Color	
POW	Normal operation	ON: Normal power supply operation	Green
ALM	Communication error	ON : Transmission error OFF: Normal	Red

- ③ Input or output indicator LEDs
Lights when corresponding I/O is on.
- ④ Station No. setting switch
Used to set the station No. to the starting address of area WB (I/O relay) to be assigned. The example below shows "WB71".
- ⑤ JIS/IEC rail mounting hook
When demounting the I/O terminal, move this hook downward with a screw driver.
- ⑥ Detachable terminal block
Open the cover to complete the wiring.



(5) Dimensions, mm



The number in () is the value for 16 point types (FTT16□□-G02).

3.6 I/O Capsule (Unit) Specifications

① Mounting and demounting

The unit can be mounted either with rail or screws.

- When using screws

Mount the unit securely by tightening two M4 screws at mounting holes on a diagonal line.

Tightening torque: 1 to 1.5 Nm [10 to 15 gkf cm]

- When using rail

When a 35 mm width guide rail conforming to the


JIS/IEC standard is used, the unit can be mounted and demounted easily. In this case use special fittings for the rail to mount the unit securely.

Fuji Electric offers the following types:

Mounting rail: TH35-15AL, 7.5, 7.5AL


End clamp kit: TS-XT

Mounting



Hook the unit to the rail as shown, and then push the unit in the direction indicated by the arrow.


Demounting




Insert a screwdriver into the sliding section of the unit, and then move it in the direction indicated by the arrow.

② Mounting direction

Front view



Side view



3.7 T-link Specifications

The MICREX-F series is provided with an I/O level serial transmission system that allows the processor to be connected to decentralized I/O modules/capsules (remote I/Os) and specialized capsules. This system, called the T-link system, achieves high-speed data transmission at low cost.

When the T-link master interface is mounted on the F55 series, a T-link system can be configured. In addition, by using a single processor and decentralized T-link slave modules/units, data transmission at I/O level is possible between multiple processors.


(1) T-link specifications

Item	Specification	
Transmission mode	Half duplex, serial transmission	
Data exchange mode	1:N (polling/selecting)	
Transmission speed	500k bits/second	
Effective transmission speed	7k bytes/second (digital 512 points/10ms)	
Modulation mode	Pulse duration modulation (PDM)	
Number of connectable units (capsules)	Program loader: Up to 2 units for each processor T-link capsule: Up to 32 units	
Number of I/O points	Digital I/O: Up to 1600 points (for each T-link system)	
Transmission line	Bus configuration (multi-drop) Optical loop connection using an optical converter (FNC100C) between busses	
Duplication of transmission line	Duplication of optical transmission line using an optical converter is possible.	
Cable	Electrical transmission line	Twisted pair cable (Furukawa Electric): KPEV-SB 0.75mm ² x 1 pair 700m max. Twisted pair cable (Furukawa Electric): KPEV-SB 0.5mm ² x 1 pair 700m max.
	Optical transmission line	Simulated step index type (SI), crystal fiber (dedicated cable), distance between optical converters 1000m max. Grated index type (GI), crystal fiber (dedicated cable), distance between optical converters 3000m max.
Termination processing	A supplied 100Ω termination resistor is connected at each end of electrical transmission lines.	
Diagnostic functions	Error check	FCS (CRC-CCITT: $X^{16}+X^{12}+X^5+1$) Data word check Collision detection
	Status mode	Statuses of T-link capsules and loaders connected to the T-link are collected by the processor and can be used as status flags. The operating mode of each T-link capsule is delivered by the processor to each station. T-link RAS function

Note: For electrical transmission lines, the total line length depends on the cable type used. For cable types, see subsection (3), "T-link cables". For details on T-link operation, see User Manual <Communication> (FEH161).

Glossary

- Multi-drop A network in which multiple stations are connected to a single line
- Polling/selecting A communication control method
The processor inquires of other stations in sequence as to presence or absence of a send request (this operation is referred to as polling). Stations having no send request reply with "send request absent" in response to polling; those having a send request reply with "send request present", and then start data transmission.
When the processor wants to send data to other stations, it specifies the target station (this operation is referred to as selecting), and then starts data transmission.



- FCS: Abbreviation of "frame check sequence", which is one method of data checking.


3.7 T-link Specifications

(2) T-link equipment connection

There are no particular restrictions on T-link equipment that can be connected to the F55 basic unit.

- FTL010A, FTL010H (set to MODE1), FTL010H (set to

MODE2), and T-link interface module (NC1ET) for the MICREX-F70 can be connected at the same time, as shown below.



- Mini T-link equipment cannot be connected directly. Use a T-link converter in this case.

3.7 T-link Specifications

(3) T-link cable (electrical transmission lines)

Use the specified T-link cables (twisted pair cable with shield) shown in the following table. If cables other

than the following are used, T-link operation is not guaranteed.

Maker	Cable type	Length	Remark
Furukawa Electric Co., Ltd.	KPEV-SB 1.25mm ² X 1	Max. 1km *1,*2	Twisted pair cable
	KPEV-SB 0.75mm ² x 1	Max. 700m *1	
	KPEV-SB 0.50mm ² x 1	Max. 700m *1	
Daiden Co., Ltd.	RMEV-SB 0.50mm ² x 1	Max. 290m *1	Robot cable
Taiyo Electric Wire & Cable Co., Ltd.	RVV-SB 0.50mm ² x 1	Max. 200m *1	
Hien Denko Co., Ltd.	TTYCYS-1 x 1	Max. 100m *1	Marine use
	250V-TTYCYS x 1	Max. 50m *1	
Sumitomo Electric Industries Ltd.	TWIN-100	Max. 250m *1	
	DPEV-SB 0.50mm ² x 1	Max. 700m *1	
Nihon Electric Wire & Cable Co., Ltd.	KPEV-SB 0.50mm ² x 1	Max. 700m *1	
	KNPEV-SB 0.50mm ² x 1	Max. 700m *1	
Furukura Electric Co., Ltd.	IPEV 0.50mm ² x 1	Max. 700m *1	

*1 The value of the maximum length has been checked by test. Note that the value may be less, depending on operating environment (noise conditions). If the cable is used close to this value, addition of a T-link repeater is recommended.

*2 700m maximum for basic unit versions 0001 to 0999

(4) Optical T-link cable (optical transmission lines)

Category	Type and specifications
Simulated step index type (dedicated cable)	FHC100A-F □ □ □ (indoor type) FHC120A-F □ □ □ (indoor and outdoor type) pulling terminal absent at one end FHC120B-F □ □ □ (indoor and outdoor type) pulling terminal present at one end SI type crystal fiber Core/clad diameter: 100μm/140μm Optical connector: Multi-mode FC type connector (equivalent to C341P100/140 from Furukawa) (For the cable types above, supplied as standard)
Grated index type (GI)	GI type crystal fiber (loss 3dB/km or less, bandwidth 200MHz-km or more) Core/clad diameter: 50μm/125μm Optical connector: Multi-mode FC type connector (equivalent to C411 from Furukawa)

Section 4 Name and Function of Each Part


	Page
4.1 Name and Function of Each Part	4-2
4.1.1 Structure of F55 series	4-2
4.1.2 Name and function of each part of the F55 series	4-4
4.1.3 Installing and uninstalling optional cards	4-15
4.1.4 Structure of the I/O card and I/O capsule	4-19
4.1.5 Name and function of each part of the I/O card and capsule	4-20
4.2 Dimensions	4-22
4.3 Simulated Input Switch	4-26
4.3.1 Simulated input switch for the input card	4-26
4.3.2 Simulated input switch for the input capsule	4-27

Section 4 Name and Function of Each Part


4.1 Name and Function of Each Part

4.1.1 Structure of F55 series

(1) Basic unit case versions 0001 to 0999 (basic unit)




(2) Basic unit case version 1001 or later (basic unit)




4.1 Name and Function of Each Part

(3) Basic unit case version 1001 or later (expansion unit)



(Rear panel)



4.1 Name and Function of Each Part


4.1.2 Name and function of each part of the F55 series

The F55 series is provided with 7, 6, or 2 status LED indicators, 2 sets of 8 x 4 LED indicators, 2x7-segment LED indicators, and 3 or 2 switches on the basic unit. Using these LED indicators and switches, the following indication is possible:


- ① I/O status display mode (for (1), (2), and (3) below)
- ② User status display mode (for (2) only)
- ③ Maintenance status display mode (for (2) only)

Mode switching is possible only for (2) below and is done by means of the MODE switch and the W124 control word in the user display area. There are two independent sets of 8 x 4 LED indicators, 7-segment LED indicators, and switches.


(1) Basic unit case versions 0001 to 0999 (basic unit)



(2) Basic unit case version 1001 or later (basic unit)



(3) Basic unit case version 1001 or later (expansion unit)



4.1 Name and Function of Each Part

- ① Processor status LED indicator (basic unit)
Indicates status of the processor with the following conditions:

LED	Color	Name	Description	Built-in contact status during LED indicating
				RUN
POW	Green	Power supply normal operation	Processor power supply circuit output is normal.	ON/OFF (according to RUN indication)
RUN	Green	During operation	User program being executed	ON
ALM1	Red	Fatal fault	Fatal fault occurred (special relay F0010 to F001F is on)	OFF
ALM2	Red	Nonfatal fault	Nonfatal fault occurred (special relay F0020 to F002F is on)	ON
BAT	Red	Battery error	Battery is not installed or battery voltage is too low (special relay F0020 is on)	ON
I/O	Green	I/O status indication	I/O status being indicated	ON

* With basic unit case version 1001 or later, the user and maintenance status LED indicators go out when the I/O status LED indicator is on.


- ① Expansion unit status LED indicator (expansion unit)
Indicates the status of the expansion unit with the following conditions:

LED	Color	Name	Description
POW	Green	Power supply normal operation	Expansion unit power supply circuit output is normal.
I/O	Green	I/O status indication	I/O status being indicated

4.1 Name and Function of Each Part

- ② I/O status LED indicator
Indicates I/O statuses on a unit basis, for 2 sets of 32 points.

* For sets 0 and 1, indication is made in the same manner but independently.
By default, set 0 indicates slot 0 status and set 1 indicates slot 1 status (when I/O card is inserted in slots 0 and 1).




Indicates ON/OFF status of I/O cards in units of 32 points.
Only 16 I/O points of data in the slot are indicated.
Lower 16 bits are off.

* Simultaneous scan mode: WB
Direct access mode: W24
Realizes the data monitoring function for each area.

- ③ Data position LED indicator
Indicates the currently displayed data position (slot position and data position in the slot). When the number of data items in the slot is 32 points (2 words) or less, only the slot position is indicated (for slots No. 0 to 7).

Example:
Displaying words 2 and 3 in slot No. 3
(When 3 or more words are occupied, the following display is made.)



- ④ Data position select switch PUSH recognition LED indicator
Lights or goes out each time the data position select switch is pressed. (There are two LED indicators corresponding to the two data position select switches.)

- ⑤ Data position select switch
By pressing this switch, the slot position and data position in the slot can be changed. (Two data position select switches are provided.)


4.1 Name and Function of Each Part

■ ③ Example display 1 for data position LED indicator
 In this example, the following configuration is assumed.

F55		16 point input	32 point output	T-link slave	16 point output
-----	--	----------------	-----------------	--------------	-----------------

The T-link slave occupies 2 words for input and 2 words for output.


When power is turned on, the data position LED indicator is as follows:



The data position LED indicator and data display switch on the CHNG0 side are to be used.

Number of times the data display switch is pressed and indication:

Data LED indicator at CHNG0



4.1 Name and Function of Each Part

■ ③ Example display 2 for data position LED indicator

	Slot No. 0	Slot No. 1	Slot No. 2	Slot No. 3	Slot No. 4	Slot No. 5	Slot No. 6	Slot No. 7
F55	I/O 16 points	I/O 64 points	I/O 32 points (2 slot type)		I/O 32 points	Interrupt	High function 4/4 words	Empty

Data status of display side 0

① I/O status LED indicator	③ Data position LED indicator (7-segment LED)				② I/O ON/OFF LED indicator	⑤ Data position select switch PUSH recognition LED indicator	④ Data position select switch
	Slot No. (0.8 sec.)	OFF (0.1 sec.)	In-slot word address (0.3 sec.)	OFF (0.4 sec.)			
ON	0	— No flicker	— No flicker	— No flicker	Upper 16 bits: Slot No. 0, word 0 data Lower 16 bits: All points are turned off	OFF	
	1	OFF	0	OFF	Upper 16 bits: Slot No. 1, word 0 data Lower 16 bits: Slot No. 1, word 1 data	ON	PUSH
	1	OFF	2	OFF	Upper 16 bits: Slot No. 1, word 2 data Lower 16 bits: Slot No. 1, word 3 data	OFF	PUSH
	2	— No flicker	— No flicker	— No flicker	Upper 16 bits: Slots No. 2 and 3, word 0 data Lower 16 bits: Slots No. 2 and 3, word 1 data	ON	PUSH
	4	— No flicker	— No flicker	— No flicker	Upper 16 bits: Slot No. 4, word 0 data Lower 16 bits: Slot No. 4, word 1 data	OFF	PUSH
	6	OFF	0	OFF	Upper 16 bits: Slot No. 6, word 0 data Lower 16 bits: Slot No. 6, word 1 data	ON	PUSH
	6	OFF	2	OFF	Upper 16 bits: Slot No. 6, word 2 data Lower 16 bits: Slot No. 6, word 3 data	OFF	PUSH
	6	OFF	4	OFF	Upper 16 bits: Slot No. 6, word 4 data Lower 16 bits: Slot No. 6, word 5 data	ON	PUSH
	6	OFF	6	OFF	Upper 16 bits: Slot No. 6, word 6 data Lower 16 bits: Slot No. 6, word 7 data	OFF	PUSH
	0	— No flicker	— No flicker	— No flicker	Upper 16 bits: Slot No. 0, word 0 data Lower 16 bits: All points are turned off	ON	PUSH
	1	OFF	0	OFF	Upper 16 bits: Slot No. 1, word 0 data Lower 16 bits: Slot No. 1, word 1 data	OFF	PUSH

* With data status of display side 1, starts from slot No. 1, word 0.

- For 2-slot type (32 points), further slot numbers are not displayed.
- For slots into which an interrupt card is installed, the slot number and I/O data are not displayed.
- For empty slots, the slot number and I/O data are not displayed.

4.1 Name and Function of Each Part

■ Operation of the I/O status LED indicator

The following describes the operation of the I/O status LED indicator.

- (1) When there are no faults, the LED indicator is operable. (When no I/O device is installed, it is inoperable.)
- (2) If a fatal fault (ALM1) occurs, it is inoperable.
- (3) If a nonfatal fault (ALM2) occurs, it is basically operable.


If the I/O status LED indicator ① is inoperable, the data position LED indicator (7-segment LED) ② is turned off when the I/O status LED indicator lights.

Detailed LED indicator conditions are shown in the table below.

			① I/O status LED indicator	② I/O ON/OFF status LED indicator	③ Data position LED indicator	④ Data position select switch	⑤ Data position select switch PUSH recognition LED indicator
No fault				Valid	Valid	Valid	Valid
Fault	Fatal fault	Power supply fault BUS error	ON	Invalid OFF	Invalid OFF	Invalid	Invalid OFF
		Memory error					
		User program error					
		Miscellaneous					
	Nonfatal fault	Direct I/O configuration fault					
Miscellaneous							

4.1 Name and Function of Each Part

- ⑥ **Battery**
Used to retain user programs and the contents of the built-in data memory if power supply fault occurs.
Type: NL8V-BT(FBL030A), life expectancy of 5 years (25°C), the guaranteed period is printed on the battery.
- ⑦ **EPROM memory card**
ROM memory used to store user programs when ROM operation is performed.
The NV1VMP-10 memory card is provided with EPROM (HN27C256AG-15) from Hitachi. For the NV1VME-10 memory card, which can only be used with basic unit case version 1001 or later, EEPROM is directly mounted. (It is not intended to be replaced by the user.)
- ⑧ **Program loader connector (for basic units only)**
Used to connect a program loader (referred to as D10S, D20, LITE, or personal computer loader).
- ⑨ **ROM card, battery compartment cover**
This compartment is opened when replacing a battery, mounting a EPROM/EEPROM memory card, or connecting a loader connector. The expansion unit does not store a battery or EPROM/EEPROM memory card and therefore should not be opened.
- ⑩ **Power supply terminal block**
This terminal block provides the power supply and ground terminals, and terminals connected to internal contacts used for indication of operating conditions.




* Normally, connect both LG and FG to the ground. (Reduces noise immunity.)
If ground connection causes malfunction, disconnect LG, FG, or both from the ground.

- ⑪ **Optional card slot**
Used to install the T-link master card (NV1L-TL1). However, for the expansion unit this slot is not used. Do not remove the blank cover of the expansion unit.
- ⑫ **I/O and function card slots**
Used to install I/O cards and function cards (for 4, 6, and 8 cards).
- ⑬ **Version No. seal**
Indicates the version number of hardware and software.
- ⑭ **Mounting projection**
Used to securely mount the card to the basic unit.
- ⑮ **Rail mount**
Used to mount the basic unit to IEC, JIS 35mm width rail.
- ⑯ **Rail mounting locks**
Used to lock the basic unit to the rail.
- ⑰ **Mounting hole**
Used to mount the basic unit to the control panel.
Use 4-M5X20 screws.

4.1 Name and Function of Each Part

⑱ User information LED indicators (basic unit version 1001 or later)

The 8 x 8 LED indicators and two 7-segment LED indicators are used to display the user information set in the user display area (W124).



Information can be set only for the numbered LED indicators shown at left.


● Mode status LED indicator
This LED indicator lights in the user status display mode. (In this case the I/O and maintenance LED indicators go out.)

Module No.: W124 (Attribute: SI, Initial value: all 0)

Module No.	Control word															
W124.0																
W124.1	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
W124.2	10	11	12	13	14	15	16	17	18	19	1A	1B	1C	1D	1E	1F
W124.3	20	21	22	23	24	25	26	27	28	29	2A	2B	2C	2D	2E	2F
W124.4	30	31	32	33	34	35	36	37	38	39	3A	3B	3C	3D	3E	3F
W124.5	40	41	42	43	44	45	46	47	48	49	4A	4B	4C	4D	4E	4F

1: Indicator lights.
0: Indicator goes out.
Can be set from the user program on a bit basis.

* Control word



Indication by the user program

- Each of bits No. 0 through 4F in user information display area W124.1 to W124.5 can be set by the user program.


- When bit No. F in user information display area W124.0 is set to "1", the LED indicator corresponding to each bit lights.

4.1 Name and Function of Each Part

① Maintenance status LED indicators (basic unit version 1001 or later)

Indicate detailed fault factor on the current fatal or nonfatal faults.

• Function of each section



● Mode status LED indicator
This LED indicator lights in the maintenance status display mode. (In this case the user LED goes out.)

● Fault factor LED indicator
Displays the cause of the fault with a 2-digit code.

● Detailed fault factor 7-segment LED indicator
When the fault indicated by the fault code LED indicator has a detailed fault factor, this indicator displays it with a 2-digit code.

● Fault factor select switch
When there is more than one fault factor, this switch makes it possible to display the corresponding codes in sequence. (Codes are displayed in ascending order.)

● Detailed fault factor select switch
When the fault indicated by the fault code LED indicator has more than one detailed fault factor, this switch makes it possible to display the codes in sequence. (Codes are displayed in ascending order.)

● Switch operation recognition LED indicator
Indicates that switch operation has been recognized by the processor. (The indicator lights or goes out [toggles its condition] each time switch operation is recognized.)

4.1 Name and Function of Each Part

• Fault factors

The following shows the codes displayed by the fault factor LED indicator and the meaning of each code.

Indication of fatal fault factors

(Contents of special relay WF001)

10: Memory error	
11: Not used	
12: Auxiliary power supply error	
13: Power supply fault	
14: T-link fault	○
15: Option fault	
16: Not used	
17: Not used	
18: User program error	
19: WDT error	
1A: BUS error	○
1B: Not used	
1C: I/O area duplication	○
1D: Too many capsules on T-link	
1E: I/O area over	
1F: Plant fault	○

Indication of nonfatal fault factors

(Contents of special relay WF002)

20: Battery error	
21: Not used	
22: Option fault	
23: Not used	
24: Not used	
25: Not used	
26: T-link configuration fault	○
27: Not used	
28: Not used	
29: Direct I/O configuration fault	○
2A: Not used	
2B: Not used	
2C: Not used	
2D: Not used	
2E: Program error	
2F: Plant fault	○

* Failure factors marked with ○ have a detailed failure factor.

* If there is no failure factor, the corresponding LED indicator is off.

• Detailed fault factor

The following shows the codes displayed by the detailed fault factor 7-segment LED indicator.

14: T-link fault
26: Detailed information on T-link configuration fault (Contents of special relays WF020 to WF029) Indicates the station number of the faulted T-link station.
1A: BUS error
29: Detailed information on direct I/O configuration fault (Contents of W165.300 to 360) Indicates the slot number of the faulted slot (including the LED indicator number). Slot number: "00" to "15" Basic unit LED: "L1" Expansion unit LED: "L2" Identification not possible: "—"


1C: I/O area duplication (Contents of W165.109) Indicates a duplicated station number (00 to 99).
1F: Plant fault <fatal fault> (Contents of annunciator relay WA000) Indicates an annunciator relay number (01 to 0F).
2F: Plant fault <nonfatal fault> (Contents of annunciator relays WA001 to 003) Indicates an annunciator relay number (11 to 3F).

* When there is no detailed fault factor, the 7-segment LED indicator is off.

4.1 Name and Function of Each Part

- ⑳ Mode select switch (basic unit version 1001 or later)
When switching between I/O status display mode, user status display mode, and maintenance status

display mode, this switch is used to set the control word for the user display area (W124).
The following shows mode transitions.



- ㉑ Extension cable connector (basic unit version 1001 or later)
Used to connect the basic unit and expansion unit. This connector is available in three lengths: 0.3m, 0.6m, and 1.0m.


* When installing this connector, the supplied screwdriver can be used.
(For the installation procedure, see subsection 5.4.6 in Section 5.)

4.1 Name and Function of Each Part

4.1.3 Installing and uninstalling optional cards

(1) Installing and removing the EPROM/EEPROM memory card and the battery


- ① Open the cover of the basic unit.



* The expansion unit is not provided with a memory card or battery. Do not open the cover.


• Installing the battery

- ② Grasp the pull tab of the battery and pull the battery out.
- ③ Pull out the connector.
When installing the battery, follow the steps above in reverse order.



• Installing the EPROM/EEPROM memory card


- ② Grasp the pull tab of the EPROM/EEPROM memory card, and then pull it out.
When installing the card, follow the steps above in reverse order.



- * The EEPROM memory card is an option for basic unit case version 1001 or later.
- * The EEPROM is directly mounted on the card and is not intended to be replaced by the user.


4.1 Name and Function of Each Part

(2) Name and function of the EEPROM memory card (type: NV1VME-10)



- ① Write protect switch
Enables and disables write operation for the EEPROM.

Before setting this switch, be sure to turn off the power of the basic unit to avoid malfunction of the processor.




- OFF: Write protection is off.
Enables program write operation.
ON: Write protection is on.
Disables program write operation.

- ② Pull tab
When pulling out the EEPROM memory card from the basic unit, grasp this tab firmly, then pull it slowly.

- ③ Connector
Used to connect the EEPROM memory card to the basic unit.

(3) Handling the EEPROM memory card



<Installing the card>

- ① Turn off the power of the basic unit. Then confirm the orientation of the card, and insert it into the slot of the basic unit.
- ② Push the card with your fingers until it fits into position.

<Removing the card>

- ① Turn off the power of the basic unit, grasp the pull tab, and then pull out the card slowly.

Orientation of the card: When inserting the card, hold it so that the parts mount surface is oriented correctly, as shown in the illustration.

⚠ CAUTION


- Before installing or removing the memory card, turn off the power of the basic unit. Inserting or removing the memory card without turning off the power may cause damage to it or basic unit and/or cause malfunction of the basic unit.
- Before setting the memory setting switches (the write protect switch of the NV1VME-10), turn off the power of the basic unit. Setting a switch without turning off the power may cause malfunction of the basic unit.

4.1 Name and Function of Each Part


(4) Installing an optional card

① Remove the blank cover for the optional card.


Press and hold the mounting projection, then pull out the cover to remove it.




② Apply a character sheet on which the link No. and channel No. are printed.



③ Tighten the two connector screws.



④ Insert the optional card until it clicks into position.



* Steps ②, ③, and ④ can be performed in any order.

Note: Optional cards cannot be used for the expansion unit. Do not remove the blank cover of the expansion unit.


4.1 Name and Function of Each Part

(5) Installing the I/O card

① Remove the blank cover for I/O and function cards.


② Insert the I/O card until it clicks into position.

Press and hold the mounting projection, then pull out the cover to remove it.




(6) Mounting the basic unit to the rail

① With the rail mounting locks released as shown, attach the basic unit to the rail.



Note Attach clamps to prevent the basic unit from being dislocated by vibration.

② Press the rail mounting locks upward.




4.1 Name and Function of Each Part


4.1.4 Structure of the I/O card and I/O capsule

There are two types of I/O unit: card type and capsule type. The card type is installed on the rack, and the capsule type is used via the T-link.

I/O card



I/O capsule



4.1 Name and Function of Each Part

4.1.5 Name and function of each part of the I/O card and capsule

The I/O card and capsule consists of different components depending on the type as shown in the table below.

Name	Type	I/O card (8/16 points)	I/O card (32 points)	I/O capsule
① Cover		○	×	○
② Program loader connector		×	×	○
③ Address setting switches		×	×	○
④ I/O terminal block		○	×	○
⑤ Power supply terminal block		×	×	○
⑥ I/O status LED indicator		×	×	○
⑦ Mounting screws		×	×	○
⑧ T-link terminal block		×	×	○
⑨ Status LED indicators		×	×	○
⑩ Mounting projection		○	○	×
⑪ Printed circuit board		○	○	×

○ : Provided as standard × : Not provided

① Cover

Protects the terminals and address setting switches.
Removed when:

- a) wiring connection for the power supply is performed (I/O capsule only)
 - b) wiring connection for I/O is performed
 - c) address setting is made (I/O capsule only)
- Do not remove this cover during operation.

② Program loader connector (I/O capsule only)

Used to connect a program loader (called D10S, D20, D25, or personal computer loader) to the basic unit.

③ Address setting switches (I/O capsule only)

Used to set the T-link address. The upper switch is used to set the upper digit, and the lower one is used to set the lower digit.

④ I/O terminal block

Used connect external I/O devices to the basic unit. There are the following two types of I/O terminal blocks.

- a) Screw type terminal block
With this type, screw terminals are arranged on a single terminal block. Because the terminal block can be attached or detached, if an I/O capsule or I/O module experiences trouble, replacement work can be done without removing wiring connections.
- b) Connector type terminal block
This type is used for the 32-point I/O card. Use the supplied connector for wiring connections, referring to the specifications of each I/O device.

⑤ Power supply terminal block (I/O capsule only)

Used to connect the power supply.

4.1 Name and Function of Each Part

- ⑥ I/O status LED indicator
Displays the ON/OFF status of I/O devices. The number shown indicates the bit address (0 to F) or the relay number.
- ⑦ Mounting screws (I/O capsule only)
When installing the I/O capsule to the control panel, tighten these screws (2-M3.5).
 - Tightening torque: 0.8 to 0.9N·m (8 to 9kgf·cm)
- ⑧ T-link terminal block (I/O capsule only)
Used to connect the T-link cable (twisted pair cable).
- ⑨ Status LED indicators (I/O capsule only)
Displays I/O capsule status (POWER) and (ALARM).
 - These LEDs light to indicate the following state.



LED	Description
POWER	The power supply of the I/O capsule is normal.
ALARM	I/O capsule fault, T-link connection fault, processor module or capsule fault, power supply fault

- ⑩ Mounting projection
Used to install the I/O card to the rack.
- ⑪ Print circuit board
Before touching the printed circuit board, touch grounded metal to discharge static electricity.

4.2 Dimensions



■ Dimensions, mm

(1) NV1P-0□2, NV1E-0□2



Mounting screw
4-M5x20


• When the T-link connector is installed




Type	A	B	C	D	E	F	Mass	
							Case versions 0001 to 0999	Case version 1001 or later
NV1P-042 (4 cards can be installed)	250	260	85	95	97	142	Approx. 790g	Approx. 1000g
NV1P-062 (6 cards can be installed)	310	320					Approx. 860g	Approx. 1170g
NV1P-082 (8 cards can be installed)	370	380					Approx. 930g	Approx. 1340g
NV1E-042 (4 cards can be installed)	250	260					Approx. 890g	
NV1E-062 (6 cards can be installed)	310	320						<i>Under development</i>
NV1E-082 (8 cards can be installed)	370	380						Approx. 1230g

4.2 Dimensions

■ Dimensions, mm (2) 16 point I/O card




(3) 32 point I/O card




4.2 Dimensions

■ Dimensions, mm
 (4) T-link master card




(5) T-link slave card




4.2 Dimensions

■ Dimensions, mm

(6) High-speed counter card



(7) General-purpose interface card



Note: Allowable bending of the cable depends on the cable type.

4.3 Simulated Input Switch

4.3.1 Simulated input switch for the input card




The simulated input switch can be used to perform program debugging and programming exercises using the I/O card.

(1) Specifications

Type	NV1V-SW16	
No. of points	16 point input (8 point common x 2 circuits)	
Rated voltage	28V AC/DC maximum (20 to 28V AC/DC)	
Rated current	0.1A maximum (0.1mA to 0.1A)	
Contact resistance	0.05Ω or less (at 20mV 10mA)	
Endurance	Mechanical	100,000 operations or more
	Electrical	50,000 operations or more (10,000 times with 28V, 0.1A maximum)
Applicable I/O card	NV1X1604, NV1X1604-W	

(2) Structure

NV1V-SW16



Note: This switch is provided with a power supply connector cord; however, the terminal block for I/O modules is not supplied.

(3) Precautions on use

- ① The rated voltage is 28V AC/DC maximum and therefore it cannot be used with high voltage (such as 100V AC).
- ② When installing this switch, the printed circuit board may reach the mounting hole of the I/O case terminal block, depending on the insertion angle. Install the switch so that the pin of the printed circuit board is perpendicular to the terminal board.

4.3 Simulated Input Switch

4.3.2 Simulated input switch for the input capsule


The simulated input switch can be used to perform program debugging and programming exercises using the I/O capsule.

(1) Specifications

Type	NH8V-SW16 (FTX100A-S16)		NH8V-SW32 (FTX100A-S32)
No. of points	16 point input (8 point common x 2 circuits)		32 point input (8 point common x 4 circuits)
Rated voltage	28V AC/DC maximum (20 to 28V AC/DC)		
Rated current	0.1A maximum (0.1mA to 0.1A)		
Contact resistance	0.05Ω or less (ay 20mV 10mA)		
Endurance	Mechanical	100,000 operations or more	
	Electrical	50,000 operations or more	



(2) Structure

NH8V-SW16



NH8V-SW32

(The terminal block for I/O modules is connected.)



Note: This switch is provided with a power supply connector cord.

Section 5 Installation and Wiring

	Page
5.1 Precautions on Installation	5-2
5.2 Before Installing the Unit	5-4
5.2.1 Checking delivered products	5-4
5.2.2 Checking normal processor operation	5-4
5.3 Installing the Unit on the Control Panel	5-6
5.3.1 Countermeasures for noise	5-6
5.3.2 Installing the panel	5-9
5.3.3 Installing PC units	5-10
5.4 Wiring	5-13
5.4.1 Wiring and types of wires	5-14
5.4.2 Wiring for the T-link	5-15
5.4.3 Wiring for power supply and ground terminals	5-16
5.4.4 I/O wiring processing	5-21
5.4.5 Checking address settings for external I/O devices	5-22
5.4.6 Connecting extension cables	5-23

Section 5 Installation and Wiring

5.1 Precautions on Installation


This section explains how to install MICREX-F Series products on a control panel and connect wiring.

Precautions regarding the handling of these products are also described.


⚠ CAUTION

Avoid doing the following actions. Doing so may cause damage, malfunction, or failure of the product.


- ① Do not drop or bring down the product.



- ④ Avoid mounting the unit on a panel in which high-voltage devices (3000V, 6000V or higher) are mounted.
⑤ Do not use the same power supply which supplies the power to noise generating device




- ② Avoid installing the unit on locations which are subject to excessive vibration.





- ⑥ Avoid using the unit on locations which are subject to high or low temperature or high humidity, or locations where condensation may occur because of rapid temperature change.

Operating temperature: 0 to 55°C
Operating humidity: 20 to 90%RH
(without condensation)



- ③ Avoid installing the unit on locations where corrosive gas is present.



5.1 Precautions on Installation

(2) When the power supply is turned on, the ALARM indicator may light.


The possible causes are as follows:

- 1) The memory contents are not written in specified format.
- 2) Hardware fault

- ALARM indicators light.

In most cases, the cause of the fault is 1). In this case, delete the memory contents by using the program loader and the resupply power. The ALARM indication will stay OFF.

- Delete the memory contents.
(System definition area, program area, and data area)



(3) Be sure to turn on the power supply of the expansion unit first and then the power supply of the basic unit. (They can be turned on at the same time.)

If the power supply of the basic unit is turned on first, the following conditions result.

- The system operates only with the basic unit with the expansion unit not recognized.
- I/O slots on the expansion unit are recognized as empty slots, resulting in direct I/O fault.
Be sure to turn off the power supply of the basic unit and then the power supply of the expansion unit. (They can be turned off at the same time.)

(4) 24V DC power supply for relay coil driving

When installing the relay output card, be sure to use a 24V power supply.

Power current capacity:

Approx. 8.3mA/point x (maximum number of ON points)

(5) Use the specified T-link cable. (See subsection 3.7 for details.)

T-link cable: Twisted pair cable, KPEV-SB 1.25mm², 1 pair

T-link cables other than the above can be used if the distance is limited.

(See subsection 3.7.)

In addition, be sure to attach the supplied termination resistors at both ends of the T-link. (See subsection 5.4.2)

Termination resistor for the T-link: 100Ω, 1W or more


5.2 Before Installing the Unit

5.2.1 Checking delivered products

When unpacking the delivered products, make sure the following:

- 1) The product is exactly the one that you have ordered.
- 2) No products have been damaged during transportation.
- 3) There are all the parts. (For the supplied parts, see the type list in subsection 1.4.2.)

(1) Assembling a system



Assembling procedure

- 1) Install the I/O card into the rack.
- 2) When the T-link master card is to be used, attach the 100Ω termination resistors, which are supplied on the T-link connector, to both ends of the T-link.
- 3) Make wiring connection to the power supply terminal and then turn on the power supply of the processor.

In addition to the **RUN** indicator, the **ALM1** or **ALM2** indicator may light. The ALM indicator lights if the memory contents are not formatted as specified. In this case, connect the program loader, delete the memory contents (system definition area, program area, and all data area), turn off the power, and then resupply power to the PC. The ALM indicator goes off.

(2) Memory deleting procedure by the D20 type program loader


No.	Item	Key operation
1	System definition area	AUX F6 F3 ENT *
2	Program area	F3 ENT *
3	All data area	F3 ENT *

*Press the **ENT** key twice during processor operation (the **RUN** indicator is on).

5.2 Before Installing the Unit

(3) Checking normal operation with the test program

Store the following program in the PC memory and execute it. If normal operation results, proceed with the next step (installation to the control panel); otherwise, check the description in (1) "Assembling a system" above again.



Note: Enter the address according to actual device.

■ Writing the program

When writing a new program in the user memory or when the program is updated, it is necessary to read the corresponding memory.

Operation flow	Key operation	Screen display	Remarks
Set the processor in the memory read mode.	MON RD	Read	● When the target memory is the processor, press MON.
Execute read operation.	PAGE/DATA 6 ENT	▲ Page 0001	▲: Read mode cursor
Set the program write mode.	WR	▼ Page 0001	▼: Write mode cursor
Move the cursor downward.	↓	When the write mode is entered, the shape of the triangle cursor changes.	
Set input specifications.	← B 0 3 7 .	B0 ← Page 0001	
Move the cursor and set output specifications.	→ () B D 7 3 0 - .	B0 → () Page 0001	
Write program to the memory.	LOAD ENT ENT*		

* When the processor is in operation, press the ENT key twice.

■ Operation check

After the above program has been written to the memory, if output B0030 goes on when input B0000 is

turned on, processor operation is normal. Proceed with the next installation step.

5.3 Installing the Unit on the Control Panel







5.3.1 Countermeasures for noise

(1) The MICREX-F series is provided with sufficient noise immunity; however, to further improve the

reliability of the system, the following measures are recommended.


No.	Noise source	Countermeasures
1	Noise coming from the power supply terminals <ul style="list-style-type: none"> • Lightning surge • Internal surge (on/off surge) 	1) Use a shield isolation transformer (such as FUJI power filter) <div data-bbox="762 546 1311 786" style="text-align: center;"> <p>Electrostatic shield (Reduces stray capacitance between the primary and secondary windings.)</p> </div> 2) Surge absorbers should be connected to the surge generating device. <div data-bbox="842 927 1289 1218" style="text-align: center;"> <p>Chassis</p> </div>
2	High frequency noise	○ Use a noise filter. Twisted pair wire should be used between the noise filter and power supply terminals of the processor. <div data-bbox="767 1384 1359 1570" style="text-align: center;"> <p>(Example: FUJI power filter)</p> </div>
3	Noise due to common grounding	○ Individual grounding shown below is the best. <div data-bbox="165 1727 700 1944" style="text-align: center;"> <p>Common grounding not allowed.</p> </div> <div data-bbox="772 1715 1394 1921" style="text-align: center;"> <p>Grounding (Grounding resistance of 100Ω or less)</p> </div> <p>For details on grounding, see (2) in subsection 5.3.1.</p>
4	Noise coming from the ground for the secondary winding of the transformer	Do not connect the secondary winding of the isolation transformer to the ground.

5.3 Installing the Unit on the Control Panel

No.	Noise source	Countermeasures
5	<p>When an inductive load current is switched off, high voltage is induced at both ends of load, causing some effect on PC operation.</p> 	<p>1) Connect a diode, varistor, or CR circuit to a DC load. 2) Connect a CR circuit to an AC load.</p> <p>(Example)</p> 
6	<p>The external I/O signal malfunctions in the following cases: If the cable is bounded together with high-voltage or power lines If the cable is wired in proximity of and in parallel with these lines This type of noise is caused by electromagnetic induction or electrostatic induction.</p>	<p>Separate the I/O lines from these lines and avoid wiring them within the same panel or pit. Make separate wiring with duct, wiring with independent cable pipe, or metal pipe (shown below). (See subsection 5.4.1.)</p>
7	<p>Malfunction or damage due to lightning surge to the transmission line (T-link)</p> 	<p>T-link cable should be run through underground metal pipes or in an electrical duct. The metal pipes should be grounded.</p> 
8	<p>Malfunction due to grounding with the arc-generating switch</p>  <p>When the door of the control panel is closed, if the distance (L) between the rear panel of the MICREX-F and magnetic contactor becomes 50mm or less, the PC malfunctions due to switching arc generated by on/off operation of the contactor.</p>	<p>Change the layout or install shield plate around the magnetic contactor.</p> 

5.3 Installing the Unit on the Control Panel

- (2) The following describes the recommended grounding procedure.




■ Description

- Sufficient noise countermeasures have been made for each card and capsule for the MICREX-F series. Except when there is much noise, each card and capsule can be used without grounding. When grounding is made, follow steps 2 to 8 below.
- Connect the FG terminal to the integrated ground section of each control panel (FG bus, FG integrated terminal block, or stud) in **branch-type configuration**. The **thickness** of the ground wire must be **2 mm² (ø1.6) or more**. Allocate the grounding point as near the card or capsule as possible to keep the ground wire as short as possible.
- Connect the integrated ground section to the integrated ground plate for each area in **branch-**

type configuration. The **thickness** of the ground wire must be **5.5mm² (ø2.6) or more**.

- Separate the ground wire as far from the lines of high-voltage circuits and main circuit as possible. In addition, keep the distance at which they run in parallel as short as possible.
- For grounding of the MICREX-F series, use dedicated ground pole and wire which are separated from those for other power lines.
- For grounding of the MICREX-F series, grounding resistance is 100Ω or less. Separate the ground pole 10m or more from that for other power lines.
- If dedicated grounding cannot be made, use ② integrated grounding below.



8. When the PC is installed on locations with inferior lightning surge conditions, electrically isolate the basic unit and all I/O capsules and cards from the control panel, and then connect each capsule and card to the ground separately.

5.3 Installing the Unit on the Control Panel

5.3.2 Installing the panel

CAUTION

- Use the control panel under environmental conditions described in the manual. Using the control panel on locations which are subject to high temperature, high humidity, condensation, dust, corrosive gas, or excessive vibration or shock may cause electrical shock, fire accident, malfunction, or failure. (For environmental specifications, see page 3-1 or the table below.)

To further improve the reliability and safety of the system, observe the following points:

Item	Specification	Remark
Operating temperature	<ul style="list-style-type: none"> • The rated operating temperature range is 0 to 55°C. • Avoid installing the control panel on locations which are exposed to direct sunlight. 	<ul style="list-style-type: none"> • If the ambient temperature is too high, install a fan or air conditioner; if it is too low, install a heater inside the control panel.
Relative humidity	<ul style="list-style-type: none"> • The relative humidity range is 20 to 90%. • Be careful not to allow condensation due to rapid temperature change. 	<ul style="list-style-type: none"> • In the winter time in particular, turning on or off the room-heater may cause condensation due to rapid temperature change. If there is possibly of condensation, keep the air conditioner turned on even during the night.
Resistance to vibration	<ul style="list-style-type: none"> • JIS C 0911, crossover frequency 57Hz, 9.8m/s² (1G) * • JIS C 0911, crossover frequency 57Hz, 19.6m/s² (2G) For 2 hours into 3 axis directions 	<ul style="list-style-type: none"> • If the control panel is subject to excessive vibration or shock, use vibration-absorbing rubber to secure the control panel or perform anti-vibration processing for the building or floor.
Resistance to shock	<ul style="list-style-type: none"> • JIS C 0912, test method 1-No.3, 294 m/s² (30G) * 2 times into 3 axis directions 	
Dust	<ul style="list-style-type: none"> • No conductive dust present 	<ul style="list-style-type: none"> • If excessive gas is present, perform air purification for the control panel.
Corrosive gas	<ul style="list-style-type: none"> • No corrosive gas present 	

Note *: When mounted by the rail, there should be no vibration or shock. Or use end clamps.

5.3 Installing the Unit on the Control Panel


5.3.3 Installing PC units

⚠ CAUTION

- Keep an open space around the PC unit as shown below to obtain sufficient ventilation; otherwise, abnormal temperature rise or failure occurs.

Keep an open space as follows:

- ① Keep an open space of 110mm (vertical) or 10mm (horizontal) between the PC units, between I/O capsules, and between the PC unit and I/O capsule.
- ② Keep an open space of 50mm between the PC unit and other device and between the PC unit and the wall to obtain sufficient ventilation.
- ③ Avoid installing heat generating devices (heaters, transformers, or resistors) underneath the PC unit.
- ④ Separate or shield the PC unit as far from high-voltage device, high-voltage cables, or power equipment as possible. Avoid installing I/O cables of the PC unit and cables of high-voltage or power equipment in parallel.
- ⑤ Install the PC unit perpendicular to the panel floor.




5.3 Installing the Unit on the Control Panel

5.3.4 Address assignment (Setting)

When PC units have been installed on the control panel and operation panel, make address assignment for each capsule and card.

In the following example, 16-point and 32-point digital I/O cards are used.




Notes:

- 1) The address number (station number) of multiple FTK capsules is duplicated, T-link transmission error result, disabling normal transmission.
- 2) The address setting of the T-link interface module (FTL010H) and the address number of the FTK address (station number) is duplicated, T-link


configuration fault occurs, resulting in a fatal fault of the PC.

- 3) If duplication occurs in area B (I/O area) with different station numbers, "I/O area overlapping" (F001C) occurs, resulting in a fatal fault of the PC.

Example of incorrect address setting




RTL010H



5.3 Installing the Unit on the Control Panel

Basic unit, expansion unit, and I/O capsule



Notes:

- Address assignment for the I/O area is made from the least significant word and bit addresses. However, for 8 point I/O cards, the upper 8 points are made empty.
- Address assignment is made continuously for the basic unit and expansion unit.
- For the basic unit and expansion unit, install I/O cards from left to right. In addition, do not make any blank slots between cards.
- The following cards (cards using interrupt) cannot be installed in the expansion unit.
 - High-speed counter card (NV1F-HC1)
 - External interrupt card (NV1F-YP1)

When performing wiring works, observe the following points:

(1) Warning on wiring works

WARNING

- Never touch any part of charged circuits as terminals and exposed metal portion while the power is turned ON. It may result in an electric shock to the operator.
- Turn OFF the power before mounting, dismounting, wiring, maintaining or checking, otherwise, electric shock, erratic operation or troubles might occur.
- Place the emergency stop circuit, interlock circuit or the like for safety outside the PC. A failure of PC might break or cause problems to the machine.

(2) Cautions on wiring works

CAUTION

- Select a wire size to suit the applied voltage and carrying current, and carry out wiring according to the operating instructions and manual. Poor wiring might cause fire.
- Periodically make sure the terminal screws and mounting screws are securely tightened. Operation at a loosened status might cause fire or erratic operation.
- Before touching the PC, touch any metallic object which is connected to the ground to discharge static electricity. Excessive static electricity may cause malfunction or fault.

(3) Cautions on wiring check


CAUTION

- Sufficiently make sure of safety before program change, forced output, starting, stopping or anything else during a run.
- Engage the loader connector in a correct orientation, otherwise, an erratic operation might occur.

5.4 Wiring

5.4.1 Wiring and types of wires

Use the following types of cables for MICREX-F systems and the following connections are recommended.



■ Types of cables

Item	Specification	
F55 series	T-link cable*	
	Twisted pair cable: KPEV-SB 0.5mm ² (1 pair) up to 700m	
	Basic unit (power supply)	
	2mm ² (to be twisted before use)	
	8/16 point card	Input device for the input card
	Output device for the output card	0.75mm ² or less
32 point card	Input device for the input card	AWG #23 (0.25mm ² or ø0.6) or less
	Output device for the output card	AWG #23 (0.25mm ² or ø0.6) or less
I/O capsule	Power supply	
	2mm ² (to be twisted before use)	
	I/O capsule	Input device for the input card
	Output device for the output card	0.75 to 1.25mm ²

*If T-link cables not specified in subsection 3.7 "Cable Specifications" are used, the system may malfunction.

5.4 Wiring


5.4.2 Wiring for the T-link

(1) Termination processing


Make termination processing of twisted pair cables and then connect it to the T-link terminal block. In this case, the total length of the T-link twisted pair cable must be

1km or less. (However, the cable can be extended by using of an optical adapter.)


① Remove a part of the sheath and internal insulation



② Attach crimp terminals




Apply the supplied insulation tube before caulking the terminal.



Direct wire connection to the terminal block without using crimp terminals may cause contact failure, resulting in T-link transmission errors. Be sure to use crimp terminals.

When the two T-link cables are to be connected to one terminal block, each pair of T-link cables can be connected to one crimp terminal for convenience.

③ Connection




Up to 32 PIO and special capsule units can be connected.

At both ends of the T-link, connect a 100Ω termination resistor supplied with the processor.

Connect a termination resistor even for independent systems which do not use the T-link.

* If the total length exceeds 1km, waveform distortion may be caused by external noise or signal attenuation, making it difficult to perform accurate signal transmission. In this case, the system failure or malfunction may occur.



(2) Example incorrect wiring for the T-link

	Correct	Incorrect
T1, T2, and SD terminal		<p>Example 1</p> <p>Example 2</p> <p>Example 3</p> <p>Internal parts are not damaged but accurate transmission is not possible.</p> <p>Accurate transmission is not possible even for short distance (without shield lines).</p>
Wiring and other works	<p>T-link connection is made in daisy chain form.</p> <p>The processor can be placed on any position.</p>	<p>Branching is not allowed for T-link connection.</p>


5.4 Wiring

5.4.3 Wiring for power supply and ground terminals

(1) Notes on wiring


- 1) If power supply voltage fluctuation of the basic unit and I/O cards exceeds the specified range, connect a

voltage stabilizer (an output waveform distortion of the stabilizer must be within 5%) to the power supply.



- 2) Use a power supply with low noise between power lines and between lines and ground. For countermeasures against excessive noise, see subsection 4.3.1.

- 3) The power supply wiring to the basic unit must be separated from wiring for I/O devices and for power equipment.



- 4) Keep the distance between the isolation transformer and the basic unit as short as possible, using twisted pair cables. In addition, to minimize voltage

- drop, use cables with a thickness of 2mm² or more. 5) The 24V DC I/O cables must be separated from 100V AC and 200V AC cables.

(2) Applicable cable size and crimp terminals


Select crimp terminals, referencing the following table.

⚠ CAUTION

- Select a wire size to suit the applied voltage and carrying current, and carry out wiring according to the operating instructions and manual. Poor wiring might cause fire.
- Periodically make sure the terminal screws and mounting screws are securely tightened. Operation at a loosened status might cause fire or erratic operation.

Connection method	Tightening	Cable size
M3.5 screw (with washer)	0.8 to 0.9N·m (8 to 9kgf·cm)	0.25 to 1.65mm ²
		1.04 to 2.63mm ²
Connector		AWG#23 or less*


Terminal block dimension, mm



M3.5 screw with washer

* Accessory cable is FCN 361J040-AU.

(3) Example external wiring on independent systems (1)




- 1) Power supply capacity
 - The power consumption is 40VA or less when the maximum configuration (including expansion units) is used. Design the wiring so that voltage drop due to inrush current (40A, 10ms or less at 100V AC) at power on is 15% or less.
 - To prevent voltage drop, use cables with a thickness of 2mm² or more.
- 2) Noise reduction
 - Although noise reduction device has been incorporated, use of an isolation transformer and twisted pair cables is recommended.
 - Connect the frame ground terminal (FG) of each component to a ground (ground resistance of 100Ω or less). In this case, it is desirable to make independent ground for each capsule. (For details, see (2) in subsection 5.3.1.)

- 3) When the HOLD station is registered, to supply voltage to the output card without interruption, make wiring indicated by *2. (In case of direct access method)
- 4) Connect the supplied termination resistor (*3) between terminals T1 and T2 of the T-link connector which is to be installed on the T-link master card.
- 5) Normally, connect terminals LG and FG. In this case be sure to make grounding (If grounding is not to be made, do not connect these terminals.). Connecting these terminals without grounding may reduce noise immunity. Terminal LG has voltage potential which is 1/2 times the input voltage and therefore touching it may cause electrical shock.

5.4 Wiring

(4) Example external wiring on expansion systems (2)



- *1 When using a relay output card, be sure to use 24V power supply.
- *2 See item 3) below.
- *3 See item 4) below.

1) Power supply capacity



- The power consumption of the NV1P-082 is 40VA or less with the maximum configuration (with 8 I/O cards). Design the wiring so that voltage drop due to inrush current (40A, 10ms or less at 100V AC) at power on is 15% or less.
- To prevent voltage drop, use cables with a thickness of 2mm² or more.

2) Noise reduction


- Although noise reduction device has been incorporated, use of an isolation transformer and twisted pair cables is recommended.

- Connect the frame ground terminal (FG) of each component to a ground (ground resistance of 100Ω or less).
- 3) When the HOLD station is registered, to supply voltage to the output card without interruption, make wiring indicated by *2.
- 4) Connect the supplied termination resistor (*3) between terminals T₁ and T₂ of the T-link connector which is to be installed on the T-link master card or the T-link slave card.
- 5) Do not connect the 24V DC output on the basic unit and the 24V DC output on the T-link interface module (type FTL010) in parallel.

(5) Example external wiring on distributed systems



ONE-POINT ADVICE Tips for Improving Safety of the PC System



Since the PC is provided with sufficient reliability, use of the PC does not result in reduction of system safety. However, like any other electronic appliances and control equipment, the PC is not perfect and has possibilities of failure. To further improve safety, it is necessary to implement a safety circuit which makes it possible to stop system operation in the event of emergency or trouble. The safety circuit should be configured as an external circuit.


(1) Emergency stop

It is necessary to configure an emergency stop circuit as an external circuit and install an emergency stop switch on a location which is easy for the operator to use. This emergency stop circuit normally is integrated into the interlock circuit which disconnects the I/O control power supply in the event of failure.

(2) Interlock relay

The interlock relay (ILR) opens if an emergency or a failure occurs to disconnect the power output. The interlock circuit incorporates a RUN contact in series with the ILR which closes only during PC operation. If a failure is detected by the PC self diagnostic function, the ILR opens.


The configuration of safety circuit differs according to the PC configuration and controlled equipment. The following shows an example.



5.4.4 I/O wiring processing


- 1) Use a crimp terminal to each wire and secure it to the terminal block with a screw. Then make arrangement so that wires be stored inside the duct

of the I/O card. The following shows an example wiring processing.



The figure at left shows recommended wiring processing.

- 2) Because the I/O terminal block is connector type, it can be removed from the case with wiring connections.




Note: The cable size connectable to the terminal block is 0.75mm² or less (1.25mm² or less for common terminals). If 1.25mm² wires are used for entire connections, the cover of the terminal block cannot be fitted depending on the cable type (diameter with wire sheath). Use the specified cable size.

5.4 Wiring

5.4.5 Checking address settings for external I/O devices

After installation, make sure that every I/O device is connected to the specified address for the I/O capsules

and I/O cards. The following describes the procedure for address check.




(1) Checking address settings for input devices

- 1) Turn on the power supply of the processor and the I/O capsules (or T-link interface modules).
- 2) Set the processor into the stop mode by using the program loader.

- 3) Close the contacts of input devices in sequence. Each time a contact is closed, make sure that the address of the input device matches corresponding address indicated by the I/O status LED indicator using the program loader.


(2) Checking address settings for output devices

Follow the steps below to check address settings for output devices. Turn on only control circuits (such as contactors) and turn off the main circuit power supply. (See the figure below.)




- 1) Turn on the PC and the program loader.
- 2) Set the processor into the stop mode by using the program loader.
- 3) Read out the word address to which the output device is connected. For example, word address WB003 is read by the following key operation.


- 4) Set data for the word address to be checked to forcibly set the desired bits on.
 - For example, to forcibly set B003F on, press the following keys.





- To forcibly set B003E on, press the following keys.



- To forcibly set B0039 on, press the following keys.



When the above operation is completed, the corresponding LED indicator of the output card/capsule goes on and the output device is turned on. (However, it is assumed that the power of the output circuit is supplied.)



Program loader (D20)


Bit No.	10 ³	10 ²	10 ¹	10 ⁰	
0	2 ³	0	0	0	→ 8000
1	2 ²	0	0	0	→ 4000
2	2 ¹	0	0	0	→ 2000
3	2 ⁰	0	0	0	→ 1000
4	2 ³	0	0	0	→ 800
5	2 ²	0	0	0	→ 400
6	2 ¹	0	0	0	→ 200
7	2 ⁰	0	0	0	→ 100
8	2 ³	0	0	0	→ 80
9	2 ²	0	0	0	→ 40
A	2 ¹	0	0	0	→ 20
B	2 ⁰	0	0	0	→ 10
C	2 ³	0	0	0	→ 8
D	2 ²	0	0	0	→ 4
E	2 ¹	0	0	0	→ 2
F	2 ⁰	0	0	0	→ 1

↑
Corresponding value for bit No.

After conforming that I/O devices are allocated to the specified address properly by means of the above procedure, delete the contents of the all memory in the processor and then proceed with the programming steps. If you have done the above procedure correctly, the debugging time in test operation will be reduced.


5.4.6 Connecting extension cables

The following shows wiring example for extension cables when the expansion unit is used.



Align the connector position and then press straight the connector until it fits into position.

Securely tighten the screws at both ends of the connector. The supplied screwdriver can be used.




Section 6 Test Operation

	Page
6.1 Preliminary Check	6-3
6.2 Test Operation	6-4

Section 6 Test Operation

Prior to test operation, it is recommended that the user program be stored in cassette tape or floppy disks.


When I/O wiring for the PC is completed, turn on the power supply, follow the steps below to perform test operation.



6.1 Preliminary Check

(1) PC installation condition check

- 1) Structure and environment of the control panel and operation panel
Check the items in subsection 5.3.2.
- 2) Others
Check the following points:
 - a) Address assignment and address settings are correct, there is no address duplication, and the address name plate is properly attached.
 - b) Dust-proof seals have been removed from the basic and expansion units.



CAUTION

- Do not use one found damaged or deformed when unpacked, otherwise, failure or erratic operation might be caused.
- Periodically make sure the terminal screws and mounting screws are securely tightened. Operation at a loosened status might cause fire or erratic operation.
- Avoid installing the PC near noise generating devices. Installing the PC near such devices may cause damage, malfunction, or fault.

(2) Wiring check prior to power on

CAUTION

- Installation, wiring, maintenance, and inspection works must done by qualified personnel with electrical knowledge. Incorrect wiring may cause fire accident, malfunction, or fault.

Make sure the following points:

- a) The T-link cable and I/O power cables for the PC are securely isolated from power lines.
- b) Wiring connections for the power supply, I/O cards, and ground terminal are correct.
- c) The T-link cable conforms to the specifications.
- d) T-link wiring conforms to the specifications and correct termination resistors are connected at both ends of the T-link.
Termination resistor: 100Ω, 1W or more

(3) Insulation resistance and dielectric strength tests

The MICREX-F is designed to guarantee the following values:

- 5MΩ or more using 500V DC megger
- 1 minute at 1500V AC

(4) Power voltage measurement


CAUTION

- Select a wire size to suit the applied voltage and carrying current, and carry out wiring according to the operating instructions and manual. Poor wiring might cause fire.


6.2 Test Operation

(1) Power on test

- 1) To minimize damage due to incorrect wiring, perform the following processing:
 - Turn off the power supply of the power circuits such as magnetic contactors and starters.
 - When a compressor is used, close the valve.
- 2) Turn on the power of the PC.
 - Power on sequence



- Make sure that there is no abnormal sound.
- On the processor, only the **POW** and **RUN** indicators light.



LED	Color	Status	Description
POW	Green		Power supply circuit normal output
RUN	Green	Operating	User program being executed
ALM1	Red	Fatal fault	Fatal fault occurred (Any of special relays F0010 to F001F is on.)
ALM2	Red	Nonfatal fault	Nonfatal fault occurred (Any of special relays F0020 to F002F is on.)
BAT	Red	Battery error	Battery disconnected or voltage drop (Special relay F0020 is on.)

- On the T-link device, only the **POW** and **RUN** indicators light.

(2) External wiring check

See subsection 4.4.

(3) Safety circuit check

WARNING

- Place the emergency stop circuit, interlock circuit or the like for safety outside the PC. A failure of PC might break or cause problems to the machine.

Make sure that the emergency stop circuit and interlock circuit operate normally.

(4) Individual manual operation test

Check the operation of each section using the manual circuit.

(5) Automatic operation test

If possible, begin automatic operation with specific system equipment and facilities or by operating individual units. Then, automatic operation for the entire system is performed.

When the "T-link registration" function of the PC is used, only the registered capsules operate. This may be conveniently used to operate specific unit.

(6) Abnormal operation test

This test checks whether the safety circuit of the PC operates normally if the facility does not operate normally and whether it be recovered normally.

* Related check points

- 1) HOLD station settings are correct and the station operates normally.
- 2) The plant fault circuit created by the user program operates normally.

Section 7 Troubleshooting

	Page
7.1 Troubleshooting	7-2
7.2 Reduction of Repair Time	7-3
7.3 General Trouble Recovery Procedure	7-4
7.3.1 With ALM indication	7-4
7.3.2 Without ALM indication	7-4
7.4 LED Indication of the Basic Unit	7-5
7.5 Meaning of ALM LED Indication	7-6
7.6 Diagnostic Procedure for Alarms	7-7
7.7 Diagnosis of Fatal Faults	7-8
7.7.1 Self-diagnosis of ALM1 fatal faults	7-8
7.7.2 F0010 (Memory error)	7-9
7.7.3 F0013 "Power failure" (Momentary power failure)	7-9
7.7.4 F0014 "T-link fault" (Fatal fault)	7-10
7.7.5 F0015 "Option fault" (Fatal fault)	7-10
7.7.6 F0018 "User program error"	7-11
7.7.7 F0019 "WDT (Watch-dog timer) error"	7-11
7.7.8 F001A "Bus error"	7-12
7.7.9 F001C "I/O area duplication"	7-12
7.7.10 F001D "Too many capsules on T-link"	7-12
7.7.11 F001E "Too many I/O addresses"	7-12
7.7.12 F001F "Plant fault (Fatal fault)"	7-13
7.7.13 F0690 "0 slot option fault (Fatal fault)"	7-13
7.8 Diagnosis of Nonfatal Fault	7-14
7.8.1 Self-diagnosis of ALM2 (Nonfatal fault)	7-14
7.8.2 F0022 "Option fault (Nonfatal fault)"	7-15
7.8.3 F0026 "T-link configuration fault"	7-15
7.8.4 F0029 "Direct I/O fault"	7-18
7.8.5 F002E "Program slow-down"	7-18
7.8.6 F002F "Plant fault (Nonfatal fault)"	7-18

Section 7 Troubleshooting

7.1 Troubleshooting

This section describes how to locate the cause of a fault, and provides possible countermeasures for trouble. If the MICREX-F series incurs trouble during

processor operation, the **ALM1** or **ALM2** LED indicator on the processor lights.

(1) The **ALM1** LED indicator lights when the power of the new unit is turned on (before a program is entered)

Possible causes are as follows:

- 1) Memory contents not formatted as specified.
- 2) Hardware error


A common cause of this error is 1). In this case, delete the memory contents using program loaders, and then turn on the power again. The ALM1 LED indicator goes off.

• ALM1 LED indicator lights

• Memory delete


Memory includes the following areas:

- System definition area
- Program area
- Data area



■ Memory deletion procedure

Follow the steps below to delete the contents of memory.




7.2 Reduction of Repair Time

With the F55 series, if a distributed unit configuration is made using the T-link, the cause of a fault may involve two or more units.


Therefore, it is necessary to know the unit configuration of the system, and to store needed programs and data in advance.

Maintenance to be performed on a daily basis




7.3 General Trouble Recovery Procedure


7.3.1 With ALM indication



7.3.2 Without ALM indication



7.4 LED Indication of the Basic Unit



7.5 Meaning of ALM LED Indication

ALM1 lights if a fatal fault occurs or special relay F0002 is set on.
ALM2 lights if a nonfatal fault occurs or special relay F0003 is set on.

ALM1 (fatal fault)

F0010 Memory error
F0013 Power supply fault
F0014 T-link fault (Units or cables on the T-link fault, or on the FTL auxiliary power supply fault)
F0015 Option fault
F0018 User program error
F0019 WDT error
F001A Bus error
F001C I/O area duplication
F001D Too many capsules on T-link
F001E Too many I/O addresses
F001F Plant fault (fatal fault)
F0690 0 slot option fault

* F0010, F0012, or F0013 indicate hardware fault of the processor.

ALM2 (nonfatal fault)


F0022 Option fault
F0026 T-link configuration fault
F0029 Direct I/O configuration fault
F002E Program slow-down
F002F Plant fault (nonfatal fault)

* Only F002F is caused by user program operation.

If a fatal fault occurs, all units on the T-link are deactivated. (The RUN indicator goes off.)
If a nonfatal fault occurs, operation continues and external indication is made by means of LED indicators and failure contact output.


7.6 Diagnostic Procedure for Alarms

If the ALM LED indicator on the basic unit or the FTL/FTK lights, perform the following diagnostic procedure:




7.7 Diagnosis of Fatal Faults

7.7.1 Self-diagnosis of ALM1 fatal faults



If the **ALM1** LED indicator lights during processor operation, the self-diagnostic function of the CPU detects a fatal fault factor, and then stores the fault information in the special relay (F).

■ Diagnosis flow




Diagnosis procedure with the D20 loader

<Operation>

Perform the following key operation to call up the following screen.

AUX,
 F2,
 F1,
 NEXT FRAME,



7.7 Diagnosis of Fatal Faults

7.7.2 F0010 (Memory error)

Memory error occurs if the processor memory becomes abnormal.
Memory check data is generated as checksum data when written or transferred to the processor from the

program loader. Data is always checked when a program is started and during operation.
The following shows possible causes for memory error.

Error	① Memory contents are defective.
Processing	<p>Perform the following key operation to delete the memory contents.</p> <p><Operation for D25> (from the initial screen)</p> <p style="text-align: center;"> <input type="button" value="F5"/> <input type="button" value="F6"/> <input type="button" value="F3"/> <input type="button" value="ENT"/> <input type="button" value="F4"/> <input type="button" value="ENT"/> <input type="button" value="F5"/> <input type="button" value="ENT"/> </p> <p><Operation for D20></p> <p style="text-align: center;"> <input type="button" value="AUX"/> <input type="button" value="F6"/> <input type="button" value="F3"/> <input type="button" value="ENT"/> <input type="button" value="F4"/> <input type="button" value="ENT"/> <input type="button" value="F5"/> <input type="button" value="ENT"/> </p> <p><Operation for D10S></p> <p style="text-align: center;"> <input type="button" value="AUX"/> <input type="button" value="↓"/> <input type="button" value="↓"/> <input type="button" value="↓"/> <input type="button" value="↓"/> <input type="button" value="ENT"/> </p> <p style="text-align: center;"> <input type="button" value="ENT"/> <input type="button" value="↓"/> <input type="button" value="ENT"/> <input type="button" value="↓"/> <input type="button" value="ENT"/> </p>
Error	② Memory contents destroyed due to battery depletion.
Processing	<p>1) Check the battery connection and replace if necessary. 2) Check the program.</p> <p>Note: Memory backup by battery To detect a memory error, the contents of the program area and system definition area, which are backed up by battery, are monitored based on checksum data. Checksum data is generated when data is written or transferred to the processor from the program loader, and are always monitored during processor operation, as well as at the time of program starting. If the power is turned off with the BATTERY alarm on, or if the battery voltage drops during power off, the memory contents may be destroyed. In this case, a memory error due to checksum error may occur when the power is turned back on.</p>

7.7.3 F0013 "Power failure" (Momentary power failure)

If a power failure lasts for 10ms or longer during processor operation, processing by the processor program is interrupted. (If it lasts for less than 10ms, processor operation is not interrupted.) When the power is recovered, the processor is restarted.
If a power failure occurs, F0013 is set on, and when the

processor is started, F0013 is copied to bit 3 of RAS copy area W166.4. Therefore, if zero is set to area W166.4, momentary power failure can be detected by means of this address. Only data monitoring or data setting is possible for area W166.4. This address cannot be used by a program.

7.7 Diagnosis of Fatal Faults

7.7.4 F0014 "T-link fault" (Fatal fault)

This fault indicates that the T-link controller of the CPU has had trouble and that the all T-link function is disabled. In this case, replacement of the CPU may be necessary. If fail-soft operation is not specified and a T-link configuration fault (F0026) such as FK capsule

fault or T-link cable disconnection occurs, a T-link fault (nonfatal fault) also occurs. For details on T-link configuration fault, see subsection 7.8.3, "T-link configuration fault".

T-link fault occurred

* Caused by T-link configuration fault

Check the station number where the fault occurred, using the program loader.

<Operation for D20>

Press the following key operation to call up the following screen.

AUX , F2 , F1 , NEXT
FRAME NEXT
FRAME
└──────────┘
7 times

FLAG (8/10)

F10 MENU

T-LK1 CONF/FAULT

	CONFIGURATION										FAULT														
	STA	NO.	0	1	2	3	4	5	6	7	8	9	STA	NO.	0	1	2	3	4	5	6	7	8	9	
F010		0													0*										F020
F011		10*													10										F021
F012		20*													20										F022
F013		30													30										F023
F014		40													40										F024
F015		50													50										F025
F016		60													60										F026
F017		70													70										F027
F018		80													80										F028
F019		90													90										F029

* Indicates the capsule with station No. 0 is not operating due to fault.

7.7.5 F0015 "Option fault" (Fatal fault)

Option fault occurs when an optional card incurs malfunction.

In this case, both the fatal fault flag (F0015) and the nonfatal fault flag (F0022) are set on. This fault also

occurs if a T-link optional card is removed (dislocated) or installed during processor operation, or if the card is missing (uninstalled) but optional card registration has been made.

7.7.6 F0018 "User program error"

This error occurs if a syntax error is detected in a user program.

Display the line on which the error occurred.

<Operation for D20>

Press the following key operation to call up the following screen.

AUX , F2 , F3

```

                USER PROGRAM ERROR (1/2)

CIRCUIT NO.      IMPORT OF ERROR
P001.0010       TIMER COUNTER DUPLICATE
    
```

Up to 8 errors are displayed at a time on a single screen. Pressing the **NEXT FRAME** displays the next screen. If there are more than 16 errors, error No. 17 and subsequent errors are displayed when the first 16 errors have been cleared. Correct the program according to the displayed error messages.

7.7.7 F0019 "WDT (Watch-dog timer) error"

The watchdog timer monitors 1 scan of the user program. This error occurs if 1 scan exceeds the WDT setting.

Monitor 1 scan time (execution speed).

<Operation for D20>

Press the following key operation to call up the following screen.

AUX , F5

```

SCAN TIME      MAX=0013   (MS)
                MIN=0011   (MS)

(PRESENT VALUE)
0011
0013
0011
0012
0011
0011
    
```

The maximum value is displayed.

The execution speed is displayed in realtime.

The watchdog timer is set to 1.5 times the normal execution speed. Confirm the execution speed and timer setting; if the timer setting is not appropriate,

correct it. (See "System Definition" in User's Manual <Instructions>.)

7.7 Diagnosis of Major Failures

7.7.8 F001A "Bus error"

This error occurs if an I/O card malfunction during processor operation.

■ Possible causes of the error

- (1) Contact failure between an I/O card and the processor connector, or falling off the card
- (2) I/O module malfunction
- (3) Empty slot between cards
- (4) Short-circuit in a processor bus line

Display the slot number where the error occurred.

<Operation for D20>

Press the following key operation to call up the following screen.

AUX , F2 , F5 , F5

DIRECT I/O FAULT (BUS ERROR) (F120)		F10 MENU
MONITORING		
SLOT NO.	ERR INF	
(-3 TIMES)		
(-2 TIMES)		
(-1 TIMES)		
(0 TIMES)	3	CONTROL SIGNAL ABNORMAL

7.7.9 F001C "I/O area duplication"

This error occurs if duplication of occupied address exists between the processor and the expansion unit or capsule on the T-link.


7.7.10 F001D "Too many capsules on T-link"

This error occurs if more than 32 expansion units or capsules are installed on the T-link.

7.7.11 F001E "Too many I/O addresses"

This error occurs if the occupied I/O word address exceeds 99 (WB99).


Example:



7.7 Diagnosis of Fatal Faults

7.7.12 F001F "Plant fault (Fatal fault)"

This fault occurs if one of the annunciator relays from A0000 to A000F is set on during execution of a user program.



7.7.13 F0690 "0 slot option fault (Fatal fault)"


(Only basic unit version 1001 or later)

This error occurs under the following conditions.

- If an optional card malfunction or if normal optional card is not installed with optional card registration made
- If a T-link optional card is removed (dislocated) or installed (T-link configuration modified) during processor operation
- If a T-link optional card is missing (uninstalled) with optional card registration made
In this case, both the fatal fault flag (F0015) and the nonfatal fault flag (F0022) are set on.



7.8 Diagnosis of Nonfatal Faults

7.8.1 Self-diagnosis of ALM2 nonfatal faults



If the **ALM2** LED indicator lights during processor operation, the self-diagnostic function of the CPU detects a nonfatal fault factor, and then stores the error information in the special relay (F).

■ Diagnosis flow



7.8 Diagnosis of Nonfatal Faults

7.8.2 F0022 "Option fault (Nonfatal fault)"

This fault occurs if an optional card malfunction.

7.8.3 F0026 "T-link configuration fault"

This fault occurs if the TK capsule is disconnected during processor operation, or if the contents of T-link registration do not match the actual T-link configuration of operating conditions that specified T-link registration.

The possible causes are as follows:

- ① A distributed I/O capsule fails during operation.
- ② An address other than the starting address of the I/O module (FTU type) installed on the same base as the T-link interface module (FTL type) is registered for T-link.

Only the address number set by the address setting dials on the FTL can be registered for T-link.

- ③ The I/O capsules and T-link interface card registered for T-link are not installed on the T-link.

- Notes:
1. Fault may occur ① during processor operation regardless of T-link registration. Fault ② and ③ may occur when the power is turned on.
 2. For T-link registration, all I/O capsules must be registered. If any of I/O capsules installed is not registered, it is ignored and is not accessible to the processor.

T-link configuration fault occurred.

Check the station number where the faults occurred, using the program loader.

<Operation for D20>

Press the **AUX**, **F2**, **F1**, **NEXT FRAME** **NEXT FRAME** keys to call the following screen.
└──────────┘
7 times

FLAG (8/10)		T-LK1 CONF/FAULT										F10 MENU													
		CONFIGURATION										FAULT													
		STA NO.	0	1	2	3	4	5	6	7	8	9	STA NO.	0	1	2	3	4	5	6	7	8	9		
F010	0												0*											F020	
F011	10*												10											F021	
F012	20*												20											F022	
F013	30												30											F023	
F014	40												40											F024	
F015	50												50											F025	
F016	60												60											F026	
F017	70												70											F027	
F018	80												80											F028	
F019	90												90											F029	


This indicates that the capsule of station No. 0 is inoperative (abnormal).

7.8 Diagnosis of Nonfatal Faults

■ FTL unit fault


The following describes the procedure to detect the cause of an FTL unit fault.

< Example system configuration >




Example of FTL unit faults


① Overloading on the FTL module 24V DC power supply




② Power supply for FTL module disconnected




⑤ FTL fault



③ I/O module fault




④ Dislocation of the I/O module from the base




ALM2 nonfatal fault

If any of the above occurs when fail-soft operation setting is specified for the processor, the ALM2 LED indicator of the processor and the ALM1 LED indicator of the FTL module light.

Under operating conditions without fail-soft operation, the ALM1 LED indicator of the processor also lights, and the processor stops operation.



In this case, execute diagnosis using the D20 and press the following key operation to call up the screen shown on next page.



7.8 Diagnosis of Nonfatal Faults

FLAG (3/11)		NONFATAL FAULT CONDITION		F10 MENU
F002				
	0	BATTERY ERROR		8
	1			9
	2			A
	3			B
	4	T-LINK FAULT		C
	5	P-LINK FAULT		C
F0026 "T-LINK CONFIGURATION FAULT"	6*	T-LINK CONFIGURATION FAULT		E LONG EXECUTING CYCLE
	7	P-LINK CONFIGURATION FAULT		F PLANT FAULT

The T-link configuration information (T-link configuration fault) in the above screen shows the failed address of the FTL unit. Press the **NEXT FRAME** key on the D20 5 times to call up the following screen. The faulty location can be easily identified because an asterisk (*) is displayed

at the faulty T-link address of the FTL unit. However, this screen does not indicate the cause of the fault (FTL module fault or I/O module fault). To investigate the cause of the FTL unit fault in detail, use "F4 T-link fault" from the diagnosis screen above.

FLAG (8/10)		T-LK1 CONF/FAULT		F10 MENU
		CONFIGURATION		FAULT
	STA NO.	0 1 2 3 4 5 6 7 8 9	STA NO.	0 1 2 3 4 5 6 7 8 9
F010	0		0	F020
F011	10		10	F021
F012	20		20*	F022
F013	30*		30	F023
F014	40		40*	F024
F015	50		50	F025
F016	60		60	F026
F017	70		70	F027
F018	80		80	F028
F019	90		90	F029

← The T-link station No. indicates the faulty capsule.
 ← This indicates that the FTL that has T-link station No. 40 has a fatal fault.

7.8 Diagnosis of Nonfatal Faults

7.8.4 F0029 "Direct I/O fault"


This fault occurs if an I/O error occurs during processor operation, or if an I/O connector is disconnected.

7.8.5 F002E "Program slow-down"

This fault occurs if the wait count of the fixed-cycle program (PROG50) exceeds 32. (This fault occurs during scan.)

7.8.6 F002F "Plant fault (Nonfatal fault)"

This fault occurs if one of the annunciator relays from A0010 to A003F is set on during execution of a user program.



Perform the system start procedure defined by the user program.

When the input conditions are not met, annunciator relays A0010 to A003F go off and the ALM2 LED indicator lights.

Section 8 Maintenance and Inspection

	Page
8.1 General Inspection Notes	8-2
8.2 Battery Replacement	8-4
8.3 Maintenance Services	8-5

Section 8 Maintenance and Inspection

8.1 General Inspection Items

For use of the MICREX-F series under the best operating conditions, periodic inspection must be performed.

(1) Inspection frequency

The MICREX-F series is a highly-reliable programmable controller, consisting mainly of semiconductor devices. However, because deterioration of devices may occur due to environmental conditions, periodic inspection is recommended. The standard inspection should be

done once or twice a year; however, it can be shorter, depending on environmental conditions.

If any inspection result does not match the rated value, check the operating conditions to make sure they are appropriate.

(2) Cautions on using the product

CAUTION

- Select a wire size to suit the applied voltage and carrying current, and carry out wiring according to the operating instructions and manual. Poor wiring might cause fire.
- Operate (keep) in the environment specified in the operating instructions and manual. High temperature, high humidity, condensation, dust, corrosive gases, oil, organic solvents, excessive vibration or shock might cause electric shock, fire, erratic operation or failure.
- Contaminants, wiring chips, iron powder or other foreign matter must not enter the device when installing it, otherwise, erratic operation or failure might occur.
- Periodically make sure the terminal screws and mounting screws are securely tightened.

8.1 General Inspection Notes

(3) Inspection items

When inspecting the MICREX-F series, use the following inspection table.

Inspection item	Inspection contents	Criteria	Inspection method
Basic unit ALARM lamps	Confirmation of ALARM lamps	Lamps must be OFF.	Visual inspection
Basic unit power supply	Voltage	Is the voltage within the normal range when measured at a terminal block? AC: -15 to +10% DC: -15 to +20%	Voltmeter
	Voltage fluctuation	Are there frequent momentary power failures or abrupt voltage rises or drops? Voltage fluctuations must be within the above range	Oscilloscope
FTK capsule power supply	Voltage	Is the voltage within the normal range when measured at a terminal block? AC: -15 to +10% DC: -15 to +20%	Voltmeter
	Voltage fluctuation	Are there frequent momentary power failures or abrupt voltage rises or drops? Voltage fluctuations must be within the above range.	Oscilloscope
Ambient environment	Temperature	Is the temperature within the specified range? (temperature in the panel when installed inside the panel) 0°C to +55°C	Max./min. thermometer
	Humidity	Is there condensation or extreme discoloration or corrosion? 20% to 90%RH	Visual inspection, hygrometer
	Vibration	Is there any vibration? There must be no vibration.	Check by touching
	Dust	Is there any dirt or other foreign matter? There should be no dirt or other foreign matter.	Visual inspection
Installation status	Are all cards mounted securely?	No looseness	Screwdriver
	Are there any loose screws on the external wiring terminals?	No looseness	Screwdriver
	Are cable connectors inserted securely?	No looseness	Visual inspection
	Are any external wiring cables damaged?	No abnormal appearance	Visual inspection
Battery	Is it time to replace the battery?	Indication on battery effectiveness label	Visual inspection
Spare parts	Is the designated quantity available? Are storage conditions appropriate?	See the inspection records.	
Program	Were any errors detected through verification?	There must be no errors.	Program verification

- If a fault occurs, replace the entire faulty unit, capsule or module. For this replacement, a minimum amount of spare components should be provided.
- Battery voltage drops even when not being used because of slight self-discharging. Replace old batteries with new ones before their effective service life expires.

8.2 Battery Replacement

Replace the battery with a new one at the determined replacement time even if the battery alarm is not indicated. (The device can ignore the battery alarm for about one week without harmful effects. However, the user should not ignore this alarm status.)

- (1) Replacement time: Data indicated on battery (effective service life)
- (2) Type of replacement battery: NL8V-BT (FBT030A)

■ Precautions

- (1) Do not short across the battery.
- (2) Do not discard in a fire.
- (3) Do not attempt to recharge the battery.
- (4) Do not disassemble the battery.

■ Battery replacement procedure

- (1) Turn OFF the processor control power. (Battery can be replaced without disconnecting the control power supply.)
- (2) Open the cover.
- (3) Remove the battery connector and then remove the old battery by loosening the screws that fix the battery holder. Insert a new battery and secure it. Replace quickly (within 5 minutes). If the processor is left without battery for a long period, user programs will be lost.
- (4) Close the cover.
- (5) Turn ON the processor control power.

8.3 Maintenance Services

■ Information on ordering and maintenance services for electrical and control equipment

1. Ordering notes

When ordering electrical and control equipment (or requesting price estimates), the following general notes are to be observed, unless otherwise specified in the estimation paper, contract paper, catalogs, or specifications.

2. Warranty period and scope of warranty

[Warranty period]

This product is covered by a warranty for a period of one year from the date of delivery to the location specified by the customer.

[Scope of warranty]

During the warranty period, if any failure judged to be the responsibility of the manufacturer occurs, replacement and repair of defective parts are performed under the responsibility of the manufacturer.

This warranty does not cover the following failures:

3. Service costs

The price of the product does not include maintenance and servicing costs, such as the cost of dispatching an engineer to the customer. The customer will be charged for actual expenses in the following cases.

When the product is delivered, check the contents of the package as soon as possible. Even before inspection, use caution on storing and using the product safely.

- (1) Failures caused by improper handling or misuse by the customer
- (2) Failures caused by something other than the delivered product itself
- (3) Failures caused by modification or repair performed by someone other than the manufacturer
- (4) Failures caused by natural calamities or environmental disruption

This warranty covers only the product itself; it does not cover any damages resulting from failures of the product.

- (1) Guidance for installation and adjustment, and attendance at a test operation
- (2) Maintenance, inspection, adjustment, and repair
- (3) Technical guidance and technical education

Fuji Electric Co., Ltd.

Gate City Ohsaki, East Tower,
11-2, Osaki 1-chome, Shinagawa-ku, Tokyo 141-0032, Japan

E-mail: micrex-sx@fujielectric.co.jp
URL: <http://www.fujielectric.com/>