

SIEMENS

SICAM AI Unit (20-mA Input Acquisition Device)

7XV5674

Device Manual

Preface

Open Source Software

Contents

User Information

1

Overview

2

Device Design

3

Measurands

4

Getting Started

5

Connection Principle

6

Operation

7

Time Synchronization

8

Communication

9

Calibration

10

Maintenance, Storage, Transport

11

Failures and LED Indications

12

Technical Data

13

Operational Indications

14

Operating Parameters

15

Glossary

Index

E50417-G1140-C492-A2



NOTE

For your own safety, please observe the warnings and safety instructions contained in this document.

Disclaimer of Liability

This document has been subjected to rigorous technical review before being published. It is revised at regular intervals, and any modifications and amendments are included in the subsequent issues. The content of this document has been compiled for information purposes only. Although Siemens AG has made best efforts to keep the document as precise and up-to-date as possible, Siemens AG shall not assume any liability for defects and damage which result through use of the information contained herein.

This content does not form part of a contract or of business relations; nor does it change these. All obligations of Siemens AG are stated in the relevant contractual agreements.

Siemens AG reserves the right to revise this document from time to time.

Document release E50417-G1140-C492-A2.00
Edition 12.2014
Product version: V1.10

Copyright

Copyright © Siemens AG 2014. All rights reserved.
The disclosure, duplication, distribution and editing of this document, or utilization and communication of the content are not permitted, unless authorized in writing. All rights, including rights created by patent grant or registration of a utility model or a design, are reserved.

Registered Trademarks

SIPROTEC® and SICAM® are registered trademarks of SIEMENS AG. An unauthorized use is illegal.

All other designations in this document can be trademarks whose use by third parties for their own purposes can infringe the rights of the owner.

Preface

Purpose of this Manual

This manual describes the application, functions, installation, commissioning and operation of the SICAM AI Unit 7XV5674.

Target Group

This manual is intended for project engineers, commissioning and operating personnel in electrical systems and power plants.

Scope of Validity of this Manual

This manual is valid for the SICAM AI Unit 7XV5674.

Further support

You find current information (e.g. new features and modifications) about the SICAM AI Unit in the readme file:

<https://w3.siemens.com/smartgrid/global/en/products-systems-solutions/Protection/accessories/input-output-devices/Pages/7XV5674.aspx#>

For any questions concerning your system, please contact your Siemens representative.

Our Energy Customer Support Center provides around-the-clock support.

Phone: +49 (1805) 24-7000

Fax: +49 (1805) 24-2471

Internet: <http://www.siprotec.com>

e-mail: support.energy@siemens.com

Training courses

If you are interested in our current training program, please contact our training center:

Siemens AG

Siemens Power Academy TD

Humboldtstr. 59

D-90459 Nuremberg

Tel.: +49 (911) 433-7415

Fax: +49 (911) 433-7929

e-mail: poweracademy@siemens.com

Internet: <http://www.siemens.com/poweracademy>

Notes On Safety

This manual does not constitute a complete catalog of all safety measures required for operating the equipment (module, device) in question, because special operating conditions may require additional measures. However, it does contain notes that must be adhered to for your own personal safety and to avoid damage to property.

These notes are highlighted with a warning triangle and different keywords indicating different degrees of danger.



DANGER

Danger means that death or severe injury **will** occur if the appropriate safety measures are not taken.

- ✧ Follow all advice instructions to prevent death or severe injury.
-



WARNING

Warning means that death or severe injury **can** occur if the appropriate safety measures are not taken.

- ✧ Follow all advice instructions to prevent death or severe injury.
-



CAUTION

Caution means that minor or moderate injury can occur if the appropriate safety measures are not taken.

- ✧ Follow all advice instructions to prevent minor injury.
-

NOTICE

Notice means that damage to property can occur if the appropriate safety measures are not taken.

- ✧ Follow all advice instructions to prevent damage to property.
-



NOTE

is important information about the product, the handling of the product, or the part of the documentation in question to which special attention must be paid.

Personnel Qualified in Electrical Engineering

Commissioning and operation of the equipment (module, device) described in this manual must be performed by personnel qualified in electrical engineering only. As used in the safety notes contained in this manual, electrically qualified personnel are those persons who are authorized to commission, release, ground and tag devices, systems, and electrical circuits in accordance with safety standards.

Use as Prescribed

The equipment (device, module) must not be used for any other purposes than those described in the Catalog and the Technical Description. If it is used together with third-party devices and components, these must be recommended or approved by Siemens.








If the device is not used in accordance with the Product Information and this manual, the scheduled protection is impaired.

Correct and safe operation of the product requires adequate transportation, storage, installation, and mounting as well as appropriate use and maintenance.


During the operation of electrical equipment, it is unavoidable that certain parts of this equipment will carry dangerous voltages. Severe injury or damage to property can occur if the appropriate measures are not taken:

- Before making any connections at all, ground the equipment at the PE terminal.
- Hazardous voltages can be present on all switching components connected to the power supply.
- Even after the supply voltage has been disconnected, hazardous voltages can still be present in the equipment (capacitor storage).
- Equipment with current transformer circuits must not be operated while open.
- The limit values indicated in the manual and the Product Information must not be exceeded; this also refers to testing and commissioning.


Used Symbols

No.	Symbol	Description
1		Direct current IEC 60417-5031
2		Alternating current IEC 60417-5032
3		Direct current and alternating current IEC 60417-5033
4		Earth (ground) terminal IEC 60417-5017
5		Protective conductor terminal IEC 60417-5019
6		Caution, risk of electric shock
7		Caution, risk of danger ISO 7000-0434

Statement of Conformity

	<p>This product complies with the directive of the Council of the European Communities on the approximation of the laws of the Member States relating to electromagnetic compatibility (EMC Council Directive 2004/108/EC) and concerning electrical equipment for use within specified voltage limits (Low-voltage Directive 2006/95/EC).</p> <p>This conformity has been established by means of tests conducted by Siemens AG according to the Council Directive in agreement with the generic standards EN 61000-6-2 and EN 61000-6-4 for the EMC directives, and with the standard EN 61010-1 for the low-voltage directive.</p> <p>The device has been designed and produced for industrial use.</p> <p>The product conforms to the standard EN 60688.</p>
---	--

Further Standards

<p>This product is UL-certified to Standard UL 61010-1, 3rd edition, based on the specification stated in chapter 13.1 (Technical Data). UL File No.: E228586.</p>	
	<p>Open-type Measuring Equipment 2UD1</p>

For further information see UL database on the internet: <http://ul.com>.

Chose **Online Certifications Directory** and insert E228586 under **UL File Number**.



Open Source Software

The product contains, among other things, Open Source Software developed by third parties. The Open Source Software used in the product and the license agreements concerning this software can be found in the `Readme_OSS`.

These Open Source Software files are protected by copyright. Your compliance with those license conditions will entitle you to use the Open Source Software as foreseen in the relevant license. In the event of conflicts between Siemens license conditions and the Open Source Software license conditions, the Open Source Software conditions shall prevail with respect to the Open Source Software portions of the software.

The Open Source Software is licensed royalty-free. Insofar as the applicable Open Source Software License Conditions provide for it you can order the source code of the Open Source Software from your Siemens sales contact - against payment of the shipping and handling charges - for a period of at least 3 years since purchase of the Product. We are liable for the Product including the Open Source Software contained in it pursuant to the license conditions applicable to the Product. Any liability for the Open Source Software beyond the program flow intended for the Product is explicitly excluded. Furthermore any liability for defects resulting from modifications to the Open Source Software by you or third parties is excluded. We do not provide any technical support for the Product if it has been modified.

Contents

- Preface** **3**
- Open Source Software** **9**
- 1 User Information** **15**
- 2 Overview** **17**
 - 2.1 Versions of SICAM AI Unit 7XV5674 18
 - 2.2 Ordering Information, Scope of Delivery and Accessories 20
- 3 Device Design** **23**
 - 3.1 Mechanical Design 24
 - 3.2 Electrical Design 25
- 4 Measurands** **27**
 - 4.1 General 28
 - 4.2 Measurands and Calculated Measurands 28
 - 4.3 Measuring Times 28
- 5 Getting Started** **29**
 - 5.1 Unpacking, Inspecting the Delivery and Installing the Battery 30
 - 5.2 Assembly 32
 - 5.2.1 General Assembly Notes 32
 - 5.2.2 Assembly 33
 - 5.3 Electrical Connection 34
 - 5.3.1 Safety Notes 34
 - 5.3.2 Electrical Connection of SICAM AI Unit 35
 - 5.4 System Requirements 36
 - 5.5 Access Rights 37
 - 5.6 Description of the LEDs 38
 - 5.7 Commissioning 39
 - 5.7.1 Initial Commissioning 39
 - 5.7.2 Changes During Operation 40
 - 5.7.3 Starting the Device with the Default IP Address 41
- 6 Connection Principle** **43**
 - 6.1 Terminals 44
 - 6.2 Communication Interfaces 47
 - 6.2.1 Ethernet Interface 47
 - 6.2.2 Serial Interface 47
 - 6.3 Connection Type 48

7	Operation	49
7.1	General Usage Notes	50
7.2	Start and Design of the User Interface	51
7.2.1	Initial Start of the User Interface	51
7.2.2	Enabling JavaScript	52
7.2.3	Number of Connections via HTML	53
7.2.4	Layout of the User Interface	54
7.2.5	Starting the User Interface during Operation	55
7.3	Configuration of the Device	62
7.3.1	Device Configuration Procedure	62
7.3.2	Access to the Passive Set of Parameters by Multiple Users	69
7.3.3	Setting the Operational Parameters	70
7.3.4	Setting Administrative Parameters	79
7.4	Value View	100
7.5	Maintenance	101
7.5.1	Firmware Upload	102
7.5.2	Calibration	104
7.5.3	Simulation	104
7.5.4	GOOSE	107
7.5.5	Presettings	108
7.5.6	Message Logs	109
7.5.7	Diagnosis	111
8	Time Synchronization	115
8.1	General	116
8.2	Internal Time Keeping	116
8.2.1	Time Format	116
8.2.2	Status Bits	116
8.3	External Time Synchronization via Ethernet NTP	117
8.4	External Time Synchronization via Fieldbus	118
8.5	Internal Time Synchronization via RTC	118
9	Communication	119
9.1	Communication Features	120
9.1.1	Ethernet Communication	120
9.1.2	Serial Communication	123

9.2	Modbus	126
9.2.1	Modbus Functions	126
9.2.2	Exception Responses	127
9.2.3	Modbus TCP	128
9.2.4	Modbus UDP	129
9.2.5	Modbus RTU	130
9.2.6	Register Assignment	131
9.2.7	Data Types	131
9.2.8	Data in the Modbus Registers (Data Mapping)	134
9.2.9	Modbus Diagnosis	139
9.3	SIPROTEC RTU 20 mA	142
9.3.1	Diagnosis SIPROTEC RTU 20 mA	142
9.4	IEC 61850	143
9.4.1	General I/O Processes	143
9.4.2	Diagnosis IEC 61850	147
10	Calibration	149
10.1	General	150
10.2	Calibrating the Direct-Current Measuring Range	151
11	Maintenance, Storage, Transport	155
11.1	Maintenance	156
11.2	Storage	156
11.3	Transport	156
12	Failures and LED Indications	157
12.1	General Inspection	158
12.2	Commissioning during Failures	159
12.2.1	Automatic Start of the Boot Loader	159
12.2.2	Manual Start of the Boot Loader	160
12.3	Indications Signaled by LEDs	161
12.4	Troubleshooting and Repair	165
13	Technical Data	167
13.1	General Device Data	168
13.1.1	Power Supply	168
13.1.2	Inputs and Outputs	169
13.1.3	Communication Interfaces	169
13.1.4	Environmental Data	172
13.1.5	General Data	172
13.2	Test Data	173
13.2.1	Electrical Tests	173
13.2.2	Mechanical Stress Tests	175
13.2.3	Climatic Stress Tests	176
13.2.4	Safety Standards	176
13.3	Dimensions	177

14	Operational Indications	179
15	Operating Parameters	183
15.1	Process Connections	184
15.1.1	20-mA Inputs	184
15.1.2	LEDs	186
15.2	Automation Functions	187
15.3	Administrative	189
15.3.1	Time Synchronization	189
15.3.2	Ethernet Communication	190
15.3.3	Communication Serial	192
15.3.4	Device and Language	194
	Glossary	195
	Index	199

1 User Information

Application

The SICAM AI Unit 7XV5674 is used for the acquisition of analog signals from automation processes and transmission of measured values to a connected supervisory system or control center over communication protocol.

The SICAM AI Unit 7XV5674 can support diverse applications. For acquiring DC field signals, SICAM AI Unit 7XV5674 can be applied in the following application fields:

- Protection
- SCADA
- DMS
- EMS systems
- GIS (Gas Insulated Switchgear) - gas pressure monitoring
- Other industrial processes

For example 4-mA to 20-mA signals coming from transducers (for example for monitoring of: power, temperatures, pressure, and position) are delivered over standard protocol for further processing, as visualization or connection to other automation processes.

The DC inputs from SICAM AI Unit 7XV5674 can be parametrized to support the following ranges:

- DC 0 mA to 20 mA
- DC 4 mA to 20 mA

The measuring accuracy amounts to 0.2 % of the rated value (20 mA) under reference condition (see chapter 13.2). The measuring accuracy amounts to 1.0 % of the rated current (20 mA) under environmental impact.

The integrated Web server allows you to configure the parameters via HTML pages using a Web browser.

Measurands

Only direct currents are measured with SICAM AI Unit. The measurement cycles on the board 1 and board 2 are carried out simultaneously. A complete measurement cycle amounts to 642 ms for 6 channels. The measurement of one channel amounts to 107 ms and is repeated after 642 ms (see chapter 4).

For more detailed information on the measurands and measuring ranges, refer to chapter 4.2.

Communication

To communicate with the control center and other peripheral devices, the device features an Ethernet interface and optionally a serial interface (RS485 or optical).

Via Ethernet, the following functions are supported:

- Device parameterization
- Transmission of measured data
- Transmission of indications
- Time synchronization via NTP

The communication protocols are HTTP and Modbus TCP or IEC 61850.

The serial interface as RS485 or optical interface supports the following functions:

- Transmission of measured data
- Transmission of indications
- Time synchronization via fieldbus

Depending on the device version, you can use either the Modbus RTU or the SIPROTEC RTU 20 mA communication protocol.



NOTE

The communication protocol SIPROTEC RTU 20 mA is only supported by SIPROTEC 4.

With the Ethernet switch that is integrated in the device, further network components can be cascaded via a Y cable, and can therefore also be incorporated in an existing network with IEC 61850 or another Ethernet protocol.

Time Synchronization

During operation SICAM AI Unit needs the date and time for all time-relevant processes. This ensures that a common time basis exists when communicating with peripheral devices and enables time stamping of the process data. The following types of time synchronization can be executed:

- External time synchronization via Ethernet NTP (preferred)
- External time synchronization via fieldbus using the Modbus RTU communication protocol
- Internal time synchronization via RTC (if external time synchronization is not available)

Parameterization

No special software is needed for parameterization. You can set the parameters from your computer via HTML pages and a Web browser. Internet Explorer 6 (or higher) is necessary for this purpose.

2 Overview

2.1	Versions of SICAM AI Unit 7XV5674	18
2.2	Ordering Information, Scope of Delivery and Accessories	20

2.1 Versions of SICAM AI Unit 7XV5674

Basic Version (Minimum Equipment)

The SICAM AI Unit 7XV5674 is used for the acquisition of analog signals from automation processes and for the transmission of measured values to a connected supervisory system or control center over communication protocol. The modules of the device detect, calculate, analyze and transmit measured values. In the basic version, the device is characterized as follows:

Device type:

- DIN rail mounted device
- Plastic case 96 mm x 96 mm x 100 mm (W x H x D)
- Protection class IP20

Input and output circuits:

- Twelve 20-mA inputs for direct-current measurements

Communication:

- Via Ethernet

Variants

SICAM AI Unit is available in various variants:

- Serial interface
 - Without serial interface
 - With RS485 interface
 - With optical interface
- Communication if RS485 or optical interface exists
 - With Modbus RTU protocol and SIPROTEC RTU 20 mA protocol
- Communication via Ethernet
 - With integrated Ethernet switch: Modbus TCP protocol
 - With integrated Ethernet switch: Modbus TCP protocol and IEC 61850 protocol


SICAM AI Unit Variants



SICAM AI Unit with DC Inputs and RS485 Interface (D-sub Socket)



SICAM AI Unit with DC Inputs and Optical Interface (ST connector)



SICAM AI Unit with DC Inputs without serial Interface

Fig. 2-1 SICAM AI Unit Variants

2.2 Ordering Information, Scope of Delivery and Accessories

Ordering Information

Use the following ordering code to order the SICAM AI Unit 7XV5674:

Description	Order No. / MLFB																																
SICAM AI Unit																																	
	<table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td><td>11</td><td>12</td><td>13</td><td>14</td><td>15</td><td>16</td> </tr> <tr> <td>7</td><td>X</td><td>V</td><td>5</td><td>6</td><td>7</td><td>4</td><td>-</td><td>0</td><td>K</td><td>K</td><td>0</td><td>-</td><td>A</td><td>A</td><td>1</td> </tr> </table>	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	7	X	V	5	6	7	4	-	0	K	K	0	-	A	A	1
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16																		
7	X	V	5	6	7	4	-	0	K	K	0	-	A	A	1																		
Device type																																	
12 x 20-mA inputs for SIPROTEC devices DIN rail mounting, protection class IP20 Case 96 mm x 96 mm x 100 mm Power supply: DC 24 V to 240 V AC 100 V to 230 V Integrated Web server Ethernet port RJ45 and integrated Ethernet switch UL listing																																	
Serial interface and communication protocol																																	
Without serial communication	0																																
RS485 interface Serial Modbus RTU and SIPROTEC 20 mA protocol point to point connection	3																																
FO interface 820 nm, ST connector Serial Modbus RTU and SIPROTEC 20 mA protocol point to point connection	4																																
Ethernet interface and communication protocol																																	
Ethernet interface with Modbus TCP/UDP	1																																
Ethernet interface with Modbus TCP/UDP and IEC 61850 (GOOSE and Server)	2																																

Fig. 2-2 Ordering Code for SICAM AI Unit 7XV5674

Scope of Delivery

The delivery comprises the following components depending on the ordering code:


- SICAM AI Unit 7XV5674 according to ordering code (see Figure 2-2)
- Battery (insulated in the battery compartment of the device)
- Product Information E50417-B1050-C541

Accessories

The following components are optionally available:



- Device Manual E50417-G1140-C492 (download available at www.siprotec.de)
- Y cable, order no. 7KE6000-8GD00-0BA2
- Ethernet patch cables (CAT6)
- RS485 cables for SIPROTEC devices according to Table 2-1:

Table 2-1 Standard RS485 Cables

Standard RS485 Cable	Cable Length	Order Number
	Maximum 1000 m (minimal order quantity 20 m)	6XV1 830-0EH10
	Length preferred 20 m	6XV1 830-0EN20
	Length preferred 50 m	6XV1 830-0EN50
	Length preferred 100 m	6XV1 830-0ET10
	Length preferred 200 m	6XV1 830-0ET20

- RS485 bus connectors for SIPROTEC devices according to Table 2-2:

Table 2-2 RS485 Bus Connectors

RS485 Bus Connector	Description	Order Number
	SIMATIC DP, bus connector with tilted cable outlet, 15.8 mm x 54 mm x 39.5 mm (WXHxD), terminating resistor with isolating function, without PG socket	6ES7972-0BA42-0XA0
	SIMATIC DP, bus connector with tilted cable outlet, 15.8 mm x 54 mm x 39.5 mm (WXHxD), terminating resistor with isolating function, with PG socket	6ES7972-0BB42-0XA0

- Ordering information for ready to use fiber-optic cables (fiber-optic cable) is available on the Internet (SIPROTEC download area) under <http://www.siprotec.com> under accessories -> 6XV81xx.
- Further notes on device accessories and their environment can be found under <http://www.siprotec.com>.

3 Device Design

3.1	Mechanical Design	24
3.2	Electrical Design	25

3.1 Mechanical Design

The electrical modules are installed in a plastic case with the dimensions 96 mm x 96 mm x 100 mm (W x H x D). The case is prepared for mounting on a DIN rail.

The top side of the device accommodates the RJ45 Ethernet connector with 2 LEDs and 4 additional LEDs. At the cover of the battery compartment there is a labeling strip for the configurable LEDs H1/H2/ERROR and a battery symbol that indicates the polarity. The name plate is also located on the top side and provides among other information the most important rated data of the device. A lithium battery is located under the removable cover of the battery compartment.

The terminals for connecting all inputs, for the supply voltage and the protective grounding are located on the terminal side. The number, type and position of the terminals differs according to device version and is described in detail in chapter 5.3. According to the ordering information (see chapter 2.2), SICAM AI Unit can also be equipped with a D-sub socket as RS485 interface (see Figure 3-1).

The snap-in unit is mounted in the center of the DIN rail side. The IP Addr. push-button is located in the lower right corner of the DIN rail side. Pressing it (> 3 s) activates the factory-set default IP address. The default IP address and the default subnet mask are imprinted on the side panel.




Fig. 3-1 Design of the SICAM AI Unit

3.2 Electrical Design

SICAM AI Unit contains the following electrical modules depending on the device version:

- Digital signal processor (DSP)
- Twelve 20-mA inputs for direct-current measurements
- Supply voltage
- Serial interface (RS485 or optical according to order version)
- Ethernet interface with integrated Ethernet switch




Fig. 3-2 Block Diagram SICAM AI Unit

4 Measurands

4.1	General	28
4.2	Measurands and Calculated Measurands	28
4.3	Measuring Times	28

4.1 General

SICAM AI Unit offers twelve 20-mA inputs referring to the standard IEC 60688. The 20-mA inputs are divided in 2 groups, on 2 boards each with 6 channels.

4.2 Measurands and Calculated Measurands

Measurands	Measuring Range	Tolerance Limits ¹⁾
Channel 1 to 12 (current measurement)	0 mA to 20 mA 4 mA to 20 mA	± 0.2 %
Channel 1 to 12 (overdriving inputs)	-0.2 mA to 20.2 mA 3.8 mA to 20.2 mA	

- 1) Tolerance limits referred to the rated current under reference conditions (see Chapter 13.2)
The measuring accuracy amounts to 1.0 % of the rated current (20 mA) over the full range of operating conditions including EMC.

Calculated Measurands	Measuring Range
Channel 1 to 12 (10 s mean value) ¹⁾	0 mA to 20 mA 4 mA to 20 mA
Channel 1 to 12 (1 min mean value) ²⁾	0 mA to 20 mA 4 mA to 20 mA
Channel 1 to 12 (1 h mean value) ³⁾	0 mA to 20 mA 4 mA to 20 mA
Channel 1 to 12 (24 h mean value) ⁴⁾	0 mA to 20 mA 4 mA to 20 mA

- 1) The mean-value range begins always to the full 10 s.
2) The mean-value range begins always to the full 1 min.
3) The mean-value range begins always to the full 1 h.
4) The mean-value range begins always at 0 o'clock device time.

4.3 Measuring Times

The measurement cycles on the board 1 and board 2 are carried out simultaneously. A complete measurement cycle amounts to 642 ms for 6 channels. The measurement of one channel amounts to 107 ms and is repeated after 642 ms.

5 Getting Started

5.1	Unpacking, Inspecting the Delivery and Installing the Battery	30
5.2	Assembly	32
5.3	Electrical Connection	34
5.4	System Requirements	36
5.5	Access Rights	37
5.6	Description of the LEDs	38
5.7	Commissioning	39

5.1 Unpacking, Inspecting the Delivery and Installing the Battery

Unpacking

The 7XV5674 has been safely packed for transport in the factory. Unpack the device with care and do not use force. Use an appropriate tool if necessary. After unpacking, inspect the device visually for any mechanical defects.



NOTE

If the device has been damaged during transport, do not connect and operate it.

Observe any additional notes enclosed with the packaging.

Keep the transport packaging for future transport.

Inspecting the Delivery

After unpacking, first compare the packing list against your original purchase order to check that the delivered device has the desired rated data and functions and that all necessary and ordered accessories are enclosed.

Installing the Battery

If you want to operate the device immediately after the delivery, first insert the battery before beginning the installation. Upon delivery the battery is insulated in the battery compartment of the device.

If you want to operate the device later, insert the battery only just before you intend to use the device.



NOTE

The battery powers the battery-buffered memory (SRAM) and the real-time clock (RTC). But the device can still be operated when no battery is inserted or when the battery is discharged. If, however, the supply voltage is lost, all metered energy values and error reports are deleted and the real-time clock is reset (2000-01-01 00:00).

Customer-specific parameters are permanently stored in the Flash-EEPROM even without a battery.

To insert the battery, observe the notes in the supplied Product Information E50417-B1050-C541 and proceed as follows:

- ◇ Lever the cover of the battery compartment out of the socket with a suitable tool (e.g. precision engineer screwdriver 2.0 mm).




Fig. 5-1 Top Side of the SICAM AI Unit

- ✧ Take the wrapped battery out of the battery compartment.
- ✧ Remove the plastic foil from the battery.
- ✧ Insert the battery into the battery compartment with the polarity imprinted on the top side of the device (see Figure 5-1).
- ✧ Close the cover of the battery compartment.

**NOTE**

For additional information on replacing used battery, refer to the product information (component of the device delivery).

Information on battery life can be found in 13.1.5.

**WARNING**

Warning of incorrect treatment of the lithium battery (type PANASONIC CR2032 or VARTA 6032 101 501) or the use of an incorrect battery type. In the case of incorrect treatment or the wrong battery type, the battery may burn, explode or trigger a chemical reaction.

See product information for type of battery to be used.

Non-observance may lead to death or serious injury.

- Installing the battery or replacing it may only be carried out by trained personnel (see preface) who are familiar with and observe the safety requirements and precautions.
 - Do not reverse the polarity of the battery.
 - Do not attempt to open the battery.
 - Do not attempt to recharge the battery.
 - Servicing of the circuitry involving the batteries and replacement of the lithium batteries shall be done by a trained technician.
 - Replace battery with VARTA 6032 101 501 or PANASONIC CR2032 only. Use of another battery may present a risk of fire or explosion. See manual for safety instructions.
 - Caution: The battery used in this device may present a fire or chemical burn hazard if mistreated. Do not recharge, disassemble, heat above 100 °C (212 °F) or incinerate.
 - Dispose of used battery promptly. Keep away from children.
-

5.2 Assembly

5.2.1 General Assembly Notes

SICAM AI Unit is intended to be installed on a DIN rail, e.g. in a control cabinet.



WARNING

Warning: do not touch any voltage-carrying parts

Non-observance may lead to death or serious injury.

- ◇ After installation of the device and wiring, close the control cabinet.



NOTE

For operating heights > 2000 m, a reduction of the test voltages according to IEC 60255-5 / 60870-2-1 is necessary.

-
- The installation site must be vibration-proof. The permitted ambient temperature must be observed (see the technical data in 13).
 - Operating the device outside the permitted operating temperature range can lead to measuring errors and device failure.
 - The terminal of the supply voltage is designed for conductor cross-sections of 1.5 mm² (AWG 16) to 2.5 mm² (AWG 14) max.
 - The terminal of the 20-mA inputs (T) and (Q) are designed for conductor cross-sections of 0.2 mm² (AWG 24) to 1.5 mm² (AWG 16) max (see also Terminals).
 - The device must not be exposed to condensation during operation.
 - The device must be installed in a location where it is not exposed to direct sunlight and strong temperature variations.

5.2.2 Assembly

Mount the SICAM AI Unit to a DIN rail according to EN 60750 in the following way:




Fig. 5-2 Mounting on a DIN Rail

- ✧ Pull down the release device at the snap-in clip and hold it in this position.
- ✧ Slide the device with the guiding of the snap-in clip onto one side of the DIN rail.
- ✧ Move the device into the desired position on the DIN rail.
- ✧ Release the release device. The device is now firmly mounted on the DIN rail.



NOTE

The snap-in clip is adjusted to a certain height setting by the manufacturer. You can change this setting if necessary. To do so, lever the release device out of its guiding (no special tool required) and move the release device into the desired position. Subsequently, press the release device back into its guiding.

UL-certification Conditions

Field Wires of Control Circuits shall be separated from other circuits with respect to the end use requirements!

5.3 Electrical Connection

5.3.1 Safety Notes

**DANGER**


Hazard due to high voltage

Non-observance will lead to death or serious injury.

- Work may only be carried out by trained personnel (see Preface) who are familiar with and observe the safety requirements and precautions.
- Work may never be carried out if there is any dangerous voltage present.
- Deenergize the device.
- **Circuit breaker:** A suitable isolating device shall be connected upstream in order to permit disconnection of the device from the power supply. The circuit breaker must be mounted close to the device, be easily accessible to the user and marked as a circuit breaker for the device.
- Secure the supply voltage with an approved (UL/IEC) fuse: 1.6 A, type C.
- If a melting fuse is used, a suitable approved (UL/IEC) fuse holder has to be used.

**NOTE**

For electrical installations you have to observe and comply with the national and international provisions concerning the installation of electrical power installation and the low voltage directive 2006/95/EG.

- Before commissioning the device, you have to check that all connections are made properly.
- Connect the protective grounding terminal H  to the protective ground of the switch panel or of the control cabinet.
- Check the polarity of the current measuring inputs.
- Siemens recommends leaving the device for a minimum of 2 hours in the operating room, before using it to allow temperature equalization and to avoid dampness and condensation.

**NOTE**

Before you switch on the supply voltage, verify that the operational data match the rated data on the name plate and the technical data according to 13. This applies in particular to the supply voltage V_H .

5.3.2 Electrical Connection of SICAM AI Unit




Fig. 5-3 Terminal Connection of the Supply Voltage at the SICAM AI Unit

Connect the cables of the supply voltage on the terminal side of the device at **terminal block H** as follows:

Supply from the AC Voltage System


Terminal N/-:	Neutral conductor of the supply voltage
Terminal L/+:	Phase of the supply voltage
Terminal  :	Protective grounding terminal

Supply from a Direct Voltage Source

Terminal N/-:	Negative supply voltage
Terminal L/+:	Positive supply voltage
Terminal  :	Protective grounding terminal



NOTE

The grounding on the SICAM AI Unit always has to be connected to the terminal for protective conductor  (terminal block H).

If several SICAM AI Units are cascaded via the internal Ethernet switch or via the RS485 interface (also in connection with SICAM I/O Units), you must create **a current-carrying grounding capacity of all devices on the communication bus (also, for example, RTU and protection device) on the same grounding potential.**



NOTE

The device is provided with Phoenix FMC 1.5/ 9-ST-3.81 plug connector for the (T) and (Q) connections.

Terminals

The conductor cross-section for the supply voltage terminal (H) amounts to:

- 1.5 mm² (AWG 16) to 2.5 mm² (AWG 14) without bootlace ferrule
- 1.5 mm² (AWG 16) with bootlace ferrule

Tightening torque

0.4 Nm to 0.5 Nm (3.5 in-lb to 4.5 in-lb)

The conductor cross-section for the 20-mA input terminals (T) and (Q) amounts to:

- 0.2 mm² (AWG 24) to 1.5 mm² (AWG 16), direct connection of stranded wires without bootlace ferrule is not recommended.

Wire stripping length

10 mm (0.39 in)

Material

Cu / E-Cu

Communication Interfaces

RS485 interface (J) on the terminal side
(if installed in the device model):

RS485 cable with plug connector

820-nm fiber-optic interface (J) on the terminal side
(if installed in the device model):

Fiber-optic cable with prepared ST connector, for example 6XV8100

**DANGER**

Danger due to Laser radiation class 1

Non-observance will lead to death or serious injury.

- ❖ Do not look into the fiber-optic elements!

Ethernet interface (Z) on the top side:

Ethernet patch cable, crossover cable, or a Y cable, when using the internal Ethernet switches

5.4 System Requirements

To operate SICAM AI Unit with a PC or notebook, the following system requirements must be met:

- PC or notebook with Intel Pentium processor (or compatible type); clock frequency min. 800 MHz
- Operating system: Microsoft Windows XP Professional with Internet Explorer 6.0 (or higher)
- Minimum 1 GB RAM primary storage
- VGA display 1024 x 768 with truecolor
- Mouse and keyboard

5.5 Access Rights

Access Rights for Configuration and Maintenance

To determine access rights, you have to set up passwords when configuring the device. You have to specify an activation password and a maintenance password. 7.3.4.4 describes how to set up passwords.

The **activation password** is necessary to enable parameter changes in the device. The **maintenance password** is necessary to make changes in the device using the Maintenance tab.



NOTE

If you do not specify new passwords, the factory-set default passwords (see 7.3.4.4) are used.

Access Rights for Communication

The access rights for the communication via **Ethernet** with **Modbus TCP** protocol are made for port 502 and for the user port. You can assign either full access rights or read-only authorization. 7.3.4.2 describes the settings.

You can also determine the access rights for **serial communication** using the **Modbus RTU** protocol. You can assign either full access rights or read-only authorization. 7.3.4.3 describes the settings.

No access rights are required when **serial communicating** via the **IEC 60870-5-103** protocol.

Communication via **Ethernet** with **IEC 61850** protocol and **serial communication** with **SIPROTEC RTU 20 mA** protocol do not require any access rights.

5.6 Description of the LEDs

7XV5674 automatically monitors the functions of its hardware and software components. The LEDs on the top side of the housing indicate the current device status.




Fig. 5-4 Designation of the LEDs

Depending on the status, the LEDs can be permanently on, flash or off. The states are described in 12.3. The meaning of the LEDs during normal operation is explained in the following table:

Table 5-1 Meaning of the LEDs

LED	Meaning
RUN	Device active
ERROR	Indicates an error and indicates according to parameterization
H1	According to parameterization
H2	According to parameterization
Ethernet switch turned off: Link/Activity (green)	LED on: Ethernet link is up LED flashing: Ethernet link is up and data are transferred LED off: no Ethernet partners connected
Ethernet switch turned off: Speed (yellow)	LED on: 100 Mbit/s LED off: 10 Mbit/s
Ethernet switch turned on: Link/Activity channel 2 (green)	LED on: Ethernet link is up LED flashing: Ethernet link is up and data are transferred LED off: no Ethernet partners connected
Ethernet switch turned on: Link/Activity channel 1 (yellow)	LED on: Ethernet link is up LED flashing: Ethernet link is up and data are transferred LED off: no Ethernet partners connected

5.7 Commissioning

5.7.1 Initial Commissioning



DANGER

Hazard due to high voltage

Non-observance will lead to death or serious injury.

- Work may only be carried out by trained personnel (see Preface) who are familiar with and observe the safety requirements and precautions.
- Work may never be carried out if there is any dangerous voltage present.
- Deenergize the device.
- **Circuit breaker:** A suitable isolating device shall be connected upstream in order to permit disconnection of the device from the power supply. The circuit breaker must be mounted close to the device, be easily accessible to the user and marked as a circuit breaker for the device.
- Secure the supply voltage with an approved (UL/IEC) fuse: 1.6 A, type C.
- If a melting fuse is used, a suitable approved (UL/IEC) fuse holder has to be used.

After you have inserted the battery, assembled the device and connected the supply voltage lines, you can start the device for the first time. Proceed as follows:

- ✧ Check that the operational data match the rated data on the name plate and the technical data of the device (see chapter 13). This applies in particular to the supply voltage and to the maximum values of AC current and AC voltage.



NOTE

You only have to wire the terminals needed for your purposes.

- ✧ On the terminal side of the device, connect the measuring lines linked with the measurement objects at the terminal blocks T and Q. Chapter 6 describes interfaces, connection principles, and examples of connection possibilities.
- ✧ Connect a cable to the systems control on the terminal side of the device at terminal block J (RS485 or optical interface, if installed).
- ✧ On the top side of the device, connect the network cable to the PC at the RJ45 socket Z (Ethernet).
- ✧ Switch on the supply voltage of the device
- ✧ Close the door of the control cabinet to prevent touching live parts accidentally.
- ✧ Switch on the connected peripheral devices (PC, measuring device or modules) for measurand analysis.



NOTE

The device does not have a power on/off switch. The supply voltage must be switched on or off directly at the respective supply cable.

After an operating time of approximately 15 minutes, the device will stay within the tolerances specified in the technical data.

- ✧ Switch the direct currents to be measured at the measurement object on the measuring lines.

- ✧ Carry out the measurements as described in 7.



NOTE

For the operation of the device through the browser, JavaScript must be enabled. If JavaScript is not yet enabled, activate it as described in 7.2.2.

5.7.2 Changes During Operation

The device is designed for permanent operation.

If you want to change the measurement setup, e.g. by connecting terminals so far unused, proceed analogously to the Initial Commissioning.



NOTE

If you change the measurement setup, you must de-energize the supply voltage lines and all measuring lines before opening the control cabinet. Please note the warnings in 5.7.1.

5.7.3 Starting the Device with the Default IP Address

SICAM AI Unit has the following internal default IP address: **192.168.0.55**.

If you have entered a custom IP address during device configuration, you can temporarily activate the internal default IP address of the device if necessary. For this purpose, press the IP-Addr. push-button on the DIN rail side for at least 3 s.




Fig. 5-5 Location of the Push-button for Activating the Default IP Address

When you press the IP-Addr. push-button, SICAM AI Unit will reset and use the default IP address until you have set a new IP address or switched the device off and on again.



NOTE

Resetting the IP address will lead to a device reset, and the LEDs on the top side of the device indicate that the device was started with the default IP address (see 12.3).

In this case, the parameterized IP address and the default IP address are displayed on the **Information** tab, **Device information** item (see 7.2.5).

When the device has restarted with the default IP address, the factory-set default passwords are also active (see 7.3.4.4).

6 Connection Principle

6.1	Terminals	44
6.2	Communication Interfaces	47
6.3	Connection Type	48

6.1 Terminals

The terminals on the terminal side of the device are designed as terminal blocks:




Fig. 6-1 Terminal Blocks on the Terminal Side of the SICAM AI Unit

Table 6-1 Terminal Blocks at SICAM AI Unit

Terminal Block	Description
H	Supply voltage
Q	Six 20-mA inputs for direct-current measurement
T	Six 20-mA inputs for direct-current measurement




NOTE

SICAM AI Unit 7XV5674-0KK00-xAA1 has a covered cut-out at position **J** on the terminal side.

SICAM AI Unit 7XV5674-0KK30-xAA1 has the RS485 interface and SICAM AI Unit 7XV5674-0KK40-xAA1 has the optical interface in this position, see chapter 6.2.2.

Functions of the Terminals at SICAM AI Unit

Table 6-2 Functions of the Terminals

Terminal	Assigned Function, Measured Value or Indication	Description
H: 	Protective conductor	-
H: N / -	N/-	Neutral of the mains voltage/ negative supply voltage
H: L / +	ph/+	Phase of the mains voltage/ Positive supply voltage
J 1)	RS485	Serial interface
	Optical (FO)	Serial interface
Q: I _{Channel 1}	I ₁	Channel 1 current measurement, Positive terminal → pin number 2 Negative terminal → pin number 1
Q: I _{Channel 2}	I ₂	Channel 2 current measurement, Positive terminal → pin number 6 Negative terminal → pin number 4
Q: I _{Channel 3}	I ₃	Channel 3 current measurement, Positive terminal → pin number 3 Negative terminal → pin number 5
Q: I _{Channel 4}	I ₄	Channel 4 current measurement, Positive terminal → pin number 7 Negative terminal → pin number 9
Q: I _{Channel 5}	I ₅	Channel 5 current measurement, Positive terminal → pin number 11 Negative terminal → pin number 13
Q: I _{Channel 6}	I ₆	Channel 6 current measurement, Positive terminal → pin number 15 Negative terminal → pin number 17
T: I _{Channel 1}	I ₁	Channel 1 current measurement, Positive terminal → pin number 2 Negative terminal → pin number 1
T: I _{Channel 2}	I ₂	Channel 2 current measurement, Positive terminal → pin number 6 Negative terminal → pin number 4

Terminal	Assigned Function, Measured Value or Indication	Description
T: I_{Channel 3}	I_3	Channel 3 current measurement, Positive terminal → pin number 3 Negative terminal → pin number 5
T: I_{Channel 4}	I_4	Channel 4 current measurement, Positive terminal → pin number 7 Negative terminal → pin number 9
T: I_{Channel 5}	I_5	Channel 5 current measurement, Positive terminal → pin number 11 Negative terminal → pin number 13
T: I_{Channel 6}	I_6	Channel 6 current measurement, Positive terminal → pin number 15 Negative terminal → pin number 17
Z	Ethernet interface	Ethernet connection; on the top side of the housing

1) Only for device variants with an RS485 or optical interface

6.2 Communication Interfaces

6.2.1 Ethernet Interface

The Ethernet interface **Z** is located on the top side of the SICAM AI Unit. Data are exchanged via the RJ45 Ethernet socket, see also chapter 9.1.1.




Fig. 6-2 Ethernet Interface Z (detail of the top side)



NOTE

If you do not connect a cable to the RJ45 socket, Siemens recommends covering the socket with a cap or dummy plug (not included in the delivery) to prevent the contacts from becoming dirty.

6.2.2 Serial Interface

As per device model, the RS485 interface (7XV5674-0KK30-xAA1) or the optical interface (7XV5674-0KK40-xAA1) at position **J** is located on the terminal side of the SICAM AI Unit, see also chapter 9.1.2.




Fig. 6-3 RS485 Interface J (detail of the terminal side)



NOTE

If you do not connect a cable to the RS485 or optical interface, Siemens recommends covering it with a cap (not included in the delivery) to prevent the contacts from becoming dirty.

6.3 Connection Type

For the input wiring, observe the following operating conditions:

- ✧ Each channel obtains its own current source.
- ✧ Check the polarity of the current measuring inputs (see Table 6-2).



DANGER

Hazard due to high voltages in the event of a breakdown of the winding insulation

Non-observance will lead to death or serious injury.

- Ground the secondary windings of the current transformers on one side. They are installed in a high-voltage power system.

The connection example for the terminal block **T** is shown in the following figure. This connection example also applies to the terminal block **Q**. For the input wiring and polarity of the current measuring inputs, see Table 6-2.




Fig. 6-4 Connection Example

7 Operation

7.1	General Usage Notes	50
7.2	Start and Design of the User Interface	51
7.3	Configuration of the Device	62
7.4	Value View	100
7.5	Maintenance	101

7.1 General Usage Notes







The device is operated from a connected PC or notebook only. The graphical user interface is stored in the device. To display the user interface, start Microsoft Internet Explorer 6.0 (or higher) and enter the IP address of the device.

You can navigate through Microsoft Internet Explorer using the icons on the toolbar, for example back, forward, print etc. The user interface itself does not contain any navigation icons.

Operating actions are performed with the mouse. Parameters and text are entered using the keyboard.

The following table lists the control elements.

Table 7-1 Control Functions

Control Element	Control Function
	Option button: selects one option
	List box: selects an item from a list
	Button: Executing an action by clicking the button, i.e. the current settings on the user interface are transmitted to the device.
	Active tab (light blue)
	Inactive tab (dark blue)
	Selects and opens the item to be activated, for example a tab



HINWEIS

Measured values are entered or displayed with a decimal point separating the integral and the fractional parts, for example 19.8 mA.


7.2 Start and Design of the User Interface

7.2.1 Initial Start of the User Interface

Requirements

Before starting the user interface, the following preconditions must be satisfied:

- ✧ Assemble the SICAM AI Unit as described in chapter 5.2.
- ✧ Connect the lines for measurement, communication and supply voltage as described in chapter 5.3 and observe the safety provisions.
- ✧ Switch on the devices needed for the measurement.
- ✧ Switch on the supply voltage of the SICAM AI Unit.
- ✧ Check whether the LEDs at the SICAM AI Unit indicate that the device is ready (see chapter 12.3).
- ✧ Match the IP address and the subnet mask of the network interface card of your computer to the device settings.
- ✧ Check on the computer screen whether the LAN connection is up. Activate the LAN connection if it is down (see the Windows manual or the Windows online help for information).
- ✧ For checking purposes, carry out the ping test as follows (example for Windows XP):
 - Click **Start** on the Windows interface.
 - Select **Execute....**
 - Enter **cmd** in the dialog and click **OK**.
 - Enter: **ping 192.168.0.55**.
 - Press the **Enter** button.
 - Check the following output in the window.



```

C:\WINNT\system32\Cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\nb22a8w0\Desktop>ping 192.168.0.55

Pinging 192.168.0.55 with 32 bytes of data:

Reply from 192.168.0.55: bytes=32 time<1ms TTL=60
Reply from 192.168.0.55: bytes=32 time<1ms TTL=60
Reply from 192.168.0.55: bytes=32 time<1ms TTL=60
Reply from 192.168.0.55: bytes=32 time<1ms TTL=60

Ping statistics for 192.168.0.55:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\Documents and Settings\nb22a8w0\Desktop>_
  
```

Fig. 7-1 Ping Test

- ✧ Start Microsoft Internet Explorer.
- ✧ Enter the IP address in Microsoft Internet Explorer (e.g. default IP address: <http://192.168.0.55>) of SICAM AI Unit and press ENTER.

The user interface opens with the **Information** tab → **Show device information** (see figure 7-4).

**NOTE**

When starting the device for the first time, a set of parameters with factory settings is loaded. You can modify these settings during the parameterization (see chapter 7.3).

To set a different user language for the user interface, open the **Administrative** menu on the **Configure** tab, select the **Device and language** menu item and change the user language as described in chapter 7.3.4.4.

**NOTE**

If user interface does not open or the displayed user interface does not show the view depicted in figure 7-3, JavaScript may be the cause. The operation of user interface requires JavaScript. You may have to activate JavaScript as described in chapter 7.2.2.

7.2.2 Enabling JavaScript

The operation of the user interface requires JavaScript.

Enable JavaScript as follows:

- ✧ Start Microsoft Internet Explorer.
- ✧ Click the **Tools** menu on the menu bar of Microsoft Internet Explorer.
- ✧ Select **Internet options...** from the **Tools** menu.
- ✧ In the **Internet options** dialog open the **Security** tab.




Fig. 7-2 Enabling JavaScript

- ✧ In the window of the **Security** tab select the **Internet** icon.
- ✧ On the **Security** tab scroll to **Medium** by moving the scroll bar with your mouse. Alternatively, if there is no scroll bar, click the **Default Level** button and set the scroll bar that appears to **Medium**.
- ✧ Click the **Apply** button.
- ✧ Click the **OK** button.

7.2.3 Number of Connections via HTML

Three connections maximum are possible via HTML.

7.2.4 Layout of the User Interface

The user interface has the following layout:




Fig. 7-3 Designations in the User Interface

7.2.5 Starting the User Interface during Operation

Starting the User Interface

To start the user interface, proceed as follows:

- ✧ Start Microsoft Internet Explorer.
- ✧ Enter the IP address in Microsoft Internet Explorer (for example the default IP address: 192.168.0.55) of SICAM AI Unit and press ENTER.

The user interface opens with the **Information** tab → **Show device information** item (see figure 7-4).

Information Tab

The screenshot shows the Siemens SICAM AI Unit 7XV5674 user interface. The top navigation bar includes 'Information', 'Configure', 'Value View', and 'Maintenance'. The 'Information' tab is active, and the 'Show device information' option is selected. The left sidebar contains options for 'Show device information', 'Save device information and message logs', and a 'Message Logs' menu with 'Operational log' and 'Error log' sub-items.

The main content area displays the following information:

Information ► Show device information

▼ **Device information**

Device information	Value
Device name	SICAM AI Unit 7XV5674
Order number (MLFB)	7XV56740KK302AA 1
Serial number	BF0000000000
Device type	20 mA Unit
Firmware version	V01.00.00.14
Bootloader version	V01.03.02.03
Parameter set version	V01.00.00.40
Firmware package version	V01.00.00

▼ **Communication**

Communication	Value
MAC address	00098EFD0FA9
IP address	192.168.0.55
Subnet mask	255.255.255.0
Default gateway	192.168.0.1
Ethernet bus protocol	Modbus TCP

▼ **Device date and time**

Parameter	Value
Local time	2000-01-01 05:02:58:415
UTC	2000-01-01 05:02:58:414
Source time synchronization	Internal

▼ **Parameter set**

Set	Date of activation	Status
Active parameter set	2000-01-01 04:53:52:810	Active
Parameter set for configuration	---	Equal to active

Fig. 7-4 Information Tab, Show Device Information Input/Output Window

Navigation Window of the Information Tab

The navigation window of the **Information** tab contains the elements **Show Device Information**, **Save device information and message logs** and the **Message Logs** menu with the elements **Operational log** and **Error log**.

7.2.5.1 Show Device Information

- ✧ Click the **Show device information** item in the navigation window.
The **Show device information** input/output window shows the following information (see figure 7-4):
 - **Device information:** Information about the device and the installed software
 - **Communication:** Information about the data transfer between device and periphery
 - **Device date and time:** Information about the time settings of the device
 - **Parameter set:** Information about the active and passive set of parameters

7.2.5.2 Save Device Information and Message Logs

- ✧ Click the **Save device information and message logs** item in the navigation window.
The **Save .TXT** and **Save .CSV** buttons in the **Save device information** input/output window are displayed.






Fig. 7-5 Information Tab, Save Device Information Input/Output Window

- ✧ In order to save the device information and logs as text file, click the **Save .TXT** button.
- ✧ In order to save the operational log as CSV file, click the **Save .CSV** button.

The **File Download** dialog opens.



File Download Dialog
(DEVINFO.TXT)



File Download Dialog
(OPLOG.CSV)

Fig. 7-6 File Download Dialog (DEVINFO.TXT) or (OPLOG.CSV)

File Download → Save

- ✧ Click the **Save** button.
The **Save As** dialog opens.





Fig. 7-7 Save As Dialog with File Name (**DEVINFO.TXT**) or (**OPLOG.CSV**)

- ✧ Select the file path in the **Save in:** list box.
- ✧ Use the file name suggested in the **File name:** list box or enter a new file name with the file extension .TXT or .CSV.
- ✧ Click the **Save** button.
The **Download complete** dialog opens.
- ✧ In the **Download complete** dialog, click the **Close** button.

File Download → Open

Alternatively, you can view the device information and message logs on the screen and print them if needed. Proceed as follows:

- ✧ In the **File download** dialog (see figure 7-6), click the **Open** button.
A Text Editor or a CSV file opens. The Text Editor contains the following information:
 - DEVICE INFORMATION
 - OPERATIONAL LOG
 - ERROR LOGThe CSV file contains the OPERATIONAL LOG as a list.
- ✧ On the menu bar of the Text Editor, click **File → Print...**, select the desired printer in the following **Print** dialog and click the **Print** button.
The list is printed on the connected printer.
- ✧ On the menu bar of the CSV file, click **File → Print...**, select the desired printer in the following **Print** dialog and click the **Print** button.
The list is printed on the connected printer.
- ✧ Close the Text Editor.
- ✧ Close the CSV file.
- ✧ Click an element on the navigation window or a tab, or alternatively, click the **Back** icon on the toolbar of Microsoft Internet Explorer twice.


7.2.5.3 Message Logs Menu

The **Message Logs** menu contains operational indications and error messages registered and saved by the device during operation. The device can save up to 128 operational indications and up to 128 error messages. When the storage capacity is exceeded, the oldest indications will be overwritten successively.

Operational Log

To show the operational indications, proceed as follows:

- ✧ In the navigation window, click the **Message Logs** menu and then the **Operational log** menu item.
The operational indications are listed in the input/output window as follows:



No.	Date	Time	Information	Value	Cause source
00030	2000-01-01	08:49:21:185	Settings Load	Off	Browser
00029	2000-01-01	08:49:21:185	Settings Activate	Off	Browser
00028	2000-01-01	08:49:16:809	Settings Activate	On	Browser
00027	2000-01-01	08:49:16:809	Settings Check	Off	Browser
00026	2000-01-01	08:49:16:801	Settings Check	On	Browser

Fig. 7-8 Information Tab, Operational Log

- **Serial No.**
- **Date** of registration
- **Time** of registration
- **Information** on the indication
- **Value** of the indication (On, Off or invalid)
- **Cause source** of the indication (e.g. Intern, Browser)



NOTE

The operational indications can be printed as described in chapter 7.2.5.2, section **File Download** → **Open**.
The chapter 7.5.6.1 explains how to delete the operational indications manually.

Error Log



NOTE

The information about error messages described below is intended for service purposes. Inform the customer service about this information when there are problems with your device.

To display the error messages, proceed as follows:

- ◇ In the navigation window, click the **Message Logs** menu and then **Error log**.

The error messages are listed in the input/output window as follows:

No.	Date	Time	Relative time	Task	Code	Location	Description
00001	2000-01-01	09:35:12:420	27307429	HTTP	ROOT	00h	*** Error Log Cleared ***
00002	2000-01-01	09:35:50:286	27345295	PARA	RTSS	1C9h	Serial task para test.
00003	2000-01-01	09:35:50:288	27345297	PARA	RTSS	1C9h	Serial task para activation.
00004	2000-01-01	09:36:30:114	27385123	PARA	RTSS	1C9h	Serial task para test.
00005	2000-01-01	09:36:30:117	27385126	PARA	RTSS	1C9h	Serial task para activation.
							*** End ***

Fig. 7-9 Information Tab, Error Log

- **Serial No.**
- **Date** of registration
- **Time** of registration
- **Relative time** (referring to the start of operation, output in milliseconds)
- **Task, Code** and **Location** are service information for the manufacturer.
- **Description** of the error



NOTE

The error messages can be printed as described in chapter 7.2.5.2, section **File Download** → **Open**.

The chapter 7.5.6.2 explains how to delete the error messages manually.

7.3 Configuration of the Device



NOTE

The device contains two set of parameters. The set of parameters currently used for device operations is the **active set of parameters**. The inactive set of parameters is called the **passive set of parameters**.

The following sections describe how to change and enable the passive set of parameters.

7.3.1 Device Configuration Procedure

If you have not changed the set of parameters since the first start of the device (see chapter 7.2.1), use the factory settings (see chapter 7.3.3 and chapter 7.3.4). To change the settings of the set of parameters, proceed as follows:

- ✧ Click the **Configure** tab on the user interface.
The **Configure** tab opens.




Fig. 7-10 Configure Tab



NOTE

The items in the **Process connections** menu show the current hardware and software configuration of the device.

- ✦ Select the **Prepare** menu in the navigation window and then either **Get device configuration** or **Open configuration from file**.

**NOTE**

If you have selected **Get device configuration**, an editable copy of the active set of parameters of the device is displayed on the screen. In the meantime, the active set of parameters in the device continues to operate. If you have selected **Open configuration from file**, you can open and enable or edit the copy of a set of parameters that was already created and saved to a folder.

7.3.1.1 Get Device Configuration

If you have selected **Get device configuration** in the **Configure** tab, you can open and edit either the **Get active configuration** or the **Get default configuration** in the input/output window. Proceed as follows:




Fig. 7-11 Configure Tab, Get Device Configuration

Get Active Configuration and Editing

- ✦ Click the **Get active configuration** button.
A copy of the active set of parameters (= passive set of parameters) of the device is opened for editing.
- ✦ Check and, if necessary, change the set parameters by opening the desired **Operational** menu described in chapter 7.3.4 and the **Administrative** menu according to chapter 7.3.3.
- ✦ Activate the modified configuration as described in chapter 7.3.1.3.

Get Default Configuration and Editing

- ✦ Click the **Get default configuration** button.
A copy of the factory settings (= passive set of parameters) of the device is opened for editing.

**NOTE**

You can edit the displayed factory settings, activate and use them as active set of parameters. The original factory settings are not overwritten and can be used at anytime.

- ✦ Activate the modified configuration as described in chapter 7.3.1.3.

7.3.1.2 Open Configuration from File

If you have selected **Open configuration from file** in the **Configure** tab, you can open an already existing file in a folder. Proceed as follows:




Fig. 7-12 Configure Tab, Open Configuration from File

- ✧ Click the **Browse...** button.
The **Choose File to Upload** dialog opens.




Fig. 7-13 Choose File

- ✧ Select the desired file (extension .cfg) in the directory.



NOTE

You can open only files with the following properties of the file name:

- Maximum 8 characters and extension (.cfg)
- Only containing:
 - Letters: a to z, A to Z
 - Numbers: 0 to 9
 - Hyphen (-) and underline (_)

- ✧ Click the **Open** button.
The selected path is inserted into the **Browse** field in the input/output window, figure 7-12.
- ✧ Click the **Open** button.
The device configuration from the CFG file is loaded.

7.3.1.3 Finish Configuration

When you have changed the configuration, you must either enable it as the active set of parameters or save it.

Activating the Set of Parameters

To **activate** the set of parameters, proceed as follows:

- ✧ In the navigation window, click the **Finish configuration** menu and then the **Activation** menu item.
The **Activation** input/output window opens.



Fig. 7-14 Configure Tab, Activation Input/Output Window

- ✧ In the **Activation** input/output window, enter the valid activation password into the **password** field. chapter 7.3.4.4 explains how to set the password.
- ✧ Click the **Activation** button.

At first the message **Parameter activation is still in progress** will be shown and then the message **Parameter activation is complete** in the input/output window.

The modified set of parameters is loaded as the active set of parameters into the device and the new parameters take effect immediately.

If the password is wrong, this message appears: **The password is wrong. Please enter the correct password.**

**NOTE**

The active and passive set of parameters are listed in the **Activation** input/output window in the **Set** column for your information.

Save Configuration to File

You can save both the active and the passive configuration to a file. Proceed as follows:

- ✧ In the navigation window, click the **Finish configuration** menu and then **Save Configuration to File**. The **Save Configuration to File** input/output window opens.




Fig. 7-15 Configure Tab, Save Configuration to File Input/Output Window

- ✧ Click either of the buttons **Save active configuration** or **Save passive configuration**.

The **File Download** dialog opens.




Fig. 7-16 File Download Dialog

File Download → Save

- ✦ Click the **Save** button.
The **Save As** dialog opens.




Fig. 7-17 Save As Dialog

- ✦ Select the file path in the **Save in:** list box.
- ✦ Use the file name suggested in the **File name:** list box or enter a new file name with the file extension .CFG.



NOTE

File names mustn't be longer than 8 signs. You use only characters according to NOTE in chapter 7.3.1.2.

- ✦ Click the **Save** button.
The **Download complete** dialog opens.
- ✦ In the **Download complete** dialog, click the **Close** button.

Cancel

To cancel the configuration, proceed as follows:

- ✧ In the navigation window, click the **Finish configuration** menu and then **Cancel**.
The **Cancel** input/output window opens.




Fig. 7-18 Configure Tab, Cancel Input/Output Window

- ✧ Click the **Cancel** button in the input/output window.



NOTE

After clicking the **Cancel** button, the active set of parameters is copied into the passive set of parameters. This action is the same as **Get device configuration** → **Get active configuration** described in chapter 7.3.1.1.

When you have clicked the **Cancel** button, the parameterization is released and can be run from a different computer if necessary.

7.3.2 Access to the Passive Set of Parameters by Multiple Users

Reading the Passive Set of Parameters

The user interface allows the simultaneous read access of up to 3 web servers to the passive set of parameters.

Editing the Passive Set of Parameters

The passive set of parameters can only be edited from one PC or notebook even though multiple users have simultaneous read access.

Once a user changes a parameter on the user interface, the write access is denied for all other users.

If the write access is blocked, **modified** in brackets will be displayed in the upper right corner of the user interface. The user making the changes will see **modified** without brackets.




Fig. 7-19 Access Blocked

If a user makes a change, the server starts a 20-minute timer. If no further changes to the set of parameters are entered by the time the timer has counted down, write access is released again for all users. In this case, the modified data are discarded and the passive set of parameters is overwritten with the content of the active set of parameters.

If new changes to the passive set of parameters are made during the 20-minute countdown, the timer is restarted by each action.

If the user has completed his changes to the passive set of parameters or finished the parameterization by clicking the **Cancel** button, write access for all users is also released.

7.3.3 Setting the Operational Parameters

In the **Configure** tab you can view and edit the set operational parameters. You can select the parameters in the **Operational** menu in the navigation window. The submenus **Process connections**, **Select automation function** and **Administrative** are available for making the settings. The submenus contain the following elements:

- Process connections
 - 20-mA inputs
 - LEDs
- Select automation functions
 - Measurand limits 1-8
 - Measurand limits 9-16
 - Group indications
- Administrative
 - Time synchronization
 - Communication Ethernet
 - Communication serial
 - Device and language

**NOTE**

Observe the procedure for the device configuration described in chapter 7.3.1 when you set the operational parameters.

7.3.3.1 Process Connections

7.3.3.1.1 20-mA Inputs

Default Settings and Setting Ranges of Measured-value Acquisition checkmark set

Table 7-2 Settings for 20-mA Inputs

Parameter	Default Setting	Setting Range
T1/2 (20-mA Channel 1 terminal block T)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
T4/6 (20-mA Channel 2 terminal block T)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
T3/5 (20-mA Channel 3 terminal block T)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
T7/9 (20-mA Channel 4 terminal block T)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
T11/13 (20-mA Channel 5 terminal block T)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
T15/17 (20-mA Channel 6 terminal block T)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
Q1/2 (20-mA Channel 1 terminal block Q)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
Q4/6 (20-mA Channel 2 terminal block Q)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
Q3/5 (20-mA Channel 3 terminal block Q)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)

Table 7-2 Settings for 20-mA Inputs (cont.)

Parameter	Default Setting	Setting Range
Q7/9 (20-mA Channel 4 terminal block Q)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
Q11/13 (20-mA Channel 5 terminal block Q)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
Q15/17 (20-mA Channel 6 terminal block Q)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
Measuring range	0 mA to +20 mA	0 mA to +20 mA 4 mA to +20 mA

To change the parameters of the 20-mA inputs, proceed as follows:

- ✧ In the navigation window, select the **Operational** menu, then the **Process connections** submenu and click the **20-mA inputs** menu item.

The **20-mA inputs** input/output window opens.




Fig. 7-20 Configure Tab, 20-mA Inputs Input/Output Window




- ✧ For the direct-current measurement, select the measuring channels of the terminal block **T** with the option button **Active**. For this purpose, set the checkmark (Yes = checkmark set).

- ✧ Select the desired input measuring range with the option buttons of the **Measuring range**. You can set the parameters of the following input measuring ranges:
 - 0 mA to +20 mA
 - 4 mA to +20 mA
- ✧ For the direct-current measurement, select the measuring channels of the terminal block **Q** with the option button **Active**. For this purpose, set the checkmark (Yes = checkmark set).
- ✧ Select the desired input measuring range with the option buttons of the **Measuring range**. You can set the parameters of the following input measuring ranges:
 - 0 mA to +20 mA
 - 4 mA to +20 mA
- ✧ Click the **Send** button.
The parameters are transmitted to the device but not enabled yet (passive set of parameters).
- ✧ If you do not want to make any additional settings, continue with the **activation** of the device configuration according to **Activating the Set of Parameters**. If you want to change other settings, enter the changes and then enable the device configuration as described in **Activating the Set of Parameters**.

7.3.3.1.2 LEDs

Default Settings of the LEDs

Table 7-3 LED Settings

LED	Default Setting	Setting Range
RUN	Device ready	Not settable
ERROR	-none-	Indicates an error and indicates according to parameterization Acc. to list box  (see chapter 15)
H1	-none-	Acc. to list box  (see chapter 15)
H2	-none-	Acc. to list box  (see chapter 15)
Indication inverted	no	no yes

To change the outputs of the LEDs H1, H2, ERROR, proceed as follows:

- ✧ In the navigation window, select the **Operational** menu, then the **Process connections** submenu and click **LEDs**.

The **LEDs** input/output window opens.




Fig. 7-21 Configure Tab, LEDs Input/Output Window

- ✧ Select the indication to be assigned to the corresponding LED from the **H1** or **H2** list box. You can select from the following indications:
 - Ready and status indications, for example Device OK, Modbus TCP OK, Input not active T1/2
 - Indications about present device activities, for example Settings load
 - Group indication, example Group Indication 2
 - Error indications, for example Battery Failure, Ethernet Link Error
 - Administrative indications, for example Daylight Saving Time
 - Limit violation indications, for example Limit Violation 1 (see chapter 7.3.3.2)
 - Measuring range exceedance, for example Out of range Q4/6
 - Measuring range lower deviation, for example Wire broken Q3/5
- ✧ Select the indication, which will be assigned to the red Error LED from the **Error** list box. You can only select the Error indications.
Select **-none-** to disable the corresponding LED.
- ✧ In the **Indication inverted** section, select whether you want to invert the indication for the output (**yes**) or not (**no**).



NOTE

The output of the **Error** LED cannot be inverted.

- ✧ Click the **Send** button.
The parameters are transmitted to the device but not enabled yet (passive set of parameters).

- ◇ If you do not want to make any additional settings, continue with the **activation** of the device configuration according to **Activating the Set of Parameters**. If you want to change other settings, enter the changes and then enable the device configuration as described in **Activating the Set of Parameters**.

Behavior of the LEDs




Fig. 7-22 Behavior of the LEDs

7.3.3.2 Automation Functions


7.3.3.2.1 Limit Settings

In the **Select automation functions** menu you can set upper or lower limits for up to 16 measured values. Limit violations of the upper or lower value range can be output as indications. Up to 4 limit value violations can be signaled at the device via the LEDs H1 and H2. Furthermore, all 16 limit violations can be sent to peripheral devices via Ethernet.

The programmable limits are divided into two groups **Measurand limits 1-8** and **Measurand limits 9-16**. The parameterization is identical for all limits.

Default Settings and Setting Ranges of the Limits

Table 7-4 Limit Settings

Parameter	Default Setting	Setting Range
Measurand	-none-	Acc. to list box  (see chapter 15)
Limit	0.00	0.00 mA to 20.00 mA
Limit type	Lower	Lower Upper
Hysteresis (%)	1.00	0.00 to 20.00
Violation indication	Limit Violation x (x = 1 to 16)	The name of the limit violation indication is customizable.

Parameterizing a Limit

To change for example limit 1, proceed as follows:

- ✧ In the navigation window, select the **Operational** menu, then the **Select automation functions** submenu and click **Measurand limits 1-8**.

The **Measurand limits** input/output window opens.




Fig. 7-23 Configure Tab, Measurand Limits 1-8 Input/Output Window (Detail)

- ✧ Select the measured value for which you want to parameterize the limit value indication from the **Measurand** list box. You can parameterize a limit value indication for the following measured values:
 - 20-mA Channel x terminal block **T** (x = 1 to 6)
 - 20-mA Channel x terminal block **Q** (x = 1 to 6)
 Select **-none-** to disable the limit value indication.
- ✧ Enter a limit value into the **Parameter** column in the **Limit type** option field that lies below the permitted value range (**Lower** limit value) or above the permitted value range (**Upper** limit value).
- ✧ Enter the limit value into the **Limit** field.

- ✧ In the **Hysteresis** field enter a value for the hysteresis of the limit value violation.




Fig. 7-24 Hysteresis (General Representation)

- ✧ Enter a name for the limit violation indication in the **Violation indication** field. By doing so, the original entry is overwritten.
- ✧ Click the **Send** button.
After clicking the **Send** button, the parameters are transmitted to the device but not enabled yet (passive set of parameters).
- ✧ If you do not want to make any additional settings, continue with the **activation** of the device configuration according to **Activating the Set of Parameters**. If you want to change other settings, enter the changes and then enable the device configuration as described in **Activating the Set of Parameters**.

7.3.3.2.2 Group Indications

In the **Select automation functions** menu, up to 4 **Group indications** can be parameterized and each of them can be assigned up to 16 logically linked single-point indications. For this purpose, set the checkmark.

Table 7-5 Group Indications

Parameter	Default Setting	Setting Range
Indication According to the available indications (see chapter 15)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)

Parameterizing a Group Indication

To change for example group indication 1, proceed as follows:

- ✧ In the navigation window, select the **Operational parameters** menu, then the **Select automation functions** submenu and click **Group indications**.

The **Group indications** input/output window opens.




Fig. 7-25 Configure Tab, Group Indications Input/Output Window (Detail)

- ✧ For the **Group Indication 1**, select up to 16 indications you want to assign to **Group Indication 1**. For this purpose, set the checkmark. You can assign the following indications to a group indication:
 - Ready and status indications, for example Device OK, Modbus TCP OK, Input not active T1/2
 - Error indications, for example Battery Failure, Ethernet Link Error
 - Administrative indications, for example Daylight Saving Time
 - Limit violation indications, for example Limit Violation 1 (see chapter 7.3.3.2)
 - Measuring range exceedance, for example Out of range Q4/6
 - Measuring range lower deviation, for example Wire broken Q3/5

If you do not set any checkmark for all indications of a group indication, the respective group indication is inactive.

- ✧ Click the **Send** button.
After clicking the **Send** button, the parameters are transmitted to the device but not enabled yet (passive set of parameters).
- ✧ If you do not want to make any additional settings, continue with the **activation** of the device configuration according to **Activating the Set of Parameters**. If you want to change other settings, enter the changes and then enable the device configuration as described in **Activating the Set of Parameters**.

7.3.4 Setting Administrative Parameters

In the **Configure** tab you can view and if necessary edit the administrative settings. You can select the parameters in the **Administrative** menu in the navigation window. These parameters can be changed in the input/output windows **Time synchronization**, **Communication** (consisting of **Communication Ethernet** and **Communication serial**) and **Device and language**.






NOTE

Observe the procedure for the device configuration described in chapter 7.3.1 when setting the administrative parameters.

7.3.4.1 Time Synchronization

Default Settings and Setting Ranges of the Time Synchronization

Table 7-6 Time Synchronization Settings

Parameter	Default Setting	Setting Range
Source time synchronization	Internal	Acc. to list box  (see chapter 15)
Time zone offset to UTC	+00:00	-12 to +13 (hours) (in increments of 0.5 h)
Daylight Saving Time switchover	yes	no yes
DST offset to UTC	+01:00	0 to + 2 (hours) (in increments of 0.5 h)
Start of DST	March Last week Sunday 02:00 AM	Acc. to list boxes  (see chapter 15)
End of DST	October Last week Sunday 03:00 AM	Acc. to list boxes  (see chapter 15)
Additional Parameters if the Source is Ethernet NTP (Modbus TCP and IEC 61850)		
Primary NTP server IP address	192.168.0.254	Any
Secondary NTP server IP address	192.168.0.253	Any No polling of the NTP server if 0.0.0.0 was entered
Error indication after	10 min	2 min to 120 min
Additional Parameter if the Source is Fieldbus (Modbus RTU)		
Error indication after	10 min	2 min to 120 min

To change the time synchronization, proceed as follows:

- ✧ In the navigation window, click the **Administrative** menu and then **Time synchronization**. The **Time synchronization** input/output window opens.



Fig. 7-26 Configure Tab, Time Synchronization Input/Output Window, Ethernet NTP Selected

- ✧ Select one of the three following sources from the **Source time synchronization** list box:
 - Internal (no time synchronization)
 - Ethernet NTP
 - Fieldbus
- ✧ Parameterize the time synchronization according to the selected source.

Internal Time Synchronization

- ✧ Select **Internal** as the source from the **Source time synchronization** list box:
- ✧ In the **Time zone offset to UTC** list box select the time difference to UTC (Universal Time Coordinated).
- ✧ The option buttons at **Daylight Saving Time switchover** allow you to enable (**yes**) or disable (**no**) the automatic Daylight Saving Time adjustment.

If you have selected the **no** option button, the time synchronization is complete. Click the **Send** button in this case. If you have selected the **yes** option button, continue the parameterization as follows:
- ✧ Select the time difference to UTC in the **DST offset to UTC** list box.
- ✧ In the list boxes under **Start of DST** specify the month, week, day and time for starting Daylight Saving Time.
- ✧ In the list boxes under **End of DST** specify the month, week, day and time for switching back to standard time.

- ✧ Click the **Send** button.
After clicking the **Send** button, the parameters are transmitted to the device but not enabled yet (passive set of parameters).
- ✧ If you do not want to make any additional settings, continue with the **activation** of the device configuration according to **Activating the Set of Parameters**. If you want to change other settings, enter the changes and then enable the device configuration as described in **Activating the Set of Parameters**.

Time Synchronization via Ethernet NTP

- ✧ Select **Ethernet NTP** as the source from the **Source time synchronization** list box:
- ✧ Enter the IP address in the **Primary NTP server IP address** field.
- ✧ Enter the IP address of the redundant NTP server in the **Secondary NTP server IP address** field.
- ✧ In the **Error indication after** field enter the time in **min** after which the operational indication "Clock error" is output.
- ✧ Select the time difference to UTC in the **Time zone offset to UTC** list box.
- ✧ The option buttons at **Daylight Saving Time switchover** allow you to enable (**yes**) or disable (**no**) the automatic Daylight Saving Time adjustment.
If you have selected the **no** option button, the time synchronization is complete. Click the **Send** button in this case. If you have selected the yes option button, continue the parameterization as follows:
- ✧ Select the time difference to UTC in the **DST offset to UTC** list box.
- ✧ In the list boxes under **Start of DST** specify the month, week, day and time for starting Daylight Saving Time.
- ✧ In the list boxes under **End of DST** specify the month, week, day and time for switching back to standard time.
- ✧ Click the **Send** button.
After clicking the **Send** button, the parameters are transmitted to the device but not enabled yet (passive set of parameters).
- ✧ If you do not want to make any additional settings, continue with the **activation** of the device configuration according to **Activating the Set of Parameters**. If you want to change other settings, enter the changes and then enable the device configuration as described in **Activating the Set of Parameters**.

Time Synchronization via Fieldbus

- ✧ Select **Fieldbus** as the source from the **Source time synchronization** list box:
- ✧ In the **Error indication after** field enter the time in **min** after which the operational indication "Clock error" is output.
- ✧ Select the time difference to UTC in the **Time zone offset to UTC** list box.
- ✧ The option buttons at **Daylight Saving Time switchover** allow you to enable (**yes**) or disable (**no**) the automatic Daylight Saving Time adjustment.
If you have selected the **no** option button, the time synchronization is complete. Click the **Send** button in this case. If you have selected the **yes** option button, continue the parameterization as follows:
- ✧ Select the time difference to UTC in the **DST offset to UTC** list box.
- ✧ In the list boxes under **Start of DST** specify the month, week, day and time for starting Daylight Saving Time.
- ✧ In the list boxes under **End of DST** specify the month, week, day and time for switching back to standard time.

7.3 Configuration of the Device

- ✧ Click the **Send** button.
After clicking the **Send** button, the parameters are transmitted to the device but not enabled yet (passive set of parameters).
- ✧ If you do not want to make any additional settings, continue with the **activation** of the device configuration according to "**Activating the Set of Parameters**". If you want to change other settings, enter the changes and then enable the device configuration as described in **Activating the Set of Parameters**.

7.3.4.2 Ethernet Communication

General Settings

Table 7-7 Ethernet Communication Settings - General Settings

Parameter	Default Setting	Setting Range
IP address ¹⁾	192.168.0.55	Any 0.0.0.0 = DHCP
Subnet mask ¹⁾	255.255.255.0	Any
Default gateway ¹⁾	192.168.0.1	Any
Ethernet switch on	no	no yes
Bus protocol	Modbus TCP	-none- Modbus TCP IEC 61850 Modbus UDP

¹⁾ After the parameter changes have been enabled, the device will reset.

Bus Protocols Modbus TCP and Modbus UDP

Table 7-8 Ethernet Communication Settings - Modbus TCP/UDP

Parameter	Default Setting	Setting Range
Bus Protocol Modbus TCP		
Use a user-port number ¹⁾	no	no yes
User-port number ¹⁾ (can only be set when <i>Use a user-port number</i> is parameterized with <i>yes</i>)	10000	10000 to 65535
Access rights for user port (can only be set when <i>Use a user-port number</i> is parameterized with <i>yes</i>)	Full	Full Read only
Access rights for port 502	Full	Full Read only
Keep Alive time	10 s	0 s = switch off 1 s to 65 535 s
Communication supervision time	50 [* 100 ms]	0 s = none 100 ms to 6 553 400 ms
Bus Protocol Modbus UDP		
Port number	51000	10000 to 65535
Access rights	Full	Full, Read only
Communication supervision time	20 [* 10 ms]	0 ms = invalid 10 ms to 60 000 ms

- ¹⁾ After enabling the parameter changes, any currently active Modbus TCP connections will be closed. The Modbus TCP client must later reopen these connections.

Bus Protocol IEC 61850

Table 7-9 Ethernet Communication Settings - IEC 61850

Parameter	Default Setting	Setting Range
Bus Protocol IEC 61850 ¹⁾		
General		
IEC 61850 Edition	Edition 1	Edition 1 Edition 2
IED name number	1	0 to 65 534
Deadband percentage	2.0	0.0 % to 10.0 %
GOOSE Publisher parameters		
GOOSE Control Block name	Goose_20mA_Values	
Multicast MAC address	01-0C-CD-01-00-01	[xx-xx-xx-xx-xx-xx] hexadecimal
App ID	3001	[xxxx] hexadecimal
VLAN ID	000	[xxx] hexadecimal
VLAN priority	4	0 to 7
Retransmit MIN	10	1 ms to 500 ms
Retransmit MAX	2000	500 ms to 65 534 ms

- ¹⁾ After having selected IEC 61850 or having changed the IEC 61850 settings with the following activation, the device is automatically restarted.

To change the Ethernet communication settings, proceed as follows:

- ✧ In the navigation window, click the **Administrative** menu and then **Communication Ethernet**.
The **Communication Ethernet** input/output window with **Protocol Modbus TCP** opens.




Fig. 7-27 Configure Tab, Communication Ethernet via Modbus TCP Input/Output Window

- ✧ Enter the IP address into the **IP address** field.
- ✧ Enter the subnet mask into the **Subnet mask** field.
- ✧ Enter the gateway into the **Default gateway** field.
- ✧ In the **Ethernet switch on** option field, select whether Ethernet switch is to be enabled (**yes**) or not (**no**).



NOTE

The Ethernet switch is switched off at delivery. In order to cascade further network components and therefore also incorporate them in an existing network with IEC 61850, the release of the Ethernet switch (option **yes**) is required. For this purpose, connect a Y cable to the Ethernet connector.

Ethernet Communication with Bus Protocol Modbus TCP (see figure 7-27)

- ✧ In the **Bus protocol** list box select the entry **Modbus TCP**.
- ✧ Under **Use a user-port number** select the option **yes** to enter your own port number.

**NOTE**

If you have selected **no** under **Use a user-port number**, you can adjust only the **Access rights for user port 502**, the **Keep Alive time** and the **Communication supervision time** parameters.

-
- ✧ Enter the user port number (≥ 10000) into the **User port number** field.
 - ✧ Under **Access rights for user port**, you can select either the **Full** access rights or **Read only** authorization.
 - ✧ Under **Access rights for user port 502** you can select either the **Full** access rights or **Read only** authorization.
 - ✧ Enter the time in **s** in the **Keep Alive time** field.
 - ✧ Enter the time in **x * 100 ms** into the **Communication supervision time** field.
 - ✧ Click the **Send** button.
After clicking the **Send** button, the parameters are transmitted to the device but not enabled yet (passive set of parameters).
 - ✧ If you do not want to change any other settings, continue with the **Activation** of the device configuration according to chapter 7.3.1.3. If you want to change other settings, enter the changes and then enable the device configuration.

**NOTE**

After changing the network settings and subsequent parameter activation the device will reset.

Ethernet Communication with Bus Protocol Modbus UDP

The screenshot shows the configuration interface for a Siemens SICAM AI Unit 7XV5674. The interface is divided into several tabs: Information, Configure, Value View, and Maintenance. The 'Configure' tab is active, and the 'Communication' sub-tab is selected. The configuration is organized into sections: 'Communication Ethernet' and 'Protocol Modbus UDP'. The 'Communication Ethernet' section includes fields for IP address (192.168.0.55), Subnet mask (255.255.255.0), Default gateway (192.168.0.1), Ethernet switch on (radio buttons for no and yes), and Bus protocol / Operating mode (Modbus UDP). The 'Protocol Modbus UDP' section includes fields for Port number (51000), Access rights (Full), and Communication supervision time (20 * 10 ms). A 'Send' button is located at the bottom of the configuration area.

Parameter	
IP address	192.168.0.55
Subnet mask	255.255.255.0
Default gateway	192.168.0.1
Ethernet switch on	<input checked="" type="radio"/> no <input type="radio"/> yes
Bus protocol / Operating mode	Modbus UDP

Parameter	
Port number	51000
Access rights	Full
Communication supervision time	20 * 10 ms

Figure 7-28 Configure Tab, Communication Ethernet via Modbus UDP Input/Output Window

- ✧ Enter the port number (≥ 10000) into the **Port number** field.
- ✧ Under **Access rights** you can select either the **Full** access rights or **Read only** authorization.
- ✧ Enter the time in $x * 10 \text{ ms}$ into the **Communication supervision time** field..
- ✧ Click the **Send** button.
After clicking the **Send** button, the parameters are transmitted to the device but not enabled yet (passive parameter set).
- ✧ If you do not want to change any other settings, continue with the **Activation** of the device configuration according to chapter 7.3.1.3. If you want to change other settings, enter the changes and then enable the device configuration.

Ethernet Communication with Bus Protocol IEC 61850

- ✧ In the **Bus protocol** list box select the entry **IEC 61850**.
The **Communication Ethernet** input/output window with **Protocol IEC 61850** opens.

The screenshot displays the configuration interface for the SICAM AI Unit 7XV5674. The main window is titled 'Configure Administrative Communication'. The left sidebar contains a tree view with categories like 'Prepare', 'Operational parameters', 'Process connections', 'Select automation functions', 'Administrative', and 'Finish configuration'. The main area is divided into sections for 'Communication Ethernet' and 'Bus protocol IEC 61850'.

Parameter	
IP address	192.168.0.55
Subnet mask	255.255.255.0
Default gateway	192.168.0.1
Ethernet switch on	<input checked="" type="radio"/> no <input type="radio"/> yes
Bus protocol / Operating mode	IEC 61850

General	
IEC 61850 Edition	Edition 1
IED name number	1 [0 to 65534] -> IED name: S_AI_00001
Deadband percentage	2.0 [0.0 % to 10.0 %]

GOOSE Publisher parameters	
GOOSE Control Block name	Goose_20mA_Values
Multicast MAC address	01-0C-CD-01-00-01 [xx-xx-xx-xx-xx-xx] hexadecimal
App ID	3001 [xxxx] hexadecimal
VLAN ID	000 [xxx] hexadecimal
VLAN priority	4 [0 to 7]
Retransmit MIN	10 [1 ms to 500 ms]
Retransmit MAX	2000 [500 ms to 65534 ms]

GOOSE Publishers can be enabled and disabled on 'Maintenance -> GOOSE'.

Buttons: Download ICD file, Download IID file, Send

Fig. 7-29 Configure Tab, Communication Ethernet via IEC 61850 Input/Output Window

- ✧ Select **Edition 1** or **Edition 2** from the **IEC 61850 Edition** list box.

**NOTE**

The device behaves as defined in the respective edition.

When you click the **Download ICD file** button, the ICD file that corresponds to the selected edition is downloaded.

**NOTE**

Clicking the **Download IID file** button the instantiated IED description file will be downloaded. It contains the information from the ICD file with information of the following current configured parameters:

- IP address
- Subnet mask
- Default gateway
- IED name
- Multicast MAC addresses
- App IDs
- VLAN IDs
- VLAN priorities
- Retransmit MINs
- Retransmit MAXs

- ✧ If several SICAM AI Unit devices are used in the substation, change the **IED Name** of the SICAM AI Unit by setting the **IED name number** (factory setting 1).

The number must comply with the number parameterized for this SICAM AI Unit in the configurator of the substation.

The originating IED name is **S_AI_XXXXX**, for example:

IED name number = 72 → results in → IED-Name = **S_AI_00072**

**NOTE**

By stating the **IED name number**, the SICAM AI Unit is clearly identified in the network.

- ✧ Enter a percentage between 0 % and 10 % in the **Deadband percentage** field.

Integrating Deadband Process

The SICAM AI Unit uses an integrating deadband process.

Differences between current and previous measurements of the respective direct current input will be added up until their sum reaches or exceeds the parameterized percentage of the rated current (20 mA). Only in this case the new value will be transmitted to IEC 61850 server and GOOSE. The sum will be reset to 0 after a new value is transmitted.

If 0 % is parameterized for deadband percentage, every change in measurements will be transmitted to IEC 61850 server and GOOSE. This can cause huge traffic in communication.

Example for the Integrating Deadband Process

Adjusted deadband percentage: 5 % (5 % of 20 mA = 1 mA)

Table 7-10 Example for the Integrating Deadband Process

Number of the measuring	Measurement	Difference to previous value	Summed differences	Transmission ?
1	4.0 mA	4.0 mA	4.0 mA	yes
2	4.4 mA	0.4 mA	0.4 mA	no
3	4.9 mA	0.5 mA	0.9 mA	no
4	5.1 mA	0,2 mA	1.1 mA	yes
5	5.4 mA	0.3 mA	0.3 mA	no
6	6.4 mA	1.0 mA	1.3 mA	yes

The following parameters describe the configuration of the GOOSE publisher (20-mA values):

- ✦ Enter the hexadecimal multicast address [xx-xx-xx-xx-xx-xx] in the **Multicast MAC address** field. The **Multicast MAC Address must** be clear.
- ✦ Enter the hexadecimal App ID [xxxx] in the **App ID** field. The **App ID should** be clear (only a warning appears in the System configurator).
- ✦ Enter the hexadecimal VLAN ID [xxx] in the **VLAN ID** field. If no VLAN is available, then is **VLAN ID = 000**.
- ✦ Enter the VLAN priority (0 to 7) in the **VLAN Priority** field.
- ✦ Enter the time (1 ms to 500 ms) in the **Retransmit MIN** field.
- ✦ Enter the time (500 ms to 65 534 ms) in the **Retransmit MAX** field.

**HINWEIS**

The GOOSE Publisher can be activated/deactivated under the tab **Maintenance**, see chapter 7.5.4. The GOOSE Publisher is disabled by default.

- ✦ Click the **Send** button.
After clicking the **Send** button, the parameters are transmitted to the device but not enabled yet (passive set of parameters).
- ✦ If you do not want to change any other settings, continue with the **Activation** of the device configuration according to chapter 7.3.1.3. If you want to change other settings, enter the changes and then enable the device configuration.

**NOTE**

Changing any of the parameters shown under Bus protocol IEC 61850 (see figure 7-29) leads to an automatic restart of the device. Devices that are cascaded via the internal Ethernet switch will be disconnected during the restart of the device.

Download ICD File

- ✧ Click the **Download ICD file** button.
The ICD file of the SICAM AI Unit corresponding to the currently selected edition is downloaded.

Download IID File

- ✧ Click the Download IID file button.
The IID file of the SICAM AI Unit corresponding to the currently activated edition and configured parameters is downloaded.

The IID file for example can be used for setting up reporting when imported to a RTU (e.g. SICAM PQS). Also it can be loaded into a system configuration tool (e.g. System configurator, DIGSI) for setting up GOOSE communication between several devices.

No Ethernet Communication

- ✧ In the **Bus protocol** list box select the entry **-none-**.
If you select **-none-**, no protocol will be available. Click the **Send** button in this case.

After clicking the **Send** button, the parameters are transmitted to the device but not enabled yet (passive set of parameters).
- ✧ If you do not want to change any other settings, continue with the **Activation** of the device configuration according to chapter 7.3.1.3. If you want to change other settings, enter the changes and then enable the device configuration.

7.3.4.3 Serial Communication for Devices with RS485 or Optical Interface

Default Settings and Setting Ranges of the Serial Communication

Table 7-11 Serial Communication Settings






Parameter	Default Setting	Setting Range
Bus protocol	Modbus RTU	-none- Modbus RTU SIPROTEC RTU 20 mA
Bus Protocol Modbus RTU		
Device address	1	1 to 247
Baud rate	19 200 bit/s	Acc. to list box  (see chapter 15)
Parity	Even	Acc. to list box  (see chapter 15)
Access rights	Full	Full Read only
Communication supervision time	600 * 100 ms	0 s = none 100 ms to 6 553 400 ms
Response delay	0 [ms]	0 ms to 1000 ms
If there is an optical interface: Fiber-optic idle state	Light OFF	Light OFF Light ON
Bus Protocol SIPROTEC RTU 20 mA		
MBS mode	8 MBS, simplex	Acc. to list box  (see chapter 15)
Repeat time ¹⁾	600 ms	0 ms to 65 534 ms
Device address ²⁾	1	1 or 2
Baud rate	9600 Bit/s	Acc. to list box  (see chapter 15)

Table 7-11 Serial Communication Settings (cont.)

Parameter	Default Setting	Setting Range
Parity	Even	Acc. to list box  (see chapter 15)
Communication supervision time	600 * 100 ms	0 s = none 100 ms to 6 553 400 ms
If there is an optical interface: Fiber-optic idle state	Light OFF	Light OFF Light ON

- 1) Only visible, if **8 MBS, simplex** is selected as **MBS mode**.
- 2) Only visible, if **8 MBS, half duplex** is selected as **MBS mode**.

To change the serial communication settings, proceed as follows:

- ✧ In the navigation window, click the **Administratives** menu and then the **Communication serial** menu item.
The **Communication serial** input/output window opens.
- ✧ In the **Bus protocol** list box select one of the entries **Modbus RTU**, **SIPROTEC RTU 20 mA** or **none**.
If you select **-none-**, no protocol will be available. Click the **Send** button in this case.

If you select **Modbus RTU** or **SIPROTEC RTU 20 mA** (available depending on the device variant), set the parameters for the corresponding protocol as follows:

Serial Communication via the Modbus RTU Protocol




Fig. 7-30 Configure Tab, Communication Serial via Modbus RTU Input/Output Window

- ✧ Select the entry **Modbus RTU** in the **Bus protocol** list box.
- ✧ Enter the slave address into the **Device address** field.
- ✧ Select the baud rate in the **Baud rate** list box.
- ✧ Select the parity in the **Parity** list box.
- ✧ Under **Access rights** you can select either the **Full** access rights or **Read only** authorization.
- ✧ Enter the time in $x * 100 \text{ ms}$ into the **Communication supervision time** field.
- ✧ Enter the time in $x \text{ ms}$ into the **Response delay** field.
- ✧ Click the **Send** button.

After clicking the **Send** button, the parameters are transmitted to the device but not enabled yet (passive set of parameters).

- ✧ If you do not want to make any additional settings, continue with the **activation** of the device configuration according to **Activating the Set of Parameters**. If you want to change other settings, enter the changes and then enable the device configuration as described in **Activating the Set of Parameters**.

Serial Communication via the SIPROTEC RTU 20 mA Protocol




Fig. 7-31 Configure Tab, Input/Output Window Communication Serial via SIPROTEC RTU 20 mA

- ✧ Select the entry **SIPROTEC RTU 20 mA** in the **Bus protocol** list box.
- ✧ Select the MBS mode in the **MBS mode** list box.
- ✧ Enter the repeat time into the **Repeat time** field.



NOTE

The **Repeat time** field is visible only if **8 MBS, simplex** has been selected as **MBS mode**.

- ✧ Enter the slave address into the **Device address** field.



NOTE


The **Repeat time** field is visible only if **8 MBS, half duplex** has been selected as **MBS mode**.

- ✧ Select the baud rate in the **Baud rate** list box.
- ✧ Select the parity in the **Parity** list box.
- ✧ Enter the time in $x * 100$ ms into the **Communication supervision time** field.
- ✧ Click the **Send** button.
After clicking the **Send** button, the parameters are transmitted to the device but not enabled yet (passive set of parameters).
- ✧ If you do not want to make any additional settings, continue with the **activation** of the device configuration according to **Activating the Set of Parameters**. If you want to change other settings, enter the changes and then enable the device configuration as described in **Activating the Set of Parameters**.

7.3.4.4 Device and Language

Default Settings and Setting Ranges for Device and Language

Table 7-12 Device and Language Settings

Parameter	Default Setting	Setting Range
Device name	[DEVICE]	Max. 32 characters
Language	ENGLISH (US)	ENGLISH (US) DEUTSCH (DE)
Date/time format	YYYY-MM-DD, Time with 24 hours	Acc. to list box  (see chapter 15)
Activation password	000000	Any 6 to 14 characters
Maintenance password	311299	Any 6 to 14 characters

To change the settings of device and language, proceed as follows:

- ⇨ In the navigation window, click the **Administrative** menu and then **Device and language**.

The **Device and language** input/output window opens.




Fig. 7-32 Configure Tab, Device and Language Input/Output Window

7.3.4.4.1 Changing the Parameters

Changing the Device Name

- ✧ Enter the name of the device into **Device name** field.

Changing the Language

- ✧ Select the user interface language of user interface in the **Language** list box.

Changing the Time Format

- ✧ Select the date and time format in the **Date/time format** list box.

7.3.4.4.2 Changing the Passwords

Changing the Activation Password

- ✧ Enter the old activation password in the **Old password** field.
- ✧ Enter the new activation password (any 6 to 14 characters of the keyboard) into the **New Password** field.
- ✧ Repeat the new activation password in the **Repeat new Password** field.

Changing the Maintenance Password

- ✧ Enter the old maintenance password in the **Old password** field.
- ✧ Enter the new maintenance password (any 6 to 14 characters of the keyboard) into the **New password** field.
- ✧ Repeat the new maintenance password in the **Repeat new Password** field.
- ✧ Click the **Send** button.
After clicking the **Send** button, the parameters are transmitted to the device and take effect.

7.3.4.4.3 Finish Configuration

The items in the **Finish configuration** menu in the navigation window are described in chapter 7.3.1, Device Configuration Procedure, in these subsections:

Activation: see **Activating the Set of Parameters**

Save configuration to file: see **Save Configuration to File**

Cancel: see "Cancel"

7.4 Value View

The measured values are displayed in the **Value view** tab. To display the measured values on the screen, proceed as follows:

- ✧ Click the **Value view** tab on the user interface.
The **Value view** tab opens.

20mA Input Terminal	Name	Inst. value	Mean value 10 s	Mean value 1 min	Mean value 1 h	Mean value 1 d	Unit
T1/2	20mA Ch 1 Terminal Block T	Not active	Not active	Not active	Not active	Not active	mA
T4/6	20mA Ch 2 Terminal Block T	Not active	Not active	Not active	Not active	Not active	mA
T3/5	20mA Ch 3 Terminal Block T	Not active	Not active	Not active	Not active	Not active	mA
T7/9	20mA Ch 4 Terminal Block T	Not active	Not active	Not active	Not active	Not active	mA
T11/13	20mA Ch 5 Terminal Block T	Not active	Not active	Not active	Not active	Not active	mA
T15/17	20mA Ch 6 Terminal Block T	Not active	Not active	Not active	Not active	Not active	mA

20mA Input Terminal	Name	Inst. value	Mean value 10 s	Mean value 1 min	Mean value 1 h	Mean value 1 d	Unit
Q1/2	20mA Ch 1 Terminal Block Q	Not active	Not active	Not active	Not active	Not active	mA
Q4/6	20mA Ch 2 Terminal Block Q	Not active	Not active	Not active	Not active	Not active	mA
Q3/5	20mA Ch 3 Terminal Block Q	Not active	Not active	Not active	Not active	Not active	mA
Q7/9	20mA Ch 4 Terminal Block Q	Not active	Not active	Not active	Not active	Not active	mA
Q11/13	20mA Ch 5 Terminal Block Q	Not active	Not active	Not active	Not active	Not active	mA
Q15/17	20mA Ch 6 Terminal Block Q	Not active	Not active	Not active	Not active	Not active	mA

Fig. 7-33 Value View Tab

- ✧ In the navigation window open the **Operational** menu, then the **Process connections** or **Automation functions** submenu and click one of the following items:
 - 20- mA inputs
 - Measurand limits
 - Group indications

Depending on which operational parameters are selected, the input/output window displays the measured values of the measurands with the corresponding unit or indications in a tabular list that is updated every 5 s.



NOTE

If ***** is displayed instead of a measured value, this measured value is invalid or out of measuring range.

The current measuring inputs must be applied with min. 4 mA, so that respective channels are identified as intact. All values below 3.8 mA (measuring tolerance) are displayed as 0 mA and indicate a wire break.

- ✧ To print out the measured values, click the  (**Print**) icon on the toolbar of Microsoft Internet Explorer.

7.5 Maintenance

In the **Maintenance** tab you can:

- Update the firmware
- Perform the calibration
- Perform the simulation
- Make various presettings
- View and delete message logs
- Analyze protocol-specific communication data of Modbus

If you want to edit this tab, you need the Maintenance password.

To open the **Maintenance** tab, proceed as follows:

- ✧ Click the **Maintenance** tab on the user interface.

The **Maintenance** tab opens.




Fig. 7-34 Maintenance Tab

7.5.1 Firmware Upload

During a firmware update, the device firmware, the default set of parameters, text libraries, HTML files or parts thereof are updated.



NOTE

Before updating the firmware, Siemens recommends saving the current parameters set as described in **Save Configuration to File**.



NOTE

If you activated the Web Browser option that the local folder name is transferred in addition to the file name when uploading a file, the total number of characters in the folder name and file names must not exceed 126. Otherwise, the firmware in your device will not be updated.

To update the firmware proceed as follows:

- ✧ Click the **Firmware upload** element in the navigation window.




Fig. 7-35 Maintenance Tab, Firmware Upload - Enable Upload Input/Output Window

- ✧ Enter the maintenance password
- ✧ Click the **Enable upload** button.




Fig. 7-36 Maintenance Tab, Firmware Upload - Open Input/Output Window

- ✧ Click the **Browse...** button.
The **Choose File to Upload** dialog opens.




Fig. 7-37 Choose File Dialog

- ✧ Select the desired update (extension .pck) in the directory.
- ✧ Click the **Open** button.
The selected path is inserted in the input/output window, figure 7-36, into the **Browse...** field.
- ✧ Click the **Open** button.
- ✧ After approx. 2 s, the message **Action was successful!** is displayed in the input/output window.
Device firmware, default set of parameters, text libraries, HTML files or parts thereof are uploaded within one minute.
The device then restarts automatically.



NOTE

Do not switch off the supply voltage during the upload process as this can lead to data loss.

7.5.2 Calibration

Chapter 10 gives a detailed description of the measuring-range calibration of direct current.

It contains:

- Measurement setup
- Calibration procedure

7.5.3 Simulation

In the simulation mode, the measured-value acquisition of the 20-mA inputs is switched off and the values are simulated.

Depending on the configuration of the device, the simulated measured values are transmitted to further devices or to the control center.



NOTE

If the simulation is not active, the message **Simulation mode is not active** appears in the **Simulation** input/output window.

Simulation of the 20-mA inputs and entering the simulated currents in **Simulated current** field are active only when the inputs to be simulated are active in the **Operational parameters** menu → **Process connections** submenu → **20-mA inputs** element (20-mA Channel: T1/2 to T15/17 or Q1/2 to Q15/17).

If the simulation is active, the message **Simulation mode is active** appears in red text in the **Simulation** input/output window.

To simulate the 20-mA inputs, proceed as follows:

- ◇ Click the **Simulation** element in the navigation window.

The **Simulation** input/output window opens.




Fig. 7-38 Maintenance Tab, Simulation Input/Output Window

- ✧ Enter a random value between 0 mA and 20 mA which you want to simulate for the respective channel into the **Simulated current** field.
- ✧ Select the appropriate quality bits (**Failure**, **Invalid**, and **Overload**) which are to be transmitted. For this purpose, set the checkmark (Yes = checkmark set). If no quality bit is checked, the quality is valid.



NOTE

The quality bits describe the properties of the simulated measured values, that for example are transmitted to further devices or to the systems control.

- ✧ In the **Set data attribute „test bit“** option field, select whether the data attribute **test bit** is to be transmitted (**yes**) or not (**no**).



NOTE

The protocol IEC 61850 is the only protocol in which the data attribute **test bit** is transmitted.

If you set the data attribute **test bit**, the systems control recognizes the simulated process.

If you do not set the data attribute **test bit**, the systems control does not recognize the simulated process.

- ✧ Enter the maintenance password into the **Password** field.
- ✧ Click the **Start simulation** button.
The message **Simulation mode is active** appears in red text in the **Simulation** input/output window and the message **Action was successful** appears in the status bar.




Fig. 7-39 Maintenance Tab, Simulation Mode is Active Input/Output Window

If you want to send the values to the control center, proceed as follows:

- ✧ Enter the maintenance password.
- ✧ Click the **Send values** button (see figure 7-39).
The message **Action was successful!** is displayed in the input/output window.

If you want to interrupt the simulation, proceed as follows:

- ✧ Click the **Stop simulation** button (see figure 7-39).

or:

- ✧ Click on a different element in the navigation window or a tab.



NOTE

If you want to exit the input/output window by clicking another element or another tab during the simulation, answer the appearing retrieval to leave the simulation mode with **yes**.

After 20 minutes without clicking the **Start simulation** button, the simulation mode is exited and the device measures the present currents again.

7.5.4 GOOSE

GOOSE Publisher of the device can be activated and deactivated here.




Fig. 7-40 GOOSE Publisher

To enable GOOSE Publishers proceed as follows:

- ✧ Select **GOOSE** Publishers you want to activate or deactivate.
- ✧ Enter the **maintenance password**
- ✧ Click the **Set** button.

Enabling/disabling GOOSE Publishers is equal to writing the GoEna attribute of the corresponding GOOSE control block with an IEC 61850 client. The current state is shown on **Maintenance** → **IEC 61850** HTML page.

The state of enabled and disabled GOOSE Publishers is not stored in device configuration that can be downloaded on tab **Configure** → **Get device configuration**.

7.5.5 Presettings

7.5.5.1 Date/Time

To set the date and time, proceed as follows:

- ✧ In the navigation window, click the **Presets** menu and then **Date/time**.
The **Date/time** input/output window opens.




Fig. 7-41 Maintenance Tab, Preset Date/time

You can either get the date and time from the connected PC or adjust it manually.

Get PC Date and Time

- ✧ In the input/output window, click the **Get PC date/time** button.
The PC time is displayed in the fields of the input/output window and applied in the device.

Setting the Date and Time Manually (24-hour format)

- ✧ In the input/output window enter the desired time into the fields **Day** (format dd), **Month** (format mm), **Year** (format yyyy), **Hour** (format hh) and **Minute** (format mm).
- ✧ Enter the maintenance password into the **Password** field.
- ✧ Click the **Set Date/time** button.
The time you have entered is displayed in the fields of the input/output window and applied in the device.

7.5.6 Message Logs

7.5.6.1 Operational Log

To view and clear the **Operational log** (max. 128), proceed as follows:



NOTE

The last 128 operational indications are displayed, older indications are automatically deleted.

- ✧ In the navigation window, click the **Message Logs** menu and then the **Operational log** menu item. The **Operational log** input/output window opens.




Fig. 7-42 Maintenance Tab, Delete Log

- ✧ Enter the maintenance password into the **Password** field.
- ✧ Click the **Delete log** button in the input/output window.
All operational indications in the input/output window are deleted without backup. The indication no. 0001 appears in the log list: "Clear Operational Log".



NOTE

If you need the operational indications, for example for subsequent analysis, save or print them out as described in chapter 7.2.5.2.

7.5.6.2 Error Logs



NOTE

Error messages are service information that you quote to the service department upon request in case of an error.

To view and clear the **Error log** (max. 128), proceed as follows:

- ✧ In the navigation window, click the **Message Logs** menu and then **Error log**.
The **Error log** input/output window opens.




Fig. 7-43 Maintenance Tab, Delete Error Log

- ✧ Enter the maintenance password into the **Password** field.
- ✧ Click the **Delete log** button in the input/output window.

All error messages in the input/output window are deleted without backup. The indication no. 0001 appears in the log list: ***Error Log Cleared***.



NOTE

If you need the error messages, for example for subsequent analysis, save or print them out as described in chapter 7.2.5.2.

7.5.7 Diagnosis

7.5.7.1 Diagnosis Modbus



NOTE

The data for diagnosing Modbus TCP and/or Modbus RTU are only displayed if you have selected these bus protocols on the **Configure** tab → **Administrative** menu → **Ethernet communication** and **Communication serial** menu items.

For protocols that are not selected, the **Diagnosis Modbus** input/output window shows the entry **-none-**.

- ◇ In the navigation window, click the **Diagnosis** menu and then **Modbus**.
The **Modbus** input/output window opens and the **Modbus TCP** and **Modbus RTU** protocols are displayed. For Modbus TCP the **Standard server** and the **User-port server** are analyzed, for Modbus RTU the **Serial interface** and the **Serial server** are analyzed.

The screenshot shows the Siemens SICAM AI Unit 7XV5674 Maintenance Tab, Diagnosis Modbus Input/Output Window. The window is divided into several sections:

- Navigation:** Information, Configure, Value View, Maintenance (selected).
- Maintenance Tab:** Firmware upload, Calibration, Simulation, GOOSE, Presets, Message logs, Operational log, Error log, Diagnosis (selected).
- Modbus TCP Section:**
 - Parameters for Standard server and User-port server.
 - Table of Modbus TCP parameters:

Parameter	Standard server	User-port server
Port number	502	10000
Maximum connections	2	2
Used connections	0	0
Connection overflows	0	0
Access rights	Full	Full
Communication supervision time	5000 ms	5000 ms

 - Table of Modbus TCP connection statistics:

Parameter	Connection #1	Connection #2	Connection #3	Connection #4
Server port	0	0	0	0
Client IP:Port	0.0.0.0:0	0.0.0.0:0	0.0.0.0:0	0.0.0.0:0
Received bytes	0	0	0	0
Sent bytes	0	0	0	0
Good messages	0	0	0	0
MBAP header errors	0	0	0	0
Exception responses	0	0	0	0
Access rights violations	0	0	0	0

 - Clear counters button.
- Modbus RTU Section:**
 - Parameters for Serial interface and Serial server.
 - Table of Modbus RTU parameters:

Parameter	Serial interface	Serial server
Device address	1	Received bytes 0
Baud rate	19200 bit/s	Sent bytes 0
Parity	Even	Framing errors 0
Access rights	Full	Parity errors 0
Communication supervision time	60000 ms	Broadcast messages 0
Response delay	0 ms	Access rights violations 0

 - Clear counters button.

Fig. 7-44 Maintenance Tab, Diagnosis Modbus Input/Output Window with Protocols Modbus TCP and Modbus RTU

- ◇ To clear the counters for Modbus TCP, click the **Clear counters** button in the **Modbus TCP** section of the input/output window.
All counters in the Modbus TCP section are reset to zero.

- ✧ To clear the counters for Modbus RTU, click the **Clear counters** button in the Modbus RTU section of the input/output window.

All counters in the Modbus RTU section are reset to zero.

**NOTE**

The chapter 9.2.9 gives more details about diagnosing Modbus.

7.5.7.2 Diagnosis SIPROTEC RTU 20 mA

**NOTE**

The diagnostics data of SIPROTEC RTU 20 mA are only displayed if this bus protocol has been selected on the **Configure** tab → **Administrative** menu → **Communication serial** menu item.

If no protocol is selected, the **Diagnosis SIPROTEC RTU 20 mA** input/output window shows the entry **-none-**.

- ✧ In the navigation window, open the **Diagnosis** menu and click the **SIPROTEC RTU 20 mA** menu item. The **SIPROTEC RTU 20 mA** input/output window opens and the protocol is displayed. The **Parameter** and the **Counter** are then analyzed.

Parameter	Counter
Operating mode 8 MBS, simplex	Received bytes 0
Device address 92	Sent bytes 968
Baud rate 9600 bit/s	Good messages 0
Parity Even	Bad messages 0
	Framing errors 0

Fig. 7-45 Maintenance Tab, Diagnosis SIPROTEC RTU 20 mA Input/Output Window

- ✧ To clear the counters for SIPROTEC RTU 20 mA, click the **Clear counters** button. All counters are reset to 0.

**NOTE**

The chapter 9.3.1 provides more details on diagnosing SIPROTEC RTU 20 mA.

7.5.7.3 Diagnosis IEC 61850



NOTE

The diagnostics data of IEC 61850 are only displayed if this bus protocol has been selected on the **Configure** tab → **Administrative** menu → **Communication Ethernet** menu item.

If no protocol is selected, the **Diagnosis IEC 61850** input/output window shows the entry **-none-**.

- ✧ In the navigation window open the **Diagnosis** menu and click the **IEC 61850** menu item.
The **IEC 61850** input/output window opens and the protocol is displayed. The Ethernet interface is then analyzed.




Fig. 7-46 Maintenance Tab, Diagnosis IEC 61850 Input/Output Window

8 Time Synchronization

8.1	General	116
8.2	Internal Time Keeping	116
8.3	External Time Synchronization via Ethernet NTP	117
8.4	External Time Synchronization via Fieldbus	118
8.5	Internal Time Synchronization via RTC	118

8.1 General

During operation, SICAM AI Unit needs the date and time for all time-relevant processes. The term **time** is used throughout this section to refer to both the date and the time.

The time synchronization in the SICAM AI Unit is necessary to guarantee a common time basis for the communication with peripheral devices and time stamping of the process data.

SICAM AI Unit supports both external and internal time synchronization. The type of time synchronization is specified during the parameterization (see chapter 7.3.4.1). The external time synchronization from an NTP server is preferred.

8.2 Internal Time Keeping

8.2.1 Time Format

The internal time is kept in UTC (Universal Time Coordinated) from 01.01.2000, 00:00 to 31.12.2099, 23:59.

To display the local time e.g. on the HTML pages of the user, you can configure a local time correction factor and the automatic adjustment to daylight saving time during parameterization (see chapter 7.3.4.1).

8.2.2 Status Bits

FAIL Status Bit

The **FAIL** status bit implemented in the SICAM AI Unit signals with "0" that the time is **valid** and with "1" that the time is **invalid**.

The status of the FAIL bit corresponds to the "Clock error" operational indication, see chapter 14.

The following table lists the time stamps of events or indications for the displayed operational and error logs according to status bit set/not set using the example of *date 2010-09-26, time 13:49.35246*:

Table 8-1 FAIL Status Bit for Time Synchronization via NTP Server

FAIL	Output
0	2010-09-26 13:49.35:246
1	2010-09-26 13?49?35?246

DST Status Bit

With "1", the **DST** status bit implemented in the SICAM AI Unit signals that the local daylight saving time is active. The operational indication "Daylight saving time" is displayed.

8.3 External Time Synchronization via Ethernet NTP

General

To synchronize the time via an external source, SICAM AI Unit is equipped with an SNTP client (SNTP = Simple Network Time Protocol) that can be connected to 2 NTP servers (NTP = Network Time Protocol), the primary and the secondary (redundant) NTP server.

The chapter 7.3.4.1 describes how to set the parameters of the 2 servers.

NTP is used for external time synchronization via Ethernet. The SNTP client sends a time request to the NTP server once a minute. The time synchronization error is ± 5 ms referred to UTC time of the NTP server.

The time stamp of the NTP server has a 64-bit format. Counting is accomplished in seconds and fractions of seconds.



NOTE

The time format is described in detail in the RFC 5905 (Request for Comments 5905 for NTP).

Time Synchronization Procedure

The device was set to external time synchronization (**Ethernet NTP**) during the parameterization. After switching on or resetting the device, the FAIL bit is first set to "1" (=invalid) and the device sends a time request to the NTP server. After receiving the time information from the NTP server via Ethernet, the FAIL bit is set to "0" (=valid) and the internal timer (RTC) is updated. The SNTP client repeats the time request to the NTP server cyclically once every minute.

If the primary NTP server fails (for example, no response to a request twice or one of the criteria at "Redundant NTP server" satisfied) and if the secondary NTP server is operational (always polled in parallel), the device switches to the secondary NTP server. The FAIL bit remains = 0. In this case, the operational indication "Primary NTP Server Error" is displayed, see chapter 14.

If the secondary NTP server is also invalid, the FAIL bit will be set to 1 after the programmable timer **Error indication after** (see Figure 7-26) has expired, and the "Clock Error" indication is output.

Redundant NTP Servers

The time synchronization supports a primary and a secondary NTP server. Different IP addresses are set for the two NTP servers, see chapter 7.3.4.1.

SICAM AI Unit cyclically polls both NTP servers once every minute, but during normal operation it is synchronized by the primary NTP server. The device automatically switches to the secondary NTP server if one of the following criteria are met:

- No response from the primary NTP server to two successive requests
- The "Alarm" indication is set in the time information of the primary NTP server.
- The primary NTP server responds with zero.
- The message runtime in the network is > 5 ms.
- The stratum of the primary NTP server is 0 (unknown) or > 3 .

Switching to the secondary NTP server is prevented if:

- The secondary server does not provide better time information (see criteria that initiate the switch from primary to secondary NTP server; "Secondary NTP Server Error" indication was already output) or
- The secondary server has recently been available for less than 10 minutes.

In these cases, SICAM AI Unit is not synchronized anymore. The device uses the internal clock (on milliseconds time basis) and the last valid drift. After the programmable delay time, the device reports "Clock Error", see chapter 14.

Switching Back from the Secondary to the Primary NTP Server

While the device is synchronized by the secondary NTP server, it continues to cyclically poll the primary NTP server. The device will only switch back to the primary NTP server if it receives correct time information and if none of the criteria for **Redundant NTP Servers** are fulfilled anymore.



NOTE

The chapter 7.3.4.1, Time Synchronization via Ethernet NTP gives a detailed description of how to parameterize the time. chapter 9.2.7.2 and chapter 9.2.8.2 provide information on the data format.

8.4 External Time Synchronization via Fieldbus

The external time synchronization via fieldbus is used if the device is connected to the systems control via protocol **Modbus RTU** using the RS485 or optical interface.

The time information can also be transmitted from the systems control via **Modbus TCP** or **IEC 61850** using Ethernet interface. When using the Ethernet connection, Siemens recommend, however, to synchronize the device from an NTP server, see chapter 8.3.

When using the external time synchronization via fieldbus, the client should send a message containing the time information to the device in 1-minute cycles, see chapter 9.2.8.2.

The time synchronization error using the **Modbus RTU** protocol is ± 20 ms max.



NOTE

The chapter 7.3.4.1, Time Synchronization via Fieldbus gives a detailed description of how to parameterize the time. chapter 9.2.7.2 and chapter 9.2.8.2 provide information on the data format.

8.5 Internal Time Synchronization via RTC

Besides external time synchronization, the internal time synchronization is also possible using the battery-buffered RTC (Real Time Clock). SICAM AI Unit features a quartz oscillator for this purpose.

The time offset of internal time synchronization is 86 ms/day maximum. Due to the reduced accuracy, RTC should only be used in case of failure or unavailability of the external time synchronization.



NOTE

The chapter 7.3.4.1, Internal Time Synchronization gives a detailed description of how to parameterize the time. chapter 9.2.7.2 and chapter 9.2.8.2 provide information on the data format.

9 Communication

9.1	Communication Features	120
9.2	Modbus	126
9.3	SIPROTEC RTU 20 mA	142
9.4	IEC 61850	143

9.1 Communication Features

SICAM AI Unit supports the communication via Ethernet. Device versions equipped with a serial interface also support communication via RS485 or optical interface.

Simultaneous communication via the Ethernet port and in parallel via the serial interface is possible with the corresponding parameterization. In this case it is possible, for example, to parameterize and read out data via the Ethernet port while the protocol traffic runs with a client via the serial interface.

9.1.1 Ethernet Communication

Via the Ethernet interface the following are supported:

- Parameterization, analysis and diagnosis with HTML pages
- DHCP (Dynamic Host Configuration Protocol) to assign the network configuration (IP address etc.) to clients in an Ethernet network with DHCP server
- Time synchronization via NTP
- Data exchange with connected devices via Modbus TCP or IEC 61850

It is possible to connect 2 devices directly with Ethernet interface due to the integrated Ethernet switch.

9.1.1.1 TCP/IP Protocol Stack

SICAM AI Unit supports the following TCP/IP services:

- TCP/IP IPv4
- DHCP client (Dynamic Host Configuration Protocol)
- NTP (Network Time Protocol)
- HTTP server

9.1.1.2 IP Address

To enable the device to communicate within the Ethernet network, you have to establish a network configuration consisting of IP address, subnet mask and standard gateway.

The device comes delivered with a default IP address that can be restored at any time by pressing the IP-Addr. push-button. Each device also has a unique MAC address.

The default IP address and the default subnet mask are imprinted on the side panel, see Figure 9-1:




Fig. 9-1 DIN Rail Side with IP-Addr. Push-button

Default IP Address and IP-Addr. Push-button

The IP-Addr. push-button is located in the lower right corner of the DIN rail side (see Figure 9-1). When pressed (> 3 s), this button activates the factory-set default IP address. After pressing the IP-Addr. push-button, the device restarts and the IP address and subnet mask are temporarily activated in the default IP network configuration. The customer-specific IP configuration is not overwritten.

The network configuration settings can be displayed and edited on an HTML page during the parameterization (see chapter 7.3.4.2). After a renewed restart the parameterized network configuration is used again.

Check for Twice Assigned IP Address

Serious problems can occur if the same IP address is assigned more than once in a communication network.

For this reason, an ARP request is sent to the own IP address during start-up of the device. If no response is received from the communication network within 2 s, it is assumed that the IP address is not yet used in the network.

Otherwise, the LEDs (see chapter 12.3) signal that the IP address is already assigned and the device is not connected to the network. In this case, you have to specify a different IP address.



NOTE

If the device is directly connected to a PC (without Ethernet switch), the PC will need a longer period to be able to detect the connection and therefore to receive the ARP telegram. In this case it may not be detected when PC and device have the same IP address.

Reception of the Network Configuration from the DHCP Server

The network configuration can also be obtained from an external server. Using the DHCP protocol, the device is integrated into an already existing network.

If the IP address 0.0.0.0 is configured (see chapter 7.3.4.2), the device sends a query to the external DHCP server requesting the network configuration immediately after booting. Having received the network configuration, the device launches the Ethernet services.

If no DHCP server is available, you have to disconnect the device from the network and start it using the default IP address (see chapter 5.7.3) and assign a permanent IP address.

9.1.1.3 Ethernet Interface with Internal Ethernet Switch

SICAM AI Unit is equipped with an Ethernet interface. The data are exchanged via the RJ45 Ethernet plug connector located on the top side of the device.




Fig. 9-2 RJ45 Ethernet Plug Connector

Since the SICAM AI Unit is provided with an internal Ethernet switch, 2 devices with Ethernet interface can be connected (cascaded) via a Y cable.

The Ethernet interface is characterized by the following parameters:

- Transmission rate: 10/100 Mbit/s
- Protocol: IEEE802.3
- Connection: 100Base-T (RJ45), pin assignment according to DIN EN 50173, automatic patch/crossover cable recognition
- Connecting cable: 100 Ω to 150 Ω STP, CAT5 (shielded twisted-pair cable), max. 100 m if well installed

9.1.2 Serial Communication

Devices equipped with an RS485 or optical interface can communicate serially with peripheral devices using the Modbus RTU or SIPROTEC RTU 20 mA fieldbus protocol. The serial interface supports the following actions:

- Transmission of measured data, metered values and indications
- Time synchronization.

Data of the RS485 Interface when Using the Modbus RTU Protocol

The RS485 interface comes with the following parameters set by the manufacturer:

- Bus protocol: Modbus RTU
- Device address: 1
- Baud rate: 19 200 bit/s
- Parity: even
- Access rights: Full
- Communication supervision time: 600 * 100 ms
- Response delay: 0 ms

You can modify these parameters during the parameterization, see chapter 7.3.4.3.

The connection is a 9 pin D-sub connector plug.

Data of the RS485 Interface when Using the SIPROTEC RTU 20 mA Protocol

The RS485 interface comes with the following parameters set by the manufacturer:

- Bus protocol: SIPROTEC RTU 20 mA
- MBS mode ¹⁾: 8 MBS, simplex
- Repeat time ²⁾: 600 ms
- Device address ³⁾: 1
- Baud rate ¹⁾: 9600 bit/s
- Parity ¹⁾: even
- Communication supervision time ¹⁾: 600 * 100 ms

The parameters, except for the parity, can be changed during the parameterization, see chapter 7.3.4.3.

The connection is a 9-pin D-sub connector plug.

- 1) For possible selection, see chapter 15
- 2) Only visible if **MBS mode = 8 MBS, simplex**
- 3) Only visible if **MBS mode = 8 MBS, half duplex**

Data of the Optical Interface when Using the Modbus RTU Protocol

The optical interface comes with the following parameters set by the manufacturer:

- Bus protocol: Modbus RTU
- Device address: 1
- Baud rate: 19 200 bit/s
- Parity: Even
- Access rights: Full
- Communication supervision time: 600 * 100 ms
- Response delay: 0 ms
- Fiber optical idle state: Light off

You can modify these parameters during the parameterization, see chapter 7.3.4.3.

The connection is an ST connector BFOC/2.5 for sending and receiving, 820 nm.

Data of the Optical Interface when Using the SIPROTEC RTU 20 mA Protocol

The optical interface comes with the following parameters set by the manufacturer:

- Bus protocol: SIPROTEC RTU 20 mA
- MBS mode ¹⁾: 8 MBS, simplex
- Repeat time ²⁾: 600 ms
- Device address ³⁾: 1
- Baud rate ¹⁾: 9600 bit/s
- Parity ¹⁾: even
- Communication supervision time ¹⁾: 600 * 100 ms
- Fiber optical idle state: Light off

You can modify these parameters during the parameterization, see chapter 7.3.4.3.

The connection is an ST connector BFOC/2.5 for sending and receiving, 820 nm.

1) For possible selection, see chapter 15

2) Only visible if **MBS mode = 8 MBS, simplex**

3) Only visible if **MBS mode = 8 MBS, half duplex**

Location of the Serial Interface on the Device




Fig. 9-3 Position of the D-sub Socket (RS485 interface) of SICAM AI Unit




Fig. 9-4 Position of the ST Connector (Optical Interface) of SICAM AI Unit



NOTE

The pin assignment of the serial interface is described in chapter 13.1.3.

9.2 Modbus

When communicating via Ethernet, the Modbus TCP protocol is used; communication via RS485 relies on the Modbus RTU protocol. The Modbus specification with a detailed explanation of the Modbus protocol is provided in:

- Modbus over Serial Line
Specification & Implementation Guide
<http://www.modbus.org>
- Modbus Application Protocol Specification
<http://www.modbus.org>
- Modbus Messaging on TCP/IP Implementation Guide
<http://www.modbus.org>

9.2.1 Modbus Functions



NOTE

The Modbus functions are the same for Modbus TCP (Ethernet) and Modbus RTU (serial).

The Modbus server of SICAM AI Unit supports the following Modbus functions:

Table 9-1 Supported Modbus Functions

Function Number	Function Name	Description
03 (03H)	Read Holding Registers	Reading one or more holding registers from the Modbus server Up to 125 registers can be read with one message.
06 (06H)	Write Single Register	Writing a holding register Function 16 is used for writing multiple holding register using one Modbus message.
16 (10H)	Write Multiple Registers	Writing one or more holding registers Up to 123 registers can be written with one message.

9.2.2 Exception Responses



NOTE

The exception responses for Modbus TCP (Ethernet) and Modbus RTU (serial) are the same.

The Modbus server performs a series of consistency checks of the Modbus client requests, and if errors (e.g. request to read a nonexistent register) are detected, it generates Modbus exception codes which are signaled to the Modbus client in exception responses messages.

The messages contain the following codes:

Exception Code 01 **ILLEGAL_FUNCTION**

- The Modbus client uses a function that is not supported by the Modbus server of the SICAM AI Unit (the supported Modbus functions are listed in chapter 9.2.1).

Exception Code 02 **ILLEGAL_DATA_ADDRESS**

- An attempt is made to read out or write to a nonexistent Modbus register (see chapter 9.2.8, Modbus mapping for valid registers).
- An attempt is made to read out or write to too many registers. A Modbus message enables reading out 125 holding registers and writing to 123 holding registers maximum.
- The Modbus clients tries to write to a register in the Modbus server for which only read access is allowed according to the Modbus mapping (see chapter 9.2.8).

Exception Code 03 **ILLEGAL_DATA_VALUE**

- The Redundanz client addresses a register that does not allow access to partial data because it is part of a data type with a complex data structure distributed across several registers and can be read or written only as a whole.
- The Modbus client attempts to write to the Modbus server for which the access rights are set to "read only".

Exception Code 04 **SERVER_FAILURE**

- Error during the time format conversion in the Modbus server because a faulty date/time format was received via Modbus (for example month format > 12).

9.2.3 Modbus TCP

Properties of the Modbus TCP

- Connection-oriented Ethernet protocol based on TCP/IP
- Use of IP addresses for addressing individual components connected to the bus (bus nodes)
- The Modbus TCP protocol has the TCP port number 502 reserved on the server side. It is possible to use a parameterized port number.
- All data types in the Modbus TCP messages which are larger than 1 byte, are stored in the Big-endian format, that is the most significant byte (MSB) is stored at the lowest register address and is transmitted first.
- Communication sequence:
 - The client sends a request to the server to start a data transfer from the server to the client.
 - If the requested data are unavailable, the server sends an exception response to the client.
- The Modbus TCP data packet has a maximum size of 260 bytes:
 - 253 bytes max. for data and
 - 7 bytes for the Modbus TCP header

Parameterization

The following parameters can be set for the Modbus TCP bus protocol, see also chapter 7.3.4.2:

Table 9-2 Modbus TCP Settings

Parameter	Default Setting	Settings
IP address	192.168.0.55	any, 0.0.0.0 for DHCP
Subnet mask	255.255.255.0	any
Default gateway	192.168.0.1	any
Ethernet switch on	no	no yes
Bus protocol / Operating mode	Modbus TCP	-
Use a user-port number	no	no yes
User-port number (only if <i>Use a user-port number</i> yes has been parameterized)	10000	10000 to 65535
Access rights for user port 502	Full	Full Read only
Access rights for user port (only if <i>Use a user-port number</i> yes has been parameterized)	Full	Full Read only
Keep Alive time	10 s	0 s = switch off 1 s to 65 535 s
Communication supervision time	50 * 100 ms	0 s = none 100 ms to 6 553 400 ms

Number of Connections

Up to four TCP connections are possible:

- Without user port number: 4 connections via standard port 502
- With user port number: 2 connections via standard port 502 and 2 connections via the user port

9.2.4 Modbus UDP

Properties Modbus UDP

- Connectionless, asynchronous client-server communication via Ethernet protocol on the basis of UDP/IP
- Use of IP addresses for addressing individual components connected to the Bus (bus stations)
- Use of a parameterized port number (see Table 9-3)
- All data types in the Modbus UDP telegrams that are bigger than 1 byte, are stored in the Big-Endian format, that is, the most significant byte (MSB) is saved on the least significant register address and is transferred first.
- Sequence of the communication:
 - In order to start data transfer from server to client, the client sends a request to the server.
 - If the requested data is not available, the server sends the client the requested data or an error feedback.
- The Modbus data in the UDP telegram has a maximum size of 260 bytes:
 - Maximum of 253 bytes for data and
 - 7 bytes for Modbus UDP header

The following parameters can be set for the Modbus UDP:

Table 9-3 Modbus UDP Settings

Parameter	Default Setting	Settings
IP address	192.168.0.55	Any, 0.0.0.0 for DHCP
Subnet mask	255.255.255.0	Any
Default gateway	192.168.0.1	Any
Bus protocol	Modbus UDP	-
Port number	51000	10000 to 65535
Access rights	Full	Full Read only
Communication supervision time	20 * [10 ms]	0 s = invalid 10 ms to 60 000 ms

9.2.5 Modbus RTU

Properties of the Modbus RTU

- Client-server protocol
- All clients have a unique address in the range from 1 to 247.
- Packets with the address = 0 are forwarded to all clients (broadcast).
- The individual data bytes in the messages are transmitted asynchronously with 11 bits.
 - 1 start bit,
 - 8 data bits,
 - 1 parity bit and 1 stop bit or
 - No parity bit and 2 stop bits
- Single messages are separated by bus silent intervals of at least 3.5 character times and end with a CRC code for error detection.
- RS485 is used as bus physics.
- The Modbus RTU data packet has a maximum size of 256 bytes.
 - 1 byte server address
 - 253 bytes for data
 - 2 bytes for CRC

The following parameters can be set for the Modbus RTU bus protocol:

Table 9-4 Modbus RTU Settings

Parameter	Default Setting	Setting Range
Device address	1	1 to 247
Baud rate	19 200 bit/s	1200 bit/s, 2400 bit/s 4800 bit/s, 9600 bit/s 19 200 bit/s, 38 400 bit/s 57 600 bit/s, 115 200 bit/s
Parity	Even	None, 1 stop bit Even Odd None, 2 stop bits
Access rights	Full	Full Read only
Communication supervision time	600 * 100 ms	0 s = none 100 ms to 6 553 400 ms
Response delay	0 [ms]	0 ms to 1000 ms
If there is an optical interface: Fiber-optic idle state	Light OFF	Light OFF Light ON

9.2.6 Register Assignment

Only holding registers are used for SICAM AI Unit. All measured values, indications and metered values are stored in these holding registers.

9.2.7 Data Types



NOTE

The Modbus functions for Modbus TCP (Ethernet) and Modbus RTU (serial) are the same.

The following data types are used for storing variables in the Modbus registers.

- Measured value
- Date/time
- Indication (read only)



NOTE

The following convention applies when storing variables to the Modbus holding register that consist of more complex data types (that is variables that are larger than a holding register, for example 32-bit measured values):


The register with the lowest address contains the most significant byte (MSB), the register with the highest address contains the least significant byte (LSB).

9.2.7.1 Data Type - Measured Value

The *Measured Value* data type is transferred into 2 holding registers in 32-bit floating-point format (single precision) according to IEEE standard 754.

Structure of the Format

The 32-bit floating-point format consists of a sign bit (S), exponent and mantissa:



Value Range

The 32-bit floating-point format has the value range: $\pm(10^{-38}$ to 10^{+38}).

Value of the Measured Values

The value of a measured value is obtained as follows:

Exponent = 0: Resulting value = 0

Exponent = 255, mantissa = 0: Resulting value = $(-1)^{\text{sign}} * +\text{Inf}$

Exponent = 255, mantissa not equal to 0: Resulting value = NaN

$0 < \text{Exponent} < 255$: Resulting value = $(-1)^{\text{sign}} * 2^{(\text{exponent} - 127)} * 1, \text{ <mantissa>}$

Status and Quality Information

SICAM AI Unit uses floating-point values with the exponent 255 (Inf, NaN) to display status information of the measured values:

Table 9-5 Floating-point Values

Floating-point Value (hexadecimal)		State	Remark
7F800000H	+Inf	Overflow	Measured value overflow ($> 1.2 V_{\text{rated}}, > 2 I_{\text{rated}}$)
7F800001H	NaN	invalid	For example, frequency not measured because mains voltage too small ($< 15 \% V_{\text{rated}}$)
7F800002H	NaN	not calculated	Measured value is not calculated, for instance because it does not exist in the selected network type.

Accuracy of the Floating-point Numbers


The 32-bit floating-point numbers have a 23-bit mantissa. Integer numbers can be represented in the following ranges without loss of accuracy:

- Binary: $\pm(1)111\ 1111\ 1111\ 1111\ 1111\ 1111$
- Hexadecimal: $\pm FF\ FF\ FF$
- Decimal: ± 16777216

32-bit floating-point numbers are accurate to about 7 decimal digits. An accuracy of 4 decimal digits (0.2 measuring error) is required for measuring alternating current quantities.

9.2.7.2 Data Type - Date/Time

The *Date/Time* data type is used to transmit the local time. The following format is used:



Date/time Status

10H set: Daylight saving time active

20H set: Date/time error (equivalent to FAIL bit in Table 8-1).



NOTE

For the time synchronization via Ethernet, Siemens recommends the use of NTP, see chapter 8.

9.2.7.3 Data Type - Indications (Read Only)

The *Indications* data type is represented by two bits in holding registers:

Q	V	Q	V	Q	V	Q	V	Q	V	Q	V	Q	V	Q	V
Indication 8		Indication 7		Indication 6		Indication 5		Indication 4		Indication 3		Indication 2		Indication 1	

e.g. Holding register 0101

Where:

- Q: status/quality bit: 0 = OK, 1 = invalid
- V: Value bit: 0 = OFF, 1 = ON

Status or Quality Bit "Q"

An indication is invalid if the result of a calculation is based on an invalid measured value, for example the calculated limit value of an invalid measured value. If the indication is invalid, the quality bit is set to "1". The value bit can be ignored in this case.

Example: The system frequency is invalid if the voltage is smaller than 15 % of the rated voltage when measuring the frequency. Any limit violation indication based on this value is also invalid.

For indications that are always valid, for example the internal device indication *Device OK*, "0" is transmitted as the quality bit.

Value Bit "V"

The value bit indicates whether an indication is ON (=1) or OFF (=0).

9.2.8 Data in the Modbus Registers (Data Mapping)



NOTE

The data for Modbus TCP (Ethernet) and Modbus RTU (serial) in the Modbus registers are the same.

The indications, measured values etc. are stored in Holding registers. The following register groups exist. They are described in the following sections:

- Register 0001 to 0048: Device identification (read only)
- Register 0065 to 0068: Date and time (read and write)
- Register 0071 to 0088: Version information (read only)
- Register 0101: Device status (read only)
- Register 0111 to 0112: Indications concerning limit violations (read only)
- Register 0401 to 0424: Measured values (read only)

9.2.8.1 Register 0001 to 0048: Device Identification

These registers are write protected. A write attempt will be rejected with exception code 03 (ILLEGAL_DATA_VALUE).

Table 9-6 Register 0001 to 0048: Device Identification

Register	Type of Information	Remark
0001 to 0008	Device type (string, max. 16 characters)	"SICAM AI Unit"
0009 to 0024	Device ordering code (string, max. 32 characters)	Example: "7XV56740KK302AA1"
0025 to 0040	Device name from the configuration (string, max. 32 characters)	Example: "SICAM AI Unit #1"
0041 to 0048	Device serial number (string, max. 16 characters)	Example: "BF0704034576"

9.2.8.2 Register 0065 to 0068: Date and Time

The date and time can be transmitted in 64-bit format or in 32-bit format.

64-bit Format

The 4 registers 0065 to 0068 (time and date) are transmitted in one message.

32-bit Format

The registers are transmitted in two messages. The first message contains the registers 0067 and 0068 (date), the second message contains the registers 0065 and 0066 (time).

The time synchronization only takes effect when the time has been completely transmitted.

Data type: Date/time

Table 9-7 Register 0065 to 0068: Date and Time

Register	Type of Information	Remark
0065	Milliseconds	see chapter 9.2.7.2
0066	Hours/minutes	
0067	Month/day	
0068	Time status/year	

9.2.8.3 Register 0071 to 0088: Version Information

These registers are write protected. A write attempt will be rejected with exception code 03 (ILLEGAL_DATA_VALUE).

Table 9-8 Register 0071 to 0088: Version Information

Register	Type of Information	Remark
0071 to 0076	Boot version	e.g. „V01.10.01“
0077 to 0082	Firmware version	e.g. „V01.10.01“
0083 to 0088	Parameter set version	e.g. „V01.10.01“

9.2.8.4 Register 0101: Device Status

This register is write protected. A write attempt will be rejected with exception code 03 (ILLEGAL_DATA_VALUE).

Data type: indication

Table 9-9 Register 0101: Device Status

Register	Type of Information	Remark
0101/2 ⁰	Device ready	1 = Device ready
0101/2 ²	Battery failure	0 = Battery OK, 1 = Battery failure (exchange battery)
0101/2 ⁴	Reserved	= 0
0101/2 ⁶	Reserved	= 0
0101/2 ⁸	Settings Load	1 = Load settings
0101/2 ¹⁰	Settings Check	1 = Check settings
0101/2 ¹²	Settings Activate	1 = Activate settings
0101/2 ¹⁴	Reserved	= 0



NOTE

Registers between 0103 and 0141 that are not shown can be read too during requests and return the value 0.

9.2.8.5 Register 0111 and 0112: Limit Violation Indications

These registers are write protected. A write attempt will be rejected with exception code 03 (ILLEGAL_DATA_VALUE).

Data type: indication

Table 9-10 Register 0111 and 0112: Limit Violation Indications

Register	Type of Information	Remark
0111/2 ⁰	Limit Violation 1	An indication is output (= 1) if a measured value has exceeded or fallen below a configured limit value, see chapter 7.3.3.2.
0111/2 ²	Limit Violation 2	
0111/2 ⁴	Limit Violation 3	
0111/2 ⁶	Limit Violation 4	
0111/2 ⁸	Limit Violation 5	
0111/2 ¹⁰	Limit Violation 6	
0111/2 ¹²	Limit Violation 7	
0111/2 ¹⁴	Limit Violation 8	
0112/2 ⁰	Limit Violation 9	An indication is output (= 1) if a measured value has exceeded or fallen below a configured limit value, see chapter 7.3.3.2.
0112/2 ²	Limit Violation 10	
0112/2 ⁴	Limit Violation 11	
0112/2 ⁶	Limit Violation 12	
0112/2 ⁸	Limit Violation 13	
0112/2 ¹⁰	Limit Violation 14	
0112/2 ¹²	Limit Violation 15	
0112/2 ¹⁴	Limit Violation 16	

9.2.8.6 Registers 0401 to 0424: Measured Values

These registers are write protected. A write attempt will be rejected with exception code 03 (ILLEGAL_DATA_VALUE).

Data type: Measured value

Table 9-11 Registers 0401 to 0424: Measured Values

Register	Type of Information	Remark	Unit
0401	DC_measurand_1	Analog input 1	mA
0403	DC_measurand_2	Analog input 2	mA
0405	DC_measurand_3	Analog input 3	mA
0407	DC_measurand_4	Analog input 4	mA
0409	DC_measurand_5	Analog input 5	mA
0411	DC_measurand_6	Analog input 6	mA
0413	DC_measurand_7	Analog input 7	mA
0415	DC_measurand_8	Analog input 8	mA
0417	DC_measurand_9	Analog input 9	mA
0419	DC_measurand_10	Analog input 10	mA
0421	DC_measurand_11	Analog input 11	mA
0423	DC_measurand_12	Analog input 12	mA

9.2.9 Modbus Diagnosis

The diagnostics function for Modbus TCP and Modbus RTU, see chapter 7.5.7.1, enables analyzing the parameters and the communication and resetting diagnostics counters.

9.2.9.1 Modbus TCP Diagnosis




Fig. 9-5 Modbus TCP Diagnosis

Parameter for Standard Server and User-port Server

- Port number: Standard port 502 and configured user port
- Number of connections: For user port number 502: 4 connections via standard port 502
For other user port numbers: 2 connections via standard port 502 and 2 connections via the user port
- Used connections: Number of connections that are actually used
- Connection overflow: Counter of the attempts to establish more connections than allowed;
Number of allowed connection attempts:
For user port number 502: ≥ 5 connection attempts via standard port 502
For other user port numbers: ≥ 3 connection attempts via standard port 502 and/or ≥ 3 connection attempts via user port
- Status of the access rights: Factory setting: Full
- Monitoring time of the communication: Factory setting: 5000 ms

Parameter of Connections

- Server port: Server port number of the current connection in the respective column; if "0" is displayed, the connection is inactive or down
- Client IP:Port: Last or current IP address and port number of the client
- Received bytes: Total number of bytes received by the TCP port
- Sent bytes: Total number of bytes sent to the TCP port
- Good messages: Total number of messages received that were detected as valid Modbus messages
- MBAP header error: Error in the MBAP header: incorrect protocol ID or implausible length of data
- Exception responses: Counters of the transmitted exception response messages (see chapter 9.2.2)
- Access rights violations: Total number of write accesses received if the parameter **Access rights for port xxx** is set to **Read only** of the associated TCP port (e.g. 502) in the **Communication Ethernet** input/output window (see see chapter 7.3.4.2)

9.2.9.2 Modbus RTU Diagnosis

▼ Modbus RTU					
Parameter		Serial interface		Serial server	
Device address	1	Received bytes	0	Good messages	0
Baud rate	19200 bit/s	Sent bytes	0	CRC errors	0
Parity	Even	Framing errors	0	Exception responses	0
Access rights	Full	Parity errors	0	Broadcast messages	0
Communication supervision time	60000 ms			Access rights violations	0
Response delay	0 ms				

Clear counters

Fig. 9-6 Modbus RTU Diagnosis

Parameter

The following parameters are displayed with Modbus RTU:

- Device address: Default setting: 1
- Baud rate: Default setting: 19 200 bit/s
- Parity: Default setting: Even
- Access rights: Default setting: Full
- Communication supervision time: Default setting: 60 000 ms
- Response delay: Default setting: 0 ms
- Fiber optical idle state (at FO interface): Default: Light OFF

Serial Interface

- Bytes received: Total number of bytes received by the RS485 interface
- Bytes sent: Total number of bytes sent to the RS485 interface
- Frame error: Number of detected frame errors (invalid stop bit, e.g. if the baud rate is wrong)
- Parity error: Number of detected parity errors (wrong parity)

Serial Server

- Correct messages: Total number of messages received that were detected as valid Modbus messages
- CRC error: Total number of messages received in which CRC errors were detected
- Exception responses: Counters of the transmitted exception response messages (see chapter 9.2.2)
- Broadcast messages: Total number of the broadcast messages received with the server address 0
- Access rights violations: Total number of write accesses received if the parameter **Access rights** is set to **Read only** in the **Communication serial** input/output window (see see chapter 7.3.4.3)

9.3 SIPROTEC RTU 20 mA

The SIPROTEC RTU 20 mA protocol can also be applied for communication via RS485 or optical interface.

SIPROTEC RTU 20 mA is an ASCII-based protocol. With this protocol, the communication between SICAM AI Unit and compatible SIPROTEC 4 devices (6MD66) is realized.

9.3.1 Diagnosis SIPROTEC RTU 20 mA

The diagnosis for SIPROTEC RTU 20 mA, see chapter 7.5.7.2, allows an analysis of the parameters and communication as well as a reset of the diagnosis counters.




Fig. 9-7 SIPROTEC RTU 20 mA Diagnosis

Parameter

With SIPROTEC RTU 20 mA, the following parameters are displayed:

- Operating mode: Default setting: 8 MBS, simplex
- Device address: Default setting: 1
- Baud rate: Default setting: 9600 Bit/s
- Parity: Default setting: Even

Counter

For the counter, the following parameters are displayed:

- Received bytes: Total number of bytes received by the serial port
- Sent bytes: Total number of bytes sent to the serial port
- Good messages: Total number of protocol messages
- Bad messages: Number of defective protocol messages
- Framing errors: Number of detected frame errors (invalid stop bit, for example if the baud rate is wrong)

9.4 IEC 61850



NOTE

The IEC 61850 specification is described in the manual *SICAM AI Unit 7XV5674, IEC 61850, PIXIT, PICS, TICS*, order number E50417-C1040-C484; see Internet: <http://www.siprotec.com>.

9.4.1 General I/O Processes

Table 9-12 Limit Violations

inst		1
desc		Limit violations
InClass		GGIO
InName		MEAS/GGIO1
Data Objects	CDC	
Status Information		
Alm1~16	SPS	Limit violations 1 to 16

Table 9-13 Group Indications

inst		2
desc		Group indications
InClass		GGIO
InName		MEAS/GGIO2
Data Objects	CDC	
Status Information		
Ind1~4	SPS	Group indications 1 to 4

Table 9-14 Analog Inputs

inst		1
desc		Analog inputs
InClass		GGIO
InName		MEAS/ma20/GGIO1
Data Objects	CDC	
Status Information		
AnIn1~12	MV	Analog inputs 1 to 12

Table 9-15 10-s Mean Value of the Analog Input Values

inst		1
desc		10-s mean value of the analog input values
InClass		GGIO
InName		MEAS/m10sGGIO1
Data Objects	CDC	
Status Information		
AnIn1~12	MV	10-s mean value of the analog input values 1 to 12

Table 9-16 1-min Mean Value of the Analog Input Values

inst		1
desc		1-min mean value of the analog input values
InClass		GGIO
InName		MEAS/m1minGGIO1
Data Objects	CDC	
Status Information		
AnIn1~12	MV	1-min mean value of the analog input values 1 to 12

Table 9-17 1-h Mean Value of the Analog Input Values

inst		1
desc		1-h mean value of the analog input values
InClass		GGIO
InName		MEAS/m1hGGIO1
Data Objects	CDC	
Status Information		
AnIn1~12	MV	1-h mean value of the analog input values 1 to 12

Table 9-18 24-h Mean Value of the Analog Input Values

inst		1
desc		24-h mean value of the analog input values
InClass		GGIO
InName		MEAS/m1dGGIO1
Data Objects	CDC	
Status Information		
AnIn1~12	MV	24-h mean value of the analog input values 1 to 12

Table 9-19 Battery

inst		1
desc		Battery status
InClass		ZBAT
InName		MEAS/ZBAT1
Data Objects	CDC	
Status Information		
Vol	MV	Battery voltage (not available, invalid)
BatLo	SPS	Battery failure (undervoltage or battery is missing)

9.4.2 Diagnosis IEC 61850

The diagnosis for IEC 61850, see chapter 7.5.7.3, allows the analysis of parameters and communication.




Fig. 9-8 Diagnosis IEC 61850

Statuses

With IEC 61850, the following statuses are displayed:

IEC 61850 Communication status: Status of communication: OK or Fail

Port number: Set port number, for example 102

Information

IED Name: Default: S_AI_00001

GOOSE Publishers

Goose_20mA_Values Default: disabled

10 Calibration

10.1	General	150
10.2	Calibrating the Direct-Current Measuring Range	151

10.1 General

Calibration Due to Internal Requirements

The device comes calibrated from the factory and does not have to be calibrated again throughout its entire operation period. The calibration is only carried out if this is necessary due to internal requirements.

Direct-Current Reference

To calibrate the SICAM AI Unit, a DC supply as reference is required which generates direct currents with a tolerance of max. 0.02 % of the rated current of infeed.



NOTE

Measured values are entered or displayed with a decimal point separating the integral and the fractional parts, for example 19.8 mA.



NOTE

You have to observe the specifications and execution instructions of the accident prevention regulation BGV A3. Use appropriate electric tools.

10.2 Calibrating the Direct-Current Measuring Range

Measurement Setup




Fig. 10-1 Measurement Setup for Calibrating the Direct-Current Measuring Range

To calibrate a channel, a DC supply with the reference current between 19 mA and 21 mA is connected to the respective channel of the terminal block.

The setup for channel 1 of the terminal block T (as shown in figure 10-1) can be applied to calibrate all other channels of the terminal blocks T and Q.

Calibration

To calibrate the direct-current measuring ranges, proceed as follows:

- ◇ Set up the measurement as shown in figure 10-1 for each channel.



DANGER

Danger by high contact voltages when attaching the measuring lines to the terminal blocks

Non-observance will lead to death or serious injury.

- Work may only be carried out by trained personnel (see Preface) who are familiar with and observe the safety requirements and precautions.
- Work may never be carried out if there is any hazardous voltage present.
- Deenergize the device.
- **Circuit breaker:** A suitable isolating device shall be connected upstream in order to permit disconnection of the device from the power supply. The circuit breaker must be mounted close to the device, be easily accessible to the user and marked as a circuit breaker for the device.
- Secure the supply voltage with an approved (UL/IEC) fuse: 1.6 A, type C.
- If a melting fuse is used, a suitable approved (UL/IEC) fuse holder has to be used.

- ◇ On the rear plate of the device, connect the supply voltage at the terminal block H acc. to chapter 5.3.2.

- ◇ Start the device as described in chapter 5.7.

10.2 Calibrating the Direct-Current Measuring Range

- ✧ Activate the 20-mA Channels to be calibrated in the **Configure** tab → **20-mA Inputs** element:




Fig. 10-2 Activation of 20-mA Inputs for the Calibration

- ✧ Click the **Maintenance** tab on the User Interface.
The **Maintenance** tab opens.
- ✧ Click the **Calibration** element in the navigation window.
The **Calibration** input/output window opens.




Fig. 10-3 Calibrating the Direct-Current Measuring Range

- ✧ Enter the maintenance password into the **Password** field.
- ✧ Select the channel to be calibrated in the **20-mA Channel** list box.
- ✧ Enter the reference current between 19 mA and 21 mA into the **Reference current** field.
- ✧ Click the **Calibrate current** button.
The device executes the calibration and in case of successful calibration, an appropriate status indication appears after a few seconds.
- ✧ Check the calibrating values in the **Value View** tab → **20-mA Inputs** element.

**NOTE**

Carry out the operation for all other active 20-mA Channels.

11 Maintenance, Storage, Transport

11.1	Maintenance	156
11.2	Storage	156
11.3	Transport	156

11.1 Maintenance

Except for a battery replacement, the SICAM AI Unit is maintenance-free.

Wipe the device using a clean, dry and soft cloth if necessary. Do not use solvents.

The product information enclosed with the device describes how to replace the battery.

11.2 Storage

Store the device in a dry and clean location. Store the device within a temperature range from -25 °C to +70 °C (-13 °F to +158 °F).

The relative humidity must not lead to condensation or ice formation.

To avoid premature aging of the electrolytic capacitors, store the device within the recommended temperature range of +10 °C to +35 °C (+50 °F to +95 °F).

Siemens furthermore recommends connecting the device to supply voltage once a year for 1 to 2 days in order to form the inserted electrolytic condensers. This procedure should also be carried out before operating the device.



NOTE

In this context, pay attention to the commissioning notes in chapter 5.7.

The Lithium-batteries in our equipment are subject to Special Provision 188 of the UN Recommendations on the Transport of Dangerous Goods Model Regulations and Special Provision A45 of the IATA Dangerous Goods Regulation and the ICAO Technical Instructions. This is only valid for the original battery or original spare batteries.

11.3 Transport

If devices are to be shipped elsewhere, you can reuse the transport packaging. When using different packaging, you must ensure that the transport requirements according to ISO 2248 are adhered to. The storage packaging of the individual devices is not adequate for transport purposes.

12 Failures and LED Indications

12.1	General Inspection	158
12.2	Commissioning during Failures	159
12.3	Indications Signaled by LEDs	161
12.4	Troubleshooting and Repair	165

12.1 General Inspection

Visual Inspection

If function failures occur, first check the device visually. Observe the following points when inspecting the device visually:

- Correct installation of the device as described in chapter 5.2 at the intended location
- Compliance with the ambient conditions specified in chapter 13.1.4 of the technical data
- Correct connection of supply voltage and grounding conductors according to chapter 5.3
- Correct connection of measuring and communication lines according to chapter 5.7.1

Function Checks

Additionally, check the following aspects:

- Correct functioning of peripheral devices (e.g. connected PC, series-connected current transformers)
- Compliance with the system requirements specified in chapter 5.4
- Compliance with the access rights according to chapter 5.5
- Compliance with the commissioning sequence of the device according to chapter 5.7
- Evaluation of the LED failure indications, see chapter 12.3.

12.2 Commissioning during Failures

12.2.1 Automatic Start of the Boot Loader

If a firmware update has failed or the device startup was unsuccessful, Internet Explorer will automatically open the HTML page **Boot Loader**, see Figure 12-1.



Fig. 12-1 Boot Loader

Starting User Interface without Loading a New/Different Firmware

- ✧ Click the **Run Application** button. The following message appears:




Fig. 12-2 Boot Loader Message of Run Application

- ✧ Wait for at least 20 s and then click the **home** link.
The User Interface opens.

Starting User Interface with Loading a New/Different Firmware

- ✧ Click the **Browse...** button.
The **Choose file** dialog box opens.
- ✧ In the **Choose file** dialog box select the current firmware update (file extension .pck) in the **Look in:** list box and click the **Open** button.
The path appears in the **Browse...** field.
- ✧ Click the **upload** button.
The firmware is uploaded from the device to the PC and the following information is displayed in the Boot Loader window:




Fig. 12-3 Information in the Boot Loader

- ✧ Wait for at least 30 s and then click the **home** link.
The User Interface opens.

12.2.2 Manual Start of the Boot Loader

If it is necessary to start the Boot Loader manually, proceed as follows:

- ✧ If the SICAM AI Unit is still energized by the supply voltage, switch off the supply voltage.
- ✧ Press the IP-Addr. push-button at the SICAM AI Unit (see chapter 5.7.3), and holding the IP-Addr. push-button down, switch on the supply voltage.
- ✧ Hold the IP-Addr. push-button down until the LEDs ERROR (red) and H2 (yellow) on the device top side are lit (LEDs RUN (green) and H1 (yellow) are off).
- ✧ Release the IP-Addr. push-button.
SICAM AI Unit starts the Boot Loader with the **Boot Loader** HTML page (see figure 12-1).

12.3 Indications Signaled by LEDs

SICAM AI Unit automatically monitors the functions of its hardware, software, and firmware components. The LEDs on the top side of the housing indicate the current device status.

Designation of the LEDs




Fig. 12-4 Designation of the LEDs

Meaning of the LEDs














-    LED (green, red, yellow): on
 -    LED (green, red, yellow): flashes
 -   LEDs H1/H2/ERROR: as set by the user
 -  LED: off
- Ethernet switch off:**
-  LED Speed (yellow):
 - off: 10 Mbit/s
 - on: 100 Mbit/s
 -  LED Link/Activity (green):
 - LED on: Ethernet link is up
 - LED flashing: Ethernet link is up and data is transferred
 - LED off: no Ethernet partners connected
- Ethernet switch on:**
-  LED Link/Activity channel 1 (yellow):
 - LED on: Ethernet link is up
 - LED flashing: Ethernet link is up and data is transferred
 - LED off: no Ethernet partners connected
 -  LED Link/Activity channel 2 (green):
 - LED on: Ethernet link is up
 - LED flashing: Ethernet link is up and data is transferred
 - LED off: no Ethernet partners connected

Table 12-1 Indications Signaled by LEDs







LED	Meaning
	Device switched off
	No firmware loaded
Boot Loader	
	IP-Addr. push-button pressed during power-on
	Boot loader started after IP-Addr. push-button was pressed during power-on
	DHCP active (H1 switches off after receiving the IP address via DHCP)
	Default IP address by pressing IP-Addr. push-button

Table 12-1 Indications Signaled by LEDs (cont.)













LED	Meaning
	<p>Boot loader started; no process application exists</p>
	<p>DHCP active (LED H1 switches off after receiving the IP address via DHCP)</p>
	<p>Default IP address by pressing the IP-Addr. push-button</p>
	<p>Boot loader was started because an error occurred in the process application.</p>
	<p>DHCP active (LED H1 switches off after reception of the IP address via DHCP)</p>
	<p>Boot loader started, process application is being loaded.</p>
	<p>Double IP address is detected</p>

Table 12-1 Indications Signaled by LEDs (cont.)

LED	Meaning
Process Application	
	<p>Normal mode: IP address has been configured or received from DHCP.</p>
	<p>Parameterization of the ERROR LED: The ERROR LED can only be assigned to Error messages.</p>
	<p>DHCP: LED RUN (green) is lit after the IP address was received by the DHCP server.</p>
	<p>Default IP address is applied by pressing the IP-Addr. push-button.</p>
	<p>Double IP address is detected.</p>

12.4 Troubleshooting and Repair

General Troubleshooting

The user is not authorized to troubleshoot the defective device beyond the measures described in chapter 12.1 and chapter 12.3 or make repairs himself. Special electronic modules are inserted in the SICAM AI Unit which can only be replaced by the manufacturer according to the guidelines for Electrostatic sensitive devices (ESD).

If you suspect any damage on the device, Siemens recommends sending the entire device to the manufacturer. For this purpose, it is best to use the original transport packaging or similar packaging.

Troubleshooting Based on Error Messages



NOTE

Error messages are service information that you quote to the service department upon request in case of an error.

The error messages can be saved as described in chapter 7.2.5.2, section **File download** → **Save**.

The error messages can be printed as described in chapter 7.2.5.2, section **File download** → **Open**.

13 Technical Data

13.1	General Device Data	168
13.2	Test Data	173
13.3	Dimensions	177

13.1 General Device Data

13.1.1 Power Supply

Direct Voltage

Rated input voltages	24 V to 250 V
Admissible input voltage tolerance	±20 %
Permitted ripple of the input voltage at 24 V, 48 V, 60 V, 110 V, 220 V, 250 V	15 %
Maximum inrush current	
At ≤ 110 V	< 15 A
At 220 V to 300 V	after 250 µs: < 5 A
Maximum power consumption	
	5 W

Alternating Voltage

Rated input voltages	110 V to 230 V
System frequency at AC	45 Hz to 65 Hz
Admissible input voltage tolerance	±20 %
Maximum inrush current	
At ≤ 115 V	< 15 A
At 230 V	after 250 µs: < 5 A
Maximum power consumption	
	16 VA

13.1.2 Inputs and Outputs

Inputs for Direct-Current Measurements (Terminal Block T and Q)

Input AC currents	
Rated input current range	DC 0 mA to 20 mA DC 4 mA to 20 mA
Further information about the current measuring inputs	
Max. input voltage at DC measurements	5 V
Max. power consumption	150 mW per channel
Input impedance	140 Ω
Measuring error	Max. 1.0 % of rated current
Measuring error (with calibration) at 23 °C \pm 1 °C	Max. 0.2 % of rated current

13.1.3 Communication Interfaces

Ethernet (Connector Z)

Ethernet, electrical	Operation	With device internal software
	Connection	Device top side RJ45 connector socket
	Ethernet switch turned off:	100BaseT acc. to IEEE802.3 LED speed (yellow): 10/100 Mbit/s (off/on) LED Link/Activity (green): <ul style="list-style-type: none"> • lit: Ethernet link is up • flashes: Ethernet link is up, data transmission • off: no Ethernet partners connected
	Ethernet switch turned on:	LED Link/Activity channel 1 (yellow) LED Link/Activity channel 2 (green): <ul style="list-style-type: none"> • lit: Ethernet link is up • flashes: Ethernet link is up, data transmission • off: no Ethernet partners connected
	Protocols	Modbus TCP IEC 61850
	Voltage strength	DC 700 V
	Transmission rate	10/100 Mbit/s
	Cable for 100Base-T	100 Ω to 150 Ω STP, CAT6
	Maximum cable length 100Base-T	20 m

Serial Interface (Connector J)

RS485	Connection	Terminal side, 9-pin D-sub socket		
	Protocol	Modbus RTU	SIPROTEC RTU 20 mA	
	Baud rate (adjustable)	Min. 1200 bit/s Max. 115 200 bit/s; Default setting 19 200 bit/s	Min. 4800 bit/s Max. 38 400 bit/s; Default setting 9600 bit/s	
	Parity	None, 1 stop bit Even Odd None, 2 stop bit	None, 1 stop bit Even Odd None, 2 stop bit	
	Maximum distance of transmission	Max. 1 km (depending on transmission rate)		
	Transmission level	low: -5 V to -1.5 V high: +1.5 V to +5 V		
	Reception level	low: ≤ -0.2 V high: $\geq +0.2$ V		
	Measured value ranges	-	-	
	Bus termination	Not integrated, bus termination using plugs with integrated bus terminating resistors (see figure 13-1)		
	SICAM AI Unit 7XV5674-0KK40-xAA1			
	Optical	Connection	Terminal side, ST connector, 820 nm Bending radiuses: According to fiber-optic cable used	
Protocol/Operating mode		Modbus RTU	SIPROTEC RTU 20 mA	
Baud rate		Min. 1200 bit/s Max. 115 000 bit/s; Default setting 19 200 bit/s	Min. 4800 bit/s Max. 38 400 bit/s; Default setting 9600 bit/s	
Parity		None, 1 stop bit Even Odd None, 2 stop bit	None, 1 stop bit Even Odd None, 2 stop bit	
Maximum distance of transmission		Max. 2000 m at 62.5 μ m/125 μ m multimode optical fiber Max. 1500 m at 50 μ m/125 μ m multimode optical fiber		
Receiver sensitivity		-24 dBm at 62.5 μ m/125 μ m multimode optical fiber		
Optical budget		Min. 8 dB at 62.5 μ m/125 μ m multimode optical fiber		

Recommended Termination of the RS485 Interface (Connector J)

The RS485 bus requires at least the bus termination shown in the figure below, with pullup/pulldown resistors:




Fig. 13-1 Termination of the RS485 Interface

The bus termination must be respectively carried out at the first and last RS485 device interface of the bus. No terminating resistor may be used at all other devices in this line.

Siemens recommends the use of a bus termination plug with integrated (activatable) resistors in accordance with figure 13-1, for example plugs with 35°-cable outlet type 6ES7972-0BA42-0XA0 (see chapter 2.2). Use a 2-wired, twisted and shielded cable (see chapter 2.2). In case of outdoor mounting Siemens recommends a rodent protection. You can find current installation material at SIEMENS IS in the "Catalog for Industrial Communication", chapter "PROFIBUS", see also:

<http://www.automation.siemens.com/mcms/automation/en/industrial-communications/Pages/Default.aspx>.

The 9 pin D-sub socket of the RS485 interface is connected as follows:

Pin No.	Assignment	Pin No.	Assignment
1	Shield	6	DC +5 V Supply voltage for terminating resistors (max. 100 mA)
2	Not assigned	7	RTS Direction control (if required for an external conversion)
3	A RS485 connection pin A	8	B RS485 connection pin B
4	Not assigned	9	Not assigned
5	GND (towards DC +5 V)		

13.1.4 Environmental Data

Temperature data	Operating temperature	-25 °C to +70 °C -13 °F to +158 °F
	Temperature during transport	-25 °C to +70 °C -13 °F to +158 °F
	Temperatur during storage	-25 °C to +70 °C -13 °F to +158 °F
	Maximum temperature gradient	20 K/h
Air humidity data	Mean relative air humidity per year	≤ 75 %
	Maximum relative air humidity	95 % 30 days a year
	Condensation during operation	Not permitted
	Condensation during transport and storage	Permitted

13.1.5 General Data

Battery	Type	PANASONIC CR2032 or VARTA 6032 101 501
	Voltage	3 V
	Capacity	230 mAh
	Typical life	10 years In operation with continuous supply voltage 2 months within 10 years; In operation where supply voltage is not applied continuously
Protection class acc. to IEC 60529	DIN rail side	IP20
	Terminal side (terminals)	IP20
	Top side	IP20

13.2 Test Data

Reference Conditions for Determining the Test Data

Input current of reference source	Rated current $\pm 0.02\%$
Curve shape	Direct current
Ambient temperature	$23\text{ °C} \pm 1\text{ °C}$
Supply voltage	$V_{HN} \pm 5\%$
Frequency of supply voltage	45 Hz to 65 Hz
Warm-up time	$\geq 15\text{ min}$
Interfering fields	None

13.2.1 Electrical Tests

Standards

Standards:	IEC 60688 and IEC 60255 IEEE Std C37.90, see individual functions VDE 0435 For more standards see also individual functions
------------	--

Insulation Test according to IEC 61010-1 and IEC 61010-2-030

Inputs/Outputs	Insulation	Rated Voltage	ISO Test Voltage	Category
Current measuring inputs	Reinforced	< 50 V	AC 2.3 kV DC 3.6 kV	Cat. III
Supply voltage	Reinforced	300 V	DC 3.125 kV	Cat. III
Ethernet interface	Function	< 50 V	DC 700 V	Cat. III
RS485 interface	Function	< 50 V	DC 700 V	Cat. III

EMC Tests for Immunity (Type Tests)

Standards:	IEC 60255-6 and -22, (product standards) IEC/EN 61000-6-2 VDE 0435 For more standards see also individual functions	
1 MHz test, Class III, IEC 60255-22-1, IEC 61000-4-18, IEEE C37.90.1	2.5 kV (peak); 1 MHz; $\tau = 15 \mu\text{s}$; Repetition rate of 400/s; Test duration 2 s; $R_i = 200 \Omega$	
Electrostatic discharge, Class III IEC 60255-22-2, IEC 61000-4-2	4 kV contact discharge; 8 kV air discharge, both polarities; 150 pF; $R_i = 330 \Omega$	
Radio frequency electromagnetic field, amplitude-modulated, Class III IEC 61000-4-3, IEC 60255-22-3	10 V/m; 80 MHz to 2.7 GHz; 80 % AM; 1 kHz	
Fast transient bursts, Class III IEC 61000-4-4, IEC 60255-22-4, IEEE C37.90.1	2 kV; 5 ns/50 ns; 5 kHz; Burst length = 15 ms; Repetition rate 300 ms; Both polarities; $R_i = 50 \Omega$; Test duration 1 min	
High energy surge voltages (SURGE), Installation Class III IEC 61000-4-5, IEC 60255-22-5	Impulse: 1.2 $\mu\text{s}/50 \mu\text{s}$	
	Auxiliary voltage	Common mode: 2 kV; 12 Ω ; 9 μF Diff. mode: 1 kV; 2 Ω ; 18 μF
	Measuring inputs, binary inputs and relay outputs	Common mode: 2 kV; 42 Ω ; 0.5 μF Diff. mode: 1 kV; 42 Ω ; 0.5 μF
Immunity to conducted disturbances, inducted by radio-frequency fields, Class III IEC 61000-4-6, IEC 60255-22-6	10 V; 150 kHz to 80 MHz; 80 % AM; 1 kHz	
Power frequency magnetic field immunity test IEC 61000-4-8, Class IV;	30 A/m continuous; 300 A/m for 3 s	

EMC Test for Radio-Frequency Disturbance Characteristics

Standard:	IEC/EN 61000-6-4
Radio-Frequency Disturbance Characteristics IEC-CISPR 22 (conducted emission)	150 kHz to 30 MHz Limit Class B
Radio-Frequency Disturbance Characteristics IEC-CISPR 11 (radiated emission)	30 MHz to 1000 MHz Limit Class A

13.2.2 Mechanical Stress Tests

Vibration and Shock Stress during Stationary Operation

Standards:	IEC 60255-21 and IEC 60068
Vibration tests IEC 60255-21-1, Class II; IEC 60068-2-6 test Fc	Oscillation: Sinusoidal 10 Hz to 60 Hz: ± 0.075 mm amplitude; 60 Hz to 150 Hz: 1 g acceleration Frequency sweep rate 1 octave/min 20 cycles in 3 or- thogonal axes.
Shock IEC 60255-21-2, Class I; IEC 60068-2-27 test Ea	Semi-sinusoidal 5 g acceleration, duration 11 ms, each 3 shocks in both directions of the 3 axes
Seismic Vibration IEC 60255-21-3, Class II; IEC 60068-3-3 test Fc	Sinusoidal 1 Hz to 8 Hz: ± 7.5 mm amplitude (horizontal axis) 1 Hz to 8 Hz: ± 3.5 mm amplitude (vertical axis) 8 Hz to 35 Hz: 2 g acceleration (horizontal axis) 8 Hz to 35 Hz: 1 g acceleration (vertical axis) Frequency sweep 1 octave/min 1 cycle in 3 orthogonal axes

Vibration and Shock Stress during Transport

Standards:	IEC 60255-21 and IEC 60068
Vibration tests IEC 60255-21-1, Class 2; IEC 60068-2-6 test Fc	Oscillation: Sinusoidal 5 Hz to 8 Hz: ± 7.5 mm amplitude; 8 Hz to 150 Hz: 2 g acceleration Frequency sweep 1 octave/min 20 cycles in 3 orthogonal axes
Shock IEC 60255-21-2, Class 1; IEC 60068-2-27 test Ea	Semi-sinusoidal 15 g acceleration, duration 11 ms, each 3 shocks (in both directions of the 3 axes)
Bump IEC 60255-21-2, Class 1; IEC 60068-2-29 test Eb	Semi-sinusoidal 10 g acceleration, duration 16 ms, each 1000 shocks (in both directions of the 3 axes)
Free fall IEC 60068-2-32 test Ed	1 m

13.2.3 Climatic Stress Tests

Standards: IEC 60068 and IEEEC37.90
Cold: IEC 60068-2-1 test Ad IEEE C37.90-2
Dry heat during operation, storage and transport: IEC 60068-2-2 test Bd
Damp heat: IEC 60068-2-3 test Ca
Change of temperature: IEC 60068-2-14 test Na and Nb
Individual gastest, industrial atmosphere, sequential gas test: IEC 60068-2-42 test Kc IEC 60068-2-43
Flowing mixed gas: IEC 60068-2-60 method 4
Salt mist test IEC 60068-2-11 test Ka

13.2.4 Safety Standards

Standards: EN 61010
EN 61010-1

13.3 Dimensions

Mass	approx. 0.5 kg
Dimension (W x H x D)	96 mm x 96 mm x 100 mm 3.78 in x 3.78 in x 3.94 in




Fig. 13-2 Dimensional Drawing of the SICAM AI Unit

1) Dimensional drawing is valid for DIN rail DIN EN 50022-35 x 7.5

14 Operational Indications

Indication	Description	Notes
Device OK	The device startup was successful.	Indication on: Device ready
Start Up	Device startup or device restart	Indication on: Device startup successful
Battery Failure	Battery voltage < 2.7 V or no battery inserted	Indication on: Battery failure
Clear operational log	The operational indications were deleted.	Indication on: Operational indications deleted
Time Synchronization Error	Error during the time synchronization from the NTP server or fieldbus	<p>Indication off: At least one time message was received during the set timer ("Error indication after"). The time stamp is set when the first valid time information or time synchronization is received.</p> <p>Indication on: No time message was received during the set timer ("Error indication after"). The time stamp is set after the "Error indication after" timer has expired and no synchronization message was received.</p> <p>Parameter range: see chapter 7.3.4.1</p> <p>Error sources with RTC: - no valid time after device startup Error sources with NTP or fieldbus: - „Error indication after" timer expires and no synchronization message was received</p>
	Error during internal time synchronization	<p>Indication on: RTC time invalid Indication off: After setting the clock via HTML (see chapter 7.3.4.1)</p> <p>During battery failure at device startup</p>
Time Set	The time was set.	<p>Indication on: Time set</p> <p>Only when setting the clock via HTML</p>
Default IP Address	The IP-Addr. push-button has been pressed for more than 3 s.	<p>Indication on: IP-Addr. push-button was pressed</p> <p>The device restarts and applies the default IP address.</p>

Indication	Description	Notes
Primary NTP Server Error	Faulty or no response from the primary NTP server	Indication on: Error Indication off: Valid time messages has been received for a period of 10 min Only for time synchronization via Ethernet NTP (see chapter 7.3.4.1)
Secondary NTP Server Error	Faulty or no response from the secondary NTP server	Indication on: Error Indication off: Valid time messages has been received for a period of 10 min Only for time synchronization via Ethernet NTP (see chapter 7.3.4.1)
Daylight Saving Time	Switching between daylight saving time/standard time	Indication on: Daylight saving time Indication off: Standard time
Ethernet Link Error	Ethernet connection error	Indication on: Error Indication off: Ethernet link recognized
Modbus TCP OK (Modbus TCP Server)	At least one Modbus TCP link has received Modbus messages.	Indication on: At least one Modbus message was received during the set monitoring time. The time stamp is set when the first valid message is received. Indication off: No Modbus message was received during the set monitoring time. See chapter 7.3.4.2
Modbus Serial OK (Modbus RTU Slave)	The Modbus serial communication has received a valid Modbus message.	Indication on: At least one serial message was received during the set monitoring time. The time stamp is set when the first valid message is received. Indication off: No serial message was received during the set monitoring time. See chapter 7.3.4.3
Settings Load	Starting to change the parameters of the passive set of parameters.	Indication on: Start of changes Indication off: Changes complete
Settings Check	The passive set of parameters is to be activated; the internal parameter check is running.	Indication on: Check started Indication off: Check complete
Settings Activate	The passive set of parameters is enabled and the device works with these parameters.	Indication on: Activation started Indication off: Activation complete

Indication	Description	Notes
Limit Violation x	Indication that a parameterized limiting value has been violated	<p>Indication on: The limit of the monitored measured value has been violated or no measured value is parameterized as input of the limiting value.</p> <p>Indication off: The limit of the monitored measured value is not violated.</p> <p>Message invalid: The monitored measured value is invalid (e.g. negative value or a value greater than 20 mA).</p> <p>x = 1 to 16</p>
Group indication x	Up to 16 single-point indications can be linked logically and combined to a group indication.	A total of 4 group indications (x = 1 to 4) can be parameterized.
Modbus UDP OK	The Modbus UDP communication has received a valid Modbus message.	<p>Indication on: At least one valid Modbus message was received.</p> <p>Indication off: No Modbus message was received during the set monitoring time.</p> <p>See chapter 7.3.4.2</p>
Ethernet Link 2 Error	Ethernet connection error on port 2 of the Ethernet switch (available only with Y-cable)	<p>Indication on: Error</p> <p>Indication off: Ethernet link recognized</p>
Out of Range Tx/y and Qx/y	Out of range	-
Wire Broken Tx/y and Qx/y	Wire broken	-
Input not Active Tx/y and Qx/y	Input not active	-
MBS Serial OK	MBS mode is correct	-

15 Operating Parameters

15.1	Process Connections	184
15.2	Automation Functions	187
15.3	Administrative	189



NOTE for user on the online help

This chapter is integrated as an online help in the user interface.

The description of parameterization of the operating parameters can be found in the manual SICAM AI Unit, order number E50417-G1140-C492-A2.

15.1 Process Connections

The following process connections are available:

- 20-mA inputs
- LEDs

15.1.1 20-mA Inputs

Parameter	Default Setting	Setting Range
T1/2 (20-mA Channel 1 terminal block T)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
T4/6 (20-mA Channel 2 terminal block T)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
T3/5 (20-mA Channel 3 terminal block T)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
T7/9 (20-mA Channel 4 terminal block T)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
T11/13 (20-mA Channel 5 terminal block T)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
T15/17 (20-mA Channel 6 terminal block T)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
Q1/2 (20-mA Channel 1 terminal block Q)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
Q4/6 (20-mA Channel 2 terminal block Q)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
Q3/5 (20-mA Channel 3 terminal block Q)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)

Parameter	Default Setting	Setting Range
Q7/9 (20-mA Channel 4 terminal block Q)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
Q11/13 (20-mA Channel 5 terminal block Q)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
Q15/17 (20-mA Channel 6 terminal block Q)	No (no checkmark set)	No (no checkmark set) Yes (checkmark set)
Measuring range	0 mA to +20 mA	0 mA to +20 mA 4 mA to +20 mA

15.1.2 LEDs

LED	Default Setting	Setting Range
RUN	Device ready	Not settable
H1 H2	-none-	-none- Device OK Battery Failure Settings Load Settings Check Settings Activate Modbus TCP OK Ethernet Link Error Modbus Serial OK Time Synchronization Error Primary NTP Server Error Secondary NTP Server Error Daylight Saving Time Ethernet Link 2 Error Default IP Address Limit Violation y Out of range z Wire broken z Input not active z Group Indication x MBS Serial OK
ERROR (Error signalization and signalization according to parameterization) Note: Only error messages can be assigned to the ERROR LED.	-none-	-none- Battery Failure Ethernet Link Error Time Synchronization Error Primary NTP Server Error Secondary NTP Server Error Ethernet Link 2 Error

x = 1 to 4

y = 1 to 16, user-defined name, if assigned (see chapter 15.2)

z = T1/2, T4/6, T3/5, T7/9, T11/13, T15/17 → and → Q1/2, Q4/6, Q3/5, Q7/9, Q11/13, Q15/17

15.2 Automation Functions

The following automation functions are available:

- Limit violation 1-8
- Limit violation 9-16
- Group indication 1-4

Limit Violation 1-8 and 9-16

Parameter	Default Setting	Setting Range
Measurand	-none-	-none- 20 mA Ch x Terminal Block T (x = 1 to 6) 20 mA Ch x Terminal Block Q (x = 1 to 6)
Limit	0.00	0.00 mA to 20.00 mA
Limit type	Lower	Lower Upper
Hysteresis (%)	1.00	0.00 to 20.00
Violation indication	Limit Violation x (x = 1 to 16)	The name of the limit value indication is customizable.

Group Indications

Parameter	Default Setting	Setting Range
<p>Indication (selectable for Group Indication 1 to 4):</p> <p>Device OK Battery Failure Modbus TCP OK Ethernet Link Error Modbus Serial OK Time Synchronization Error Primary NTP Server Error Secondary NTP Server Error Daylight Saving Time Ethernet Link 2 Error Default IP Address Limit Violation y Out of range z Wire broken z Input not active z MBS Serial OK</p>	<p>No (no checkmark set)</p>	<p>No (no checkmark set) Yes (checkmark set)</p>

x = 1 to 4

y = 1 to 16

z = T1/2, T4/6, T3/5, T7/9, T11/13, T15/17 → and → Q1/2, Q4/6, Q3/5, Q7/9, Q11/13, Q15/17

15.3 Administrative

The following administrative settings are available:

- Time Synchronization
- Ethernet Communication
- Communication Serial
- Device and Language

15.3.1 Time Synchronization

Parameter	Default Settings	Setting Range
Source time synchronization	Internal	Internal Ethernet NTP Fieldbus
Time zone offset to UTC	+00:00	-12 to +13 (hours) (in increments of 0.5 h)
Daylight Saving Time switchover	yes	no yes
DST offset to UTC	+01:00	0 to + 2 (hours) (in increments of 0.5 h)
Start of DST	March Last week Sunday 02:00 AM	January to December First week Second week Third week Fourth week Last week Sunday to Saturday 0:00 to 23:00 (full hour)
End of DST	October Last week Sunday 03:00 AM	January to December First week Second week Third week Fourth week Last week Sunday to Saturday 0:00 to 23:00 (full hour)
Additional Parameters if the Source is Ethernet NTP (Modbus TCP and IEC 61850)		
Primary NTP server IP Address	192.168.0.254	Any
Secondary NTP server IP Address	192.168.0.253	Any No polling of the NTP server if 0.0.0.0 was entered
Error indication after	10 min	2 min to 120 min
Additional Parameters if Source is Fieldbus		
Error indication after	10 min	2 min to 120 min

15.3.2 Ethernet Communication

Parameter	Default Settings	Setting Range
IP address ¹⁾	192.168.0.55	Any 0.0.0.0 = DHCP
Subnet mask ¹⁾	255.255.255.0	Any
Default gateway ¹⁾	192.168.0.1	Any
Ethernet switch on	no	no yes
Bus protocol	Modbus TCP	Modbus TCP IEC 61850 -none-
Bus Protocol Modbus TCP		
Use a user-port number ²⁾	no	no yes
User-port number ²⁾ (can only be set when <i>Use a user-port number</i> is parameterized with yes)	10000	10000 to 65535
Access rights for user port (can only be set when <i>Use a user-port number</i> is parameterized with yes)	Full	Full Read only
Access rights for user port 502	Full	Full Read only
Keep Alive time	10 s	0 s = switch off 1 s to 65 535 s
Communication supervision time	50 * 100 ms	0 s = none 100 ms to 6 553 400 ms
Bus Protocol Modbus UDP		
Port number	51000	10000 to 65535
Access rights	Full	Full, Read only
Communication supervision time	20 [* 10 ms]	0 ms = invalid 10 ms to 60 000 ms
Bus Protocol IEC 61850 ³⁾		
IEC 61850 Edition	Edition 1	Edition 1 Edition 2
IED name number	1	0 to 65 534
Deadband percentage	2.0	0.0 % to 10.0 %
Multicast MAC address	01-0C-CD-01-00-01	[xx-xx-xx-xx-xx-xx] hexadecimal
App ID	3001	[xxxx] hexadecimal

Parameter	Default Settings	Setting Range
VLAN ID	000	[xxx] hexadecimal
VLAN priority	4	0 to 7
Retransmit MIN	10	1 ms to 500 ms
Retransmit MAX	2000	500 ms to 65 534 ms

- 1) After the parameter changes have been enabled, the device resets.
- 2) After enabling the parameter changes, any currently active Modbus TCP connections will be closed. The Modbus TCP client must later re-open these connections.
- 3) After having selected IEC 61850 or having changed the IEC 61850 settings with the following activation, the device is automatically restarted.

15.3.3 Communication Serial

Parameter	Default Settings	Setting Range
Bus protocol	Modbus RTU	-none- Modbus RTU SIPROTEC RTU 20 mA
Bus Protocol Modbus RTU		
Device address	1	1 to 247
Baud rate	19 200 bit/s	1200 bit/s, 2400 bit/s 4800 bit/s, 9600 bit/s 19 200 bit/s, 38 400 bit/s 57 600 bit/s, 115 200 bit/s
Parity	Even	None, 1 stop bit Even Odd None, 2 stop bit
Access rights	Full	Full Read only
Communication supervision time	600 * 100 ms	0 s = none 100 ms to 6 553 400 ms
Response delay	0 [ms]	0 ms to 1000 ms
If there is an optical interface: Fiber-optic idle state	Light OFF	Light OFF Light ON
Bus Protocol SIPROTEC RTU 20 mA		
MBS mode	8 MBS, simplex	8 MBS, simplex 8 MBS, half duplex 16 MBS, half duplex
Repeat time ¹⁾	600 ms	0 ms to 65 534 ms
Device address ²⁾	1	1 or 2
Baud rate	9600 Bit/s	4800 bit/s 9600 bit/s 19 200 bit/s 38 400 bit/s

Parameter	Default Settings	Setting Range
Parity	Even	None, 1 stop bit Even Odd None, 2 stop bit
Communication supervision time	600 * 100 ms	0 s = none 100 ms to 6 553 400 ms
If there is an optical interface: Fiber-optic idle state	Light OFF	Light OFF Light ON

- 1) Only visible, if **8 MBS, simplex** is selected as **MBS mode**.
- 2) Only visible, if **8 MBS, half duplex** is selected as **MBS mode**.

15.3.4 Device and Language

Parameter	Default Settings	Setting Range
Device name	SICAM AI Unit 7XV5674	Max. 32 characters
Language	ENGLISH (US)	ENGLISH (US) DEUTSCH (DE)
Date/time format	YYYY-MM-DD, Time with 24 hours	YYYY-MM-DD, Time with 24 hours YYYY-MM-DD, Time with 12 h AM/PM DD-MM-YYYY, Time with 24 hours DD-MM-YYYY, Time with 12 h AM/PM MM/DD/YYYY, Time with 24 hours MM/DD/YYYY, Time with 12 h AM/PM
Activation password	000000	Any 6 to 14 characters
Maintenance password	311299	Any 6 to 14 characters

Glossary

A

AC	Alternating Current
ACSI	Abstract Communication Service Interface
ARP	Address Resolution Protocol: Network protocol

B

Big-Endian format	The most significant byte is stored first, that is at the memory location with the lowest address.
Boot Application	Starting a device with the firmware required for the microcontroller
Broadcast message	Message in the network where data packets are transmitted to all devices on the network from one point

C

CDC	Common Data Class (IEC 61850)
Client	Device in the communication network that sends data requests or commands to the server devices and receives responses from them
CRC	Cyclic Redundancy Check: The cyclic redundancy check is a method of determining a test value for data (e.g. for data transmission in computer networks) with the purpose to detect errors during the transmission or duplication of data.

D

DC	Direct Current
DHCP	Dynamic Host Configuration Protocol enables the network configuration to be assigned to the devices by a DHCP server
DSP	Digital Signal Processor
DST	Daylight Saving Time

E

Ethernet	Cable-based data network technology for local data networks
----------	---

F

FW	Firmware: Program code for execution in a microcontroller
----	--

G		
	Gateway	Enables networks based on different protocols to communicate with each other
H		
	Holding register	Area for representing data in Modbus communication
I		
	ICD file	IED Capability Description : Contains the standardized description of the device configuration
	IEC	International Electrotechnical Commission , standards organization; Communication standard for substations and protection equipment
	IED	Intelligent Electronic Device
	Indication off	The status of the indication changes from ON to OFF, that is the indication is deleted.
	Indication on	The status of the indication changes from OFF to ON, that is the indication is currently present.
	+Inf	Stands for <i>Infinity</i> and denotes a counter overflow. Extremely large number or infinitely positive number
	IP	Internet Protocol
	IP address	Addresses in computer networks based on the Internet protocol
J		
	JavaScript	Script language mainly used by Web browsers
K		
	KeepAlive	<p>KeepAlive on TCP level is a feature intended to verify the availability and functioning of the communication partner (client) and to maintain a TCP network link if the network is inactive.</p> <p>The server sends KeepAlive messages (TCP packets without data) to the client in regular intervals (KeepAlive time) while the network is inactive, and the client responds to these messages.</p> <p>If the client does not respond to a KeepAlive message, the server assumes that the link is down or the client is inactive and closes the TCP link.</p>
L		
	LED	Light-Emitting Diode
	Limit violation	A value exceeding or falling under a parameterized limiting value.
	LSB	Least Significant Bit

M

MAC-Address	Media Access Control address: Hardware address that clearly identifies the device on the network.
MBAP	Modbus Application Protocol
MBAP Header	Header of a Modbus TCP message consisting of these 4 parts: Transaction identifier (2 bytes), protocol identifier (2 bytes), length (2 bytes), unit identifier (1 byte).
Modbus	The Modbus protocol is a communication protocol based on a client-server architecture.
Modbus RTU	Modbus Remote Terminal Unit : Modbus protocol type for transmitting data over serial networks (e.g. RS485)
Modbus TCP	Modbus Transmission Control Protocol : Modbus protocol type for transmitting data as TCP/IP packets; TCP port 502 is reserved for Modbus TCP.
MSB	Most Significant Bit

N

NaN	Not a Number means "invalid": Result of an invalid computing operation
NTP	Network Time Protocol : Standard for synchronizing clocks in computer systems using packet-based communication networks

P

PIXIT	Protocol Implementation Extra Information for Testing
-------	--

R

Response delay	<p>According to the Modbus specification the bus silent time between receiving the Modbus request from the Modbus master and sending the response must be at least 3.5 character times. This is ensured by the Modbus slave in the SICAM device.</p> <p>For some reasons (for example communication media converters in the line that need a certain direction switchover time) the 3.5 character times is too short and must be extended in order to ensure a correct receiving of the response by the Modbus master.</p> <p>With this parameter a response delay (additionally to the 3.5 character times) may be defined.</p>
RJ45	Ethernet plug connector
RS485	Interface standard for digital, wire-based, differential, serial data transmission
RTC	Real-Time Clock
RTU	See Modbus Remote Terminal Unit

S		
Server		Sends data upon request by the client
SNTP		S imple N etwork T ime P rotocol: Simplified version of the NTP
SW		S oftware: Program executed on a computer
STP		S hielded t wisted- p air is the cable for 100Base-T (Ethernet)
Stratum		Each NTP server is synchronized by a high-precision time standard or by another NTP server. The stratum is the position of the NTP server in the hierarchy of NTP servers polled by the device. The best stratum is 1, each further level in the NTP server hierarchy increases the stratum by 1.
Subnet mask		Bit mask in the network protocol that defines how many IP addresses the computer network encompasses. Together with the IP address of a device, the subnet mask defines which IP addresses the device searches in its own network and which IP addresses it tries to reach via routers in other networks.
T		
TCP/IP		T ransmission C ontrol P rotocol/ I nternet P rotocol: Family of network protocols
U		
UTC		U niversal T ime C oordinated: Universal time standard referred to the time at the prime meridian

Index

A

Access Rights 37
Accessories 21
Assembly 33
Automation functions 75

C

Calibration 149
Changes during operation 40
Commissioning 39
Communication 15
Communication features 120
Communication Interfaces 47
Compensator 150

D

Data in the Modbus registers 134
Data Type - Date/Time 133
Data Type - Indications 134
Data Type - Measured Value 132
Data Types 131
Date/ Time 108
Default IP address 41
Device 23
Device configuration 62
DHCP server 121
Dimensions 177

E

Electrical Connection 35
Electrical Data 168
Electrical design 25
Error messages 61, 110
Ethernet communication 83, 120
Ethernet Interface 122
Ethernet interface 47
Ethernet NTP 117
Exception Responses 127
External time synchronization 117

F

Failures 157, 159
Firmware update 102

G

Getting Started 29

H

Hysteresis 77

I

Indications signaled by LEDs 161
Initial Commissioning 39
Initial Start 51
Installing the battery 30
Internal Time Keeping 116
Internal time synchronization 80, 118
IP Address 120
IP-Addr. push-button 121

L

LED 161
LEDs 38, 73
Logs Menu 60

M

Maintenance 101, 155
Measured-value acquisition 71
Mechanical design 24
Messgrößen 15
Modbus 111, 126
Modbus Diagnosis 139
Modbus diagnosis 111
Modbus functions 126
Modbus RTU 130
Modbus RTU Diagnosis 140
Modbus TCP 128

Modbus TCP Diagnosis 139
Multiple Users 69

N

Network configuration 121

O

Operating parameters 183
Operational indications 109, 179
Operational parameters 70
Ordering information 20

P

Parameterization 16, 62
Presettings 108
Primary NTP server 117
Process connections 71

R

Redundant NTP Servers 117
Register assignment 131
Repair 165
RS485 interface 47

S

Saving device information and logs 56
Serial communication 93, 123
Setting the limits 75
Showing device information 56
Start during operation 55
Status bits 116
System Requirements 36

T

TCP/IP Protocol Stack 120
Technical Data 167
Terminals 44
Time 16, 115
Time Format 116
Time keeping 116
Time Synchronization 79
Time synchronization 117
Time synchronization via Ethernet NTP 81
Transport 156
Troubleshooting 165

U

User 54
User interface 54

V

Versions of SICAM AI Unit 7XV5674 18
Viewing values 100