



 PRODUCT-DETAILS

1789 LI-914

Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker alpine white - Busch-balance SI



General Information

Extended Product Type	1789 LI-914
Product ID	2CKA001731A2017
EAN	4011395190487
Catalog Description	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker alpine white - Busch-balance SI
Long Description	With >Light< icon. As cover for flush-mounted 1gang 1way, 1gang 2way switch, intermediate switch, push-button and control switch 1gang 2way.

Installation

Instructions and Manuals	No document needed
Mounting Type	Flush Mounted
Type of Fastening	Clamp

Environmental

Degree of Protection	IP20
----------------------	------

Technical

Data Sheet, Technical Information	No document needed
Application	Switch/push button

Design

Design Range	Busch-balance SI
Surface Finishing	Untreated Glossy
Material	Thermoplastic
Legend	Symbol "light"
Cover Style	with Small Transparent Calotte
RAL Number	Similar to RAL 9010
Color	alpine white

Dimensions

Product Net Width	55 mm
Product Net Height	55 mm
Product Net Depth / Length	20 mm
Product Net Weight	19 g

Material Compliance

RoHS Information	2CKA200000E1715
RoHS Status	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
REACH Declaration	2CKA309999E9999
REACH Information	False - does not contain substances > 0.1 mass percentage
REACH Date	20240705
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

Certificates and Declarations

Declaration of Conformity - CE	2CKA200000E1715
--------------------------------	-----------------

Classifications

ETIM 9	EC000011 - Control element/cover plate for domestic switching devices
eClass	V11.0 : 27144002
WEEE Category	Product Not in WEEE Scope

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
------------	-------------	------	----------	-----------------

2CKA001012A2131	Flush Mounted Inserts Off switch 1-pole 10 A	2000/1 US-507	1	piece
2CKA001022A0656	Rocker control switch Off switch 2-pole with Neon lamp - Orange 10 A	2000/2 UK	1	piece
2CKA001012A2193	Flush Mounted Inserts 2-pole switch 16 A	2000/2 US-101-500	1	piece
2CKA001012A2196	Flush Mounted Inserts 2-pole switch 10 A	2000/2 US-500	1	piece
2CKA001011A0816	Switch insert 3-pole switch 16 A	2000/3 US	1	piece
2CKA001012A2198	Switch insert Two-way switch 10 A	2000/6 US-500	1	piece
2CKA001012A2110	Flush Mounted Inserts Two-way switch 10 A	2000/6 US-507	1	piece
2CKA001012A2194	Flush Mounted Inserts Two-way switch with Neon lamp - Orange 10 A	2000/6 USGL-500	1	piece
2CKA001022A0659	Flush Mounted Inserts Two-way switch with Neon lamp - Orange with N-terminal 10 A	2000/6 USK-500	1	piece
2CKA001012A0954	Switch insert Two-way switch 2-pole 10 A	2000/6/2 US	1	piece
2CKA001012A2199	Flush Mounted Inserts Intermediate switch 10 A	2000/7 US-500	1	piece
2CKA001012A2130	Flush Mounted Inserts Intermediate switch 10 A	2000/7 US-507	1	piece
2CKA001413A0483	Push switch insert 1-pole push switch 1 NO 10 A	2020 US-201	1	piece
2CKA001413A0491	Push switch insert Series push switch 2 NO 10 A	2020 US-205	1	piece
2CKA001413A1105	Flush Mounted Inserts Series push switch 2 NO 10 A	2020 US-205-500	1	piece
2CKA001413A1104	Push switch insert Two-way push switch 1 NO 1 NC 1 CO with N-terminal 10 A	2020 US-206-500	1	piece
2CKA001413A0574	Flush Mounted Inserts with N-terminal 10 A	2020 US-500	1	piece
2CKA001413A1078	Flush Mounted Inserts with N-terminal 10 A	2020 US-507	1	piece
2CKA001413A1106	Flush Mounted Inserts with Neon lamp - with N-terminal 10 A	2020 USGL-500	1	piece
2CKA001012A2238	Flush Mounted Inserts Series switch with LED not exchangeable - Orange 16 A	2400/5 USK-500	1	piece
2CKA001012A2232	Flush Mounted Inserts Two-way switch 16 A	2400/6 US-500	1	piece
2CKA001725A1531	Cover frame 1-gang(s) entrée grey - Basic55	2511-91-507	1	piece
2CKA001725A1484	Cover frame 1-gang(s) white - Basic55	2511-92-507	1	piece
2CKA001725A1501	Cover frame 1-gang(s) champagne - Basic55	2511-93-507	1	piece
2CKA001725A1479	Cover frame 1-gang(s) alpine white - Basic55	2511-94-507	1	piece
2CKA001725A1506	Cover frame 1-gang(s) château-black - Basic55	2511-95-507	1	piece
2CKA001725A1511	Cover frame 1-gang(s) chalet white - Basic55	2511-96-507	1	piece
2CKA001725A1516	Cover frame 1-gang(s) foyer red - Basic55	2511-97-507	1	piece
2CKA001725A1521	Cover frame 1-gang(s) bistro-blue - Basic55	2511-98-507	1	piece
2CKA001725A1526	Cover frame 1-gang(s) maison-beige - Basic55	2511-99-507	1	piece
2CKA001725A1532	Cover frame 2-gang(s) entrée grey - Basic55	2512-91-507	1	piece
2CKA001725A1485	Cover frame 2-gang(s) white - Basic55	2512-92-507	1	piece
2CKA001725A1502	Cover frame 2-gang(s) champagne - Basic55	2512-93-507	1	piece
2CKA001725A1480	Cover frame 2-gang(s) alpine white - Basic55	2512-94-507	1	piece
2CKA001725A1507	Cover frame 2-gang(s) château-black - Basic55	2512-95-507	1	piece
2CKA001725A1512	Cover frame 2-gang(s) chalet white - Basic55	2512-96-507	1	piece
2CKA001725A1517	Cover frame 2-gang(s) foyer red - Basic55	2512-97-507	1	piece
2CKA001725A1522	Cover frame 2-gang(s) bistro-blue - Basic55	2512-98-507	1	piece
2CKA001725A1527	Cover frame 2-gang(s) maison-beige - Basic55	2512-99-507	1	piece
2CKA001725A1533	Cover frame 3-gang(s) entrée grey - Basic55	2513-91-507	1	piece
2CKA001725A1486	Cover frame 3-gang(s) white - Basic55	2513-92-507	1	piece

2CKA001725A1503	Cover frame 3-gang(s) champagne - Basic55	2513-93-507	1	piece
2CKA001725A1481	Cover frame 3-gang(s) alpine white - Basic55	2513-94-507	1	piece
2CKA001725A1508	Cover frame 3-gang(s) château-black - Basic55	2513-95-507	1	piece
2CKA001725A1513	Cover frame 3-gang(s) chalet white - Basic55	2513-96-507	1	piece
2CKA001725A1518	Cover frame 3-gang(s) foyer red - Basic55	2513-97-507	1	piece
2CKA001725A1523	Cover frame 3-gang(s) bistro-blue - Basic55	2513-98-507	1	piece
2CKA001725A1528	Cover frame 3-gang(s) maison-beige - Basic55	2513-99-507	1	piece
2CKA001725A1534	Cover frame 4-gang(s) entrée grey - Basic55	2514-91-507	1	piece
2CKA001725A1487	Cover frame 4-gang(s) white - Basic55	2514-92-507	1	piece
2CKA001725A1504	Cover frame 4-gang(s) champagne - Basic55	2514-93-507	1	piece
2CKA001725A1482	Cover frame 4-gang(s) alpine white - Basic55	2514-94-507	1	piece
2CKA001725A1509	Cover frame 4-gang(s) château-black - Basic55	2514-95-507	1	piece
2CKA001725A1514	Cover frame 4-gang(s) chalet white - Basic55	2514-96-507	1	piece
2CKA001725A1519	Cover frame 4-gang(s) foyer red - Basic55	2514-97-507	1	piece
2CKA001725A1524	Cover frame 4-gang(s) bistro-blue - Basic55	2514-98-507	1	piece
2CKA001725A1529	Cover frame 4-gang(s) maison-beige - Basic55	2514-99-507	1	piece
2CKA001725A1488	Cover frame 5-gang(s) white - Basic55	2515-92-507	1	piece
2CKA001725A1505	Cover frame 5-gang(s) champagne - Basic55	2515-93-507	1	piece
2CKA001725A1483	Cover frame 5-gang(s) alpine white - Basic55	2515-94-507	1	piece
2CKA001725A1510	Cover frame 5-gang(s) château-black - Basic55	2515-95-507	1	piece
2CKA001725A1515	Cover frame 5-gang(s) chalet white - Basic55	2515-96-507	1	piece
2CKA001725A1525	Cover frame 5-gang(s) bistro-blue - Basic55	2515-98-507	1	piece
2CKA001725A1530	Cover frame 5-gang(s) maison-beige - Basic55	2515-99-507	1	piece
2CKA001726A0222	Decorative Styling Frame attica / pigeon blue - Basic55	2516-901-507	1	piece
2CKA001726A0223	Decorative Styling Frame silver metallic - Basic55	2516-902-507	1	piece
2CKA001726A0224	Decorative Styling Frame light green - Basic55	2516-903-507	1	piece
2CKA001726A0225	Decorative Styling Frame orange - Basic55	2516-904-507	1	piece
2CKA001726A0226	Decorative Styling Frame yellow - Basic55	2516-905-507	1	piece
2CKA001726A0227	Decorative Styling Frame apricot - Basic55	2516-906-507	1	piece
2CKA001726A0228	Decorative Styling Frame luminous - Basic55	2516-907-507	1	piece
2CKA001726A0220	Decorative Styling Frame white - Basic55	2516-92-507	1	piece
2CKA001726A0230	Decorative Styling Frame champagne - Basic55	2516-93-507	1	piece
2CKA001726A0218	Decorative Styling Frame alpine white - Basic55	2516-94-507	1	piece
2CKA001726A0232	Decorative Styling Frame château-black - Basic55	2516-95-507	1	piece
2CKA001726A0234	Decorative Styling Frame chalet white - Basic55	2516-96-507	1	piece

Categories

Low Voltage Products and Systems → Wiring Accessories - Light Switch Ranges → Cover Plates and Control Elements → Mechanical Controls

