



 PRODUCT-DETAILS

6401 U-102

Busch-Universal Relay insert 230 V



General Information

Extended Product Type	6401 U-102
Product ID	2CKA006401A0048
EAN	4011395991299
Catalog Description	Busch-Universal Relay insert 230 V
Long Description	3 wire connection (neutral conductor required). For Busch-Watchdog 180 FP sensor for All Weather 44 6800-3x-102C. For comfort timer control element 6455-101-500. For Busch-Watchdog 180 flush-mounted Sensor Standard 6810-21x-101. For Busch-Watchdog 180 flush-mounted sensor Comfort II 6800-xxx-104 and 6800-xxx-104M. For Busch-Watchdog Presence tech 6813-xxx-101 und 6813/11-xxx. For Busch-Remote control IR control cover 6067-xxx-10x. For control cover with control lamp 6543-xxx-10x. Combinable with Busch-Watchdog extension insert 6805 U. Operation also possible via conventional push buttons (2020 US, 2021/6 UK).

Installation

Instructions and Manuals	2CKA000173B7855
Wiring Diagram	2CKA000097E0074
Mounting Type	Flush Mounted

Environmental

Ambient Air Temperature	Operation -25 ... +55 °C
Degree of Protection	IP20

Technical

Data Sheet, Technical Information	No document needed
Number of Outputs	1

Electrical

Rated Voltage (U_r)	230 V
Auxiliary Voltage AC/DC	230 V AC/DC
Rated Current (I_n)	10 A
Rated Frequency (f)	50 Hz
Minimum Switching Capacity	0...2300 W
Load Type	Resistive,Inductive,Capacitive load

Design

Design Range	Platform 63 Busch-Duro 2000 SI Reflex SI Busch-balance SI Busch-art linear future linear Busch-axcent solo Pure Stainless Steel carat Busch-Dynasty alpha impuls
Design Range Variant	Busch-Duro 2000 SI Busch-Duro 2000 SI Linear Reflex SI Reflex SI Linear Busch-art linear Busch-art linear - with Decor Ring Busch-art linear - pur future future linear Busch-axcent Busch-axcent pur alpha nea alpha exclusive
Surface Finishing	Untreated Glossy
Material	Thermoplastic

Dimensions

Product Net Width	71 mm
Product Net Height	71 mm

Product Net Depth / Length	41.4 mm
Product Net Weight	0.117 kg
Built-In Depth (t ₂)	32 mm
Dimension Diagram	2CKA000097E0660

Ordering

E-Number (Norway)	1478095
E-Number (Sweden)	1300061

Material Compliance

RoHS Information	2CKA200000E5749
RoHS Status	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
REACH Declaration	2CKA309999E9999
REACH Information	True - contains substances > 0.1 mass percentage
REACH Date	20240705
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363
SCIP	d628ece3-bec8-46c7-8314-77620d45f9b6 Germany (DE)

Certificates and Declarations

Declaration of Conformity - CE	2CKA100000E1566
--------------------------------	-----------------

Classifications

ETIM 9	EC001588 - Electronic switch
eClass	V11.0 : 27144054
WEEE Category	5. Small Equipment (No External Dimension More Than 50 cm)
WEEE B2C / B2B	Business To Consumer

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA006800A1468	Flush Mounted Inserts 230 V	6805 U	1	piece
2CKA006800A2161	Flush Mounted Inserts 230 V	6805 U-500	1	piece
2CKA006800A2727	Electronic Controls - Busch-balance SI	6800-914-104	1	piece
2CKA006599A2816	Control Element for Switch/dimmer Single push button with Neon lamp alpine white - Reflex SI	6543-214-102	1	piece
2CKA006599A3011	Electronic Controls for Switch/dimmer Single push button alpine white - Reflex SI	6543-214-102-500	1	piece
2CKA006800A2067	Electronic Controls - Reflex SI	6800-214-104	1	piece
2CKA006800A2083	Electronic Controls - Reflex SI	6800-214-104M	1	piece
2CKA006800A2037	Electronic Controls - Reflex SI	6810-214-101	1	piece
2CKA006599A2815	Control Element for Switch/dimmer Single push button with Neon lamp white - Busch-Duro 2000 SI	6543-212-102	1	piece

2CKA006800A2066	Electronic Controls - Busch-Duro 2000 SI	6800-212-104	1	piece
2CKA006800A2082	Electronic Controls - Busch-Duro 2000 SI	6800-212-104M	1	piece
2CKA006800A2166	Electronic Controls - Busch-Duro 2000 SI	6800-212-104M-500	1	piece
2CKA006800A2029	Electronic Controls - Busch-Duro 2000 SI	6810-212-101	1	piece
2CKA006599A3010	Electronic Controls for Switch/dimmer Single push button studio white - Platform 63	6543-84-101-500	1	piece
2CKA006800A2101	Electronic Controls - Platform 63	6800-84-104	1	piece
2CKA006599A2926	Control Element for Switch/dimmer Single push button stainless steel - Pure Stainless Steel	6543-866-101	1	piece
2CKA006800A2343	Electronic Controls - Pure Stainless Steel	6800-866-104	1	piece
2CKA006800A1674	Busch-Watchdog Cover plate Movement sensor alpine white - Allwetter 44 (IP 44)	6800-34-102C	1	piece
2CKA006599A2881	Control Element for Switch/dimmer Single push button anthracite - Platform 63	6543-81-101	1	piece
2CKA006599A2831	Control Element for Switch/dimmer Single push button ivory white - Platform 63	6543-82-101	1	piece
2CKA006599A2887	Control Element for Switch/dimmer Single push button aluminium silver - Platform 63	6543-83-101	1	piece
2CKA006599A2963	Control Element for Switch/dimmer Single push button studio white matt - Platform 63	6543-884-101	1	piece
2CKA006599A2968	Control Element for Switch/dimmer Single push button black matt - Platform 63	6543-885-101	1	piece
2CKA006800A2325	Electronic Controls - Platform 63	6800-83-104	1	piece
2CKA006800A2327	Electronic Controls - Platform 63	6800-83-104M	1	piece
2CKA006800A2506	Electronic Controls black matt - Platform 63	6800-885-104	1	piece
2CKA006800A2353	Busch-Watchdog Cover plate Movement sensor brown - Allwetter 44 (IP 44)	6800-31-102C	1	piece
2CKA006800A1898	Busch-Watchdog Cover plate Movement sensor white - Allwetter 44 (IP 44)	6800-32-102C	1	piece
2CKA006800A2354	Busch-Watchdog Cover plate Movement sensor aluminium silver - Allwetter 44 (IP 44)	6800-33-102C	1	piece
2CKA006800A1740	Busch-Watchdog Cover plate Movement sensor anthracite - Allwetter 44 (IP 44)	6800-35-102C	1	piece
2CKA006599A2822	Control Element for Switch/dimmer Single push button with Neon lamp ivory - alpha	6543-22G-102	1	piece
2CKA006599A2824	Control Element for Switch/dimmer Single push button with Neon lamp studio white - alpha	6543-24G-102	1	piece
2CKA006599A2820	Control Element for Switch/dimmer Single push button with Neon lamp platinum - alpha	6543-20-102	1	piece
2CKA006599A2821	Control Element for Switch/dimmer Single push button with Neon lamp bronze - alpha	6543-21-102	1	piece
2CKA006599A2869	Control Element for Switch/dimmer Single push button with Neon lamp palladium - alpha	6543-260-102	1	piece
2CKA006599A2870	Control Element for Switch/dimmer Single push button with Neon lamp titanium - alpha	6543-266-102	1	piece
2CKA006800A2084	Electronic Controls Movement sensor platinum - alpha	6800-20-104M	1	piece
2CKA006800A2118	Electronic Controls Movement sensor palladium - alpha	6800-260-104	1	piece
2CKA006800A2119	Electronic Controls Movement sensor palladium - alpha	6800-260-104M	1	piece
2CKA006599A2996	Electronic Controls for Switch/dimmer Single push button white - Basic55	6543-92-507	1	piece
2CKA006599A2997	Electronic Controls for Switch/dimmer Single push button alpine white - Basic55	6543-94-507	1	piece
2CKA006599A2994	Electronic Controls for Switch/dimmer Single push button château-black - Basic55	6543-95-507	1	piece

2CKA006599A2597	Control Element for Switch/dimmer Single push button alpine white - impuls	6543-74-101	1	piece
2CKA006599A2972	Control Element for Switch/dimmer Single push button studio white matt - impuls	6543-774-101	1	piece
2CKA006599A2976	Control Element for Switch/dimmer Single push button black matt - impuls	6543-775-101	1	piece
2CKA006599A2921	Control Element for Switch/dimmer Single push button aluminium silver - impuls	6543-783-101	1	piece
2CKA006800A2338	Electronic Controls Movement sensor ivory - impuls	6800-72-104	1	piece
2CKA006800A2339	Electronic Controls Movement sensor ivory - impuls	6800-72-104M	1	piece
2CKA006800A2505	Electronic Controls Movement sensor studio white matt - impuls	6800-774-104M	1	piece
2CKA006800A2503	Electronic Controls Movement sensor black matt - impuls	6800-775-104M	1	piece
2CKA006800A2081	Electronic Controls Movement sensor champagne metallic - impuls	6800-79-104	1	piece
2CKA006410A0399	Busch-Jalousiecontrol® II Control Element	6455-101-500	1	piece
2CKA006800A2863	Presence Detector 12 m aluminium silver	6813-183-102-500	1	piece
2CKA001725A1536	Cover frame 1gang alpine white - Reflex SI	2511-214-500	1	piece
2CKA001725A1464	Cover frame 1gang alpine white - Reflex SI	2511-214-507	1	piece
2CKA001725A1552	Cover frame 1gang white - Busch-Duro 2000 SI	2511-212-500	1	piece
2CKA001725A1463	Cover frame 1gang white - Busch-Duro 2000 SI	2511-212-507	1	piece
2CKA001754A4498	Cover frame 1gang studio white	1721-184K-500	1	piece
2CKA001754A4500	Cover frame 1-gang(s) stainless steel - Pure Stainless Steel	1721-866K-500	1	piece
2CKA001730A0191	Cover frame 1-gang(s) alpine white - Allwetter 44 (IP 44)	2101-34	1	piece
2CKA001730A0281	Cover frame 1-gang(s) alpine white - Allwetter 44 (IP 44)	2101-34-500	1	piece
2CKA001754A4173	Cover frame 1gang studio white - future	1721-184	1	piece
2CKA001754A4504	Cover frame 1gang studio white - future	1721-184-500	1	piece
2CKA001754A4331	Cover frame 1gang studio white - Busch-axcent	1721-284	1	piece
2CKA001754A4437	Cover frame 1gang white glass - Busch-axcent pur	1721-280	1	piece
2CKA001754A4536	Cover frame 1-gang(s) studio white - solo	1721-84-500	1	piece
2CKA001754A4442	Cover frame 1-gang(s) white glass - carat	1721-811	1	piece
2CKA001754A4600	Cover frame 1-gang(s) ivory white - Busch-Dynasty	1721-832-500	1	piece
2CKA001725A1398	Cover frame 1-gang(s) alpine white - Basic55	2511-944-507	1	piece
2CKA001754A2965	Cover frame 1gang studio white - alpha exclusive	1721 KA-24G	1	piece
2CKA001754A4503	Cover frame 1gang studio white - alpha nea	1721-24G-500	1	piece
2CKA001725A1539	Cover frame 1gang alpine white - Reflex SI2511-214K-102-Linear	2511-214K-102-500	1	piece
2CKA001725A1549	Cover frame 1gang white - Busch-Duro 2000 SI2511-212K-102-Linear	2511-212K-102-500	1	piece
2CKA001754A4506	Cover frame 1gang ivory white - future linear	1721-182K-500	1	piece
2CKA001754A4168	Cover frame 1gang ivory white - future	1721-182	1	piece
2CKA001754A4409	Cover frame 1gang black - Busch-axcent	1721-281	1	piece
2CKA001730A0258	Cover frame 1-gang(s) white - Allwetter 44 (IP 44)	2101-32	1	piece
2CKA001730A0282	Cover frame 1-gang(s) white - Allwetter 44 (IP 44)	2101-32-500	1	piece
2CKA001754A4800	Cover frame 1gang glass black - Busch-axcent pur	1721-245	1	piece
2CKA001754A4322	Cover frame 1-gang(s) glass black - carat	1721-825	1	piece

2CKA001754A4605	Cover frame 1-gang(s) anthracite - Busch-Dynasty	1721-831-500	1	piece
2CKA001725A1399	Cover frame 1-gang(s) white - Basic55	2511-922-507	1	piece
2CKA001754A4512	Cover frame 1gang ivory - alpha nea	1721-22G-500	1	piece
2CKA001754A4240	Cover frame 1gang anthracite - future linear	1721-181K	1	piece
2CKA001730A0275	Cover frame 1-gang(s) brown - Allwetter 44 (IP 44)	2101-31	1	piece
2CKA001754A4538	Cover frame 1-gang(s) chrome gloss - solo	1721-80G-500	1	piece
2CKA001754A4820	Cover frame 1-gang(s) porcelain anthracite - carat	1721-815	1	piece
2CKA001725A1479	Cover frame 1-gang(s) alpine white - Basic55	2511-94-507	1	piece
2CKA001754A4373	Cover frame 1gang platinum - alpha exclusive	1721 KA-20	1	piece
2CKA001730A0276	Cover frame 1-gang(s) aluminium silver - Allwetter 44 (IP 44)	2101-33	1	piece
2CKA001754A4535	Cover frame 1-gang(s) chrome matt - solo	1721-80-500	1	piece
2CKA001754A4254	Cover frame 1-gang(s) stainless steel - carat	1721-860	1	piece
2CKA001725A1484	Cover frame 1-gang(s) white - Basic55	2511-92-507	1	piece
2CKA001754A4382	Cover frame 1gang bronze - alpha exclusive	1721 KA-21	1	piece
2CKA001754A4529	Cover frame 1gang aluminium silver - future linear	1721-183K-500	1	piece
2CKA001730A0225	Cover frame 1-gang(s) anthracite - Allwetter 44 (IP 44)	2101-35	1	piece
2CKA001754A4360	Cover frame 1-gang(s) chrome - carat	1721-826-101	1	piece
2CKA001725A1531	Cover frame 1-gang(s) entrée grey - Basic55	2511-91-507	1	piece
2CKA001754A4509	Cover frame 1gang titanium - alpha exclusive	1721 KA-266-500	1	piece
2CKA001754A4531	Cover frame 1gang studio white matt - future linear	1721-884K-500	1	piece
2CKA001754A4356	Cover frame 1-gang(s) gold - carat	1721-823-101	1	piece
2CKA001725A1501	Cover frame 1-gang(s) champagne - Basic55	2511-93-507	1	piece
2CKA001754A4532	Cover frame 1gang black matt - future linear	1721-885K-500	1	piece
2CKA001754A4258	Cover frame 1-gang(s) bronze - carat	1721-821	1	piece
2CKA001725A1506	Cover frame 1-gang(s) château-black - Basic55	2511-95-507	1	piece
2CKA001725A1511	Cover frame 1-gang(s) chalet white - Basic55	2511-96-507	1	piece
2CKA001725A1516	Cover frame 1-gang(s) foyer red - Basic55	2511-97-507	1	piece
2CKA001754A4334	Cover frame 1gang yellow - Busch-axcent	1721-285	1	piece
2CKA001754A4775	Cover frame 1gang glass purple - Busch-axcent pur	1721-223	1	piece
2CKA001754A4560	Cover frame 1-gang(s) polished brass ivory white - Busch-Dynasty	1721-838-500	1	piece
2CKA001725A1521	Cover frame 1-gang(s) bistro-blue - Basic55	2511-98-507	1	piece
2CKA001754A4521	Cover frame 1gang platinum - alpha nea	1721-20-500	1	piece
2CKA001754A4337	Cover frame 1gang green - Busch-axcent	1721-286	1	piece
2CKA001754A4760	Cover frame 1gang glass sun - Busch-axcent pur	1721-225	1	piece
2CKA001754A4570	Cover frame 1-gang(s) polished brass decor ivory white - Busch-Dynasty	1721-836-500	1	piece
2CKA001725A1526	Cover frame 1-gang(s) maison-beige - Basic55	2511-99-507	1	piece
2CKA001754A4522	Cover frame 1gang bronze - alpha nea	1721-21-500	1	piece
2CKA001754A4340	Cover frame 1gang red - Busch-axcent	1721-287	1	piece
2CKA001754A4770	Cover frame 1gang glass avocado - Busch-axcent pur	1721-226	1	piece
2CKA001754A4565	Cover frame 1-gang(s) polished brass anthracite - Busch-Dynasty	1721-835-500	1	piece
2CKA001754A4391	Cover frame 1gang titanium - alpha nea	1721-266	1	piece
2CKA001754A4343	Cover frame 1gang blue - Busch-axcent	1721-288	1	piece

2CKA001754A4765	Cover frame 1gang glass coral - Busch-axcent pur	1721-227	1	piece
2CKA001754A4575	Cover frame 1-gang(s) polished brass decor anthracite - Busch-Dynasty	1721-833-500	1	piece
2CKA001754A4755	Cover frame 1gang glass ocean - Busch-axcent pur	1721-228	1	piece
2CKA001754A4780	Cover frame 1gang glass oyster - Busch-axcent pur	1721-229	1	piece
2CKA001754A4688	Cover frame 1gang platinum - Busch-axcent pur	1721-270-500	1	piece
2CKA001754A4580	Cover frame 1-gang(s) antique brass ivory white - Busch-Dynasty	1721-848-500	1	piece
2CKA001754A4708	Cover frame 1gang black matt - Busch-axcent pur	1721-275-500	1	piece
2CKA001754A4590	Cover frame 1-gang(s) antique brass decor ivory white - Busch-Dynasty	1721-846-500	1	piece
2CKA001754A4698	Cover frame 1gang titanium - Busch-axcent pur	1721-276-500	1	piece
2CKA001754A4585	Cover frame 1-gang(s) antique brass anthracite - Busch-Dynasty	1721-845-500	1	piece
2CKA001754A4595	Cover frame 1-gang(s) antique brass decor anthracite - Busch-Dynasty	1721-843-500	1	piece
2CKA001754A4790	Cover frame 1gang paper brown - Busch-axcent pur	1721-243	1	piece
2CKA001754A4785	Cover frame 1gang paper blue - Busch-axcent pur	1721-248	1	piece
2CKA001754A4805	Cover frame 1gang slate grey - Busch-axcent pur	1721-290	1	piece
2CKA001754A4795	Cover frame 1gang concrete grey - Busch-axcent pur	1721-298	1	piece
2CKA001754A4505	Cover frame 1-gang(s) ivory - impuls	1721-72-500	1	piece
2CKA001754A4514	Cover frame 1-gang(s) chrome - impuls	1721-726-500	1	piece
2CKA001754A4507	Cover frame 1-gang(s) solar gold - impuls	1721-73-500	1	piece
2CKA001754A4513	Cover frame 1-gang(s) alpine white - impuls	1721-74-500	1	piece
2CKA001754A4222	Cover frame 1-gang(s) alpine white - impuls	1721-74-507	1	piece
2CKA001754A4429	Cover frame 1-gang(s) studio white matt - impuls	1721-774	1	piece
2CKA001754A4430	Cover frame 1-gang(s) studio white matt - impuls	1721-774-507	1	piece
2CKA001754A4424	Cover frame 1-gang(s) black matt - impuls	1721-775	1	piece
2CKA001754A4510	Cover frame 1-gang(s) champagne metallic - impuls	1721-79-500	1	piece
2CKA001754A4225	Cover frame 1-gang(s) champagne metallic - impuls	1721-79-507	1	piece
2CKA001725A1033	Cover frame 1gang black - Reflex SI	2511-215	1	piece
2CKA001725A1563	Cover frame 1gang red - Reflex SI	2511-217-101	1	piece
2CKA001725A1564	Cover frame 1gang red - Reflex SI Linear	2511-217K-103	1	piece
2CKA001754A4713	Cover frame 1gang red - future linear	1721-12-182K-101	1	piece
2CKA001754A4516	Cover frame 1gang white - Busch-Duro 2000 SI	1721 NS-212-500	1	piece
2CKA001754A4527	Cover frame 1gang studio white - future linear	1721-184 NSK-500	1	piece
2CKA001754A4065	Cover frame with labelling field, horizontal 1gang studio white - alpha exclusive	1721 NSKA-24G	1	piece
2CKA001754A4496	Cover frame 1gang alpine white - Reflex SI	1721 NS-214-500	1	piece
2CKA001754A4497	Cover frame 1gang alpine white - Reflex SI Linear	1721 NSKA-214-500	1	piece
2CKA001754A4093	Cover frame with labelling field, horizontal 1gang white - Busch-Duro 2000 SI Linear	1721 NSKA-212	1	piece

2CKA001725A1413	Cover frame 2gang alpine white - Reflex SI Linear	2512-214-114	1	piece
2CKA001725A1537	Cover frame 2gang alpine white - Reflex SI	2512-214-500	1	piece
2CKA001725A1466	Cover frame 2gang alpine white - Reflex SI	2512-214-507	1	piece
2CKA001725A1553	Cover frame 2gang white - Busch-Duro 2000 SI	2512-212-500	1	piece
2CKA001725A1465	Cover frame 2gang white - Busch-Duro 2000 SI	2512-212-507	1	piece
2CKA001754A4499	Cover frame 2gang studio white - future linear	1722-184K-500	1	piece
2CKA001754A4501	Cover frame 2-gang(s) stainless steel - Pure Stainless Steel	1722-866K-500	1	piece
2CKA001730A0209	Cover frame 2-gang(s) alpine white - Allwetter 44 (IP 44)	2102-34	1	piece
2CKA001730A0283	Cover frame 2-gang(s) alpine white - Allwetter 44 (IP 44)	2102-34-500	1	piece
2CKA001754A4174	Cover frame 2gang studio white - future	1722-184	1	piece
2CKA001754A4508	Cover frame 2gang studio white - future	1722-184-500	1	piece
2CKA001754A4332	Cover frame 2gang studio white - Busch-axcent	1722-284	1	piece
2CKA001754A4438	Cover frame 2gang white glass - Busch-axcent pur	1722-280	1	piece
2CKA001754A4539	Cover frame 2-gang(s) studio white - solo	1722-84-500	1	piece
2CKA001754A4443	Cover frame 2-gang(s) white glass - carat	1722-811	1	piece
2CKA001754A4601	Cover frame 2-gang(s) ivory white - Busch-Dynasty	1722-832-500	1	piece
2CKA001725A1409	Cover frame 2-gang(s) alpine white - Basic55	2512-944-507	1	piece
2CKA001754A2999	Cover frame 2gang studio white - alpha exclusive	1722 KA-24G	1	piece
2CKA001754A4511	Cover frame 2gang studio white - alpha nea	1722-24G-500	1	piece
2CKA001754A3054	Cover frame 2gang studio white - alpha exclusive	1732 KA-24G	1	piece
2CKA001754A4067	Cover frame with labelling field, vertical 2gang studio white - alpha exclusive	1732 NSKA-24G	1	piece
2CKA001754A4528	Cover frame 2gang studio white - alpha nea	1732-24G-500	1	piece
2CKA001725A1540	Cover frame 2gang alpine white - Reflex SI Linear	2512-214K-102-500	1	piece
2CKA001725A1550	Cover frame 2gang white - Busch-Duro 2000 SI Linear	2512-212K-102-500	1	piece
2CKA001754A4231	Cover frame 2gang ivory white - future linear	1722-182K	1	piece
2CKA001754A4169	Cover frame 2gang ivory white - future	1722-182	1	piece
2CKA001754A4410	Cover frame 2gang black - Busch-axcent	1722-281	1	piece
2CKA001730A0266	Cover frame 2-gang(s) white - Allwetter 44 (IP 44)	2102-32	1	piece
2CKA001730A0284	Cover frame 2-gang(s) white - Allwetter 44 (IP 44)	2102-32-500	1	piece
2CKA001754A4801	Cover frame 2gang glass black - Busch-axcent pur	1722-245	1	piece
2CKA001754A4323	Cover frame 2-gang(s) glass black - carat	1722-825	1	piece
2CKA001754A4606	Cover frame 2-gang(s) anthracite - Busch-Dynasty	1722-831-500	1	piece
2CKA001725A1410	Cover frame 2-gang(s) white - Basic55	2512-922-507	1	piece
2CKA001754A3849	Cover frame 2gang ivory - alpha exclusive	1722 KA-22G	1	piece
2CKA001754A3799	Cover frame 2gang ivory - alpha nea	1722-22G	1	piece
2CKA001754A3864	Cover frame 2gang ivory - alpha exclusive	1732 KA-22G	1	piece
2CKA001754A3757	Cover frame 2gang ivory - alpha nea	1732-22G	1	piece
2CKA001754A4241	Cover frame 2gang anthracite - future linear	1722-181K	1	piece
2CKA001730A0277	Cover frame 2-gang(s) brown - Allwetter 44 (IP 44)	2102-31	1	piece
2CKA001754A4327	Cover frame 2-gang(s) chrome gloss - solo	1722-80G	1	piece

2CKA001754A4821	Cover frame 2-gang(s) porcelain anthracite - carat	1722-815	1	piece
2CKA001725A1480	Cover frame 2-gang(s) alpine white - Basic55	2512-94-507	1	piece
2CKA001754A4374	Cover frame 2gang platinum - alpha exclusive	1722 KA-20	1	piece
2CKA001754A4375	Cover frame 2gang platinum - alpha exclusive	1732 KA-20	1	piece
2CKA001730A0278	Cover frame 2-gang(s) aluminium silver - Allwetter 44 (IP 44)	2102-33	1	piece
2CKA001754A4537	Cover frame 2-gang(s) chrome matt - solo	1722-80-500	1	piece
2CKA001754A4255	Cover frame 2-gang(s) stainless steel - carat	1722-860	1	piece
2CKA001725A1485	Cover frame 2-gang(s) white - Basic55	2512-92-507	1	piece
2CKA001754A4383	Cover frame 2gang bronze - alpha exclusive	1722 KA-21	1	piece
2CKA001754A4384	Cover frame 2gang bronze - alpha exclusive	1732 KA-21	1	piece
2CKA001754A4530	Cover frame 2gang aluminium silver - future linear	1722-183K-500	1	piece
2CKA001730A0233	Cover frame 2-gang(s) anthracite - Allwetter 44 (IP 44)	2102-35	1	piece
2CKA001754A4361	Cover frame 2-gang(s) chrome - carat	1722-826-101	1	piece
2CKA001725A1532	Cover frame 2-gang(s) entrée grey - Basic55	2512-91-507	1	piece
2CKA001754A4523	Cover frame 2gang titanium - alpha exclusive	1722 KA-266-500	1	piece
2CKA001754A4126	Cover frame 2gang titanium - alpha exclusive	1732 KA-266	1	piece
2CKA001754A4415	Cover frame 2gang studio white matt - future linear	1722-884K	1	piece
2CKA001754A4357	Cover frame 2-gang(s) gold - carat	1722-823-101	1	piece
2CKA001725A1502	Cover frame 2-gang(s) champagne - Basic55	2512-93-507	1	piece
2CKA001754A4534	Cover frame 2gang black matt - future linear	1722-885K-500	1	piece
2CKA001754A4259	Cover frame 2-gang(s) bronze - carat	1722-821	1	piece
2CKA001725A1507	Cover frame 2-gang(s) château-black - Basic55	2512-95-507	1	piece
2CKA001725A1512	Cover frame 2-gang(s) chalet white - Basic55	2512-96-507	1	piece
2CKA001725A1517	Cover frame 2-gang(s) foyer red - Basic55	2512-97-507	1	piece
2CKA001754A4335	Cover frame 2gang yellow - Busch-axcent	1722-285	1	piece
2CKA001754A4776	Cover frame 2gang glass purple - Busch-axcent pur	1722-223	1	piece
2CKA001754A4561	Cover frame 2-gang(s) polished brass ivory white - Busch-Dynasty	1722-838-500	1	piece
2CKA001725A1522	Cover frame 2-gang(s) bistro-blue - Basic55	2512-98-507	1	piece
2CKA001754A4524	Cover frame 2gang platinum - alpha nea	1722-20-500	1	piece
2CKA001754A1660	Cover frame 2gang platinum - alpha nea	1732-20	1	piece
2CKA001754A4338	Cover frame 2gang green - Busch-axcent	1722-286	1	piece
2CKA001754A4761	Cover frame 2gang glass sun - Busch-axcent pur	1722-225	1	piece
2CKA001754A4571	Cover frame 2-gang(s) polished brass decor ivory white - Busch-Dynasty	1722-836-500	1	piece
2CKA001725A1527	Cover frame 2-gang(s) maison-beige - Basic55	2512-99-507	1	piece
2CKA001754A1710	Cover frame 2gang bronze - alpha nea	1722-21	1	piece
2CKA001754A1751	Cover frame 2gang bronze - alpha nea	1732-21	1	piece
2CKA001754A4341	Cover frame 2gang red - Busch-axcent	1722-287	1	piece
2CKA001754A4771	Cover frame 2gang glass avocado - Busch-axcent pur	1722-226	1	piece
2CKA001754A4566	Cover frame 2-gang(s) polished brass anthracite - Busch-Dynasty	1722-835-500	1	piece
2CKA001754A4392	Cover frame 2gang titanium - alpha nea	1722-266	1	piece
2CKA001754A4393	Cover frame 2gang titanium - alpha nea	1732-266	1	piece
2CKA001754A4344	Cover frame 2gang blue - Busch-axcent	1722-288	1	piece
2CKA001754A4766	Cover frame 2gang glass coral - Busch-axcent pur	1722-227	1	piece

2CKA001754A4576	Cover frame 2-gang(s) polished brass decor anthracite - Busch-Dynasty	1722-833-500	1	piece
2CKA001754A4756	Cover frame 2gang glass ocean - Busch-axcent pur	1722-228	1	piece
2CKA001754A4781	Cover frame 2gang glass oyster - Busch-axcent pur	1722-229	1	piece
2CKA001754A4689	Cover frame 2gang platinum - Busch-axcent pur	1722-270-500	1	piece
2CKA001754A4581	Cover frame 2-gang(s) antique brass ivory white - Busch-Dynasty	1722-848-500	1	piece
2CKA001754A4709	Cover frame 2gang black matt - Busch-axcent pur	1722-275-500	1	piece
2CKA001754A4591	Cover frame 2-gang(s) antique brass decor ivory white - Busch-Dynasty	1722-846-500	1	piece
2CKA001754A4699	Cover frame 2gang titanium - Busch-axcent pur	1722-276-500	1	piece
2CKA001754A4586	Cover frame 2-gang(s) antique brass anthracite - Busch-Dynasty	1722-845-500	1	piece
2CKA001754A4596	Cover frame 2-gang(s) antique brass decor anthracite - Busch-Dynasty	1722-843-500	1	piece
2CKA001754A4791	Cover frame 2gang paper brown - Busch-axcent pur	1722-243	1	piece
2CKA001754A4786	Cover frame 2gang paper blue - Busch-axcent pur	1722-248	1	piece
2CKA001754A4806	Cover frame 2gang slate grey - Busch-axcent pur	1722-290	1	piece
2CKA001754A4796	Cover frame 2gang concrete grey - Busch-axcent pur	1722-298	1	piece
2CKA001754A4313	Cover frame 2-gang(s) ivory - impuls	1722-72	1	piece
2CKA001754A4134	Cover frame 2-gang(s) chrome - impuls	1722-726	1	piece
2CKA001754A4525	Cover frame 2-gang(s) alpine white - impuls	1722-74-500	1	piece
2CKA001754A4226	Cover frame 2-gang(s) alpine white - impuls	1722-74-507	1	piece
2CKA001754A4431	Cover frame 2-gang(s) studio white matt - impuls	1722-774	1	piece
2CKA001754A4432	Cover frame 2-gang(s) studio white matt - impuls	1722-774-507	1	piece
2CKA001754A4425	Cover frame 2-gang(s) black matt - impuls	1722-775	1	piece
2CKA001754A2528	Cover frame 2-gang(s) champagne metallic - impuls	1722-79	1	piece
2CKA001754A4117	Cover frame 2gang palladium - alpha exclusive	1732 KA-260	1	piece
2CKA001754A4402	Cover frame 2gang palladium - alpha nea	1732-260	1	piece
2CKA001725A1066	Cover frame 2gang black - Reflex SI	2512-215	1	piece
2CKA001725A1565	Cover frame 2gang red - Reflex SI	2512-217-101	1	piece
2CKA001725A1566	Cover frame 2gang red - Reflex SI Linear	2512-217K-103	1	piece
2CKA001754A4714	Cover frame 2gang red - future linear	1722-12-182K-101	1	piece
2CKA001754A2239	Cover frame with labelling field, vertical 2gang white - Busch-Duro 2000 SI	1722 NS-212	1	piece
2CKA001754A2213	Cover frame with labelling field, horizontal 2gang white - Busch-Duro 2000 SI	1732 NS-212	1	piece
2CKA001754A4368	Cover frame with labelling field, horizontal 2gang studio white - future linear	1732-184 NSK	1	piece
2CKA001754A4066	Cover frame with labelling field, horizontal 2gang studio white - alpha exclusive	1722 NSKA-24G	1	piece
2CKA001754A2163	Cover frame with labelling field, vertical 2gang alpine white - Reflex SI	1722 NS-214	1	piece
2CKA001754A4059	Cover frame with labelling field, vertical 2gang alpine white - Reflex SI Linear	1722 NSKA-214	1	piece
2CKA001754A4060	Cover frame with labelling field, horizontal 2gang alpine white - Reflex SI Linear	1732 NSKA-214	1	piece

2CKA001754A4094	Cover frame with labelling field, vertical 2gang white - Busch-Duro 2000 SI Linear	1722 NSKA-212	1	piece
2CKA001754A4095	Cover frame with labelling field, horizontal 2gang white - Busch-Duro 2000 SI Linear	1732 NSKA-212	1	piece
2CKA001725A1538	Cover frame 3gang alpine white - Reflex SI	2513-214-500	1	piece
2CKA001725A1554	Cover frame 3gang white - Busch-Duro 2000 SI	2513-212-500	1	piece
2CKA001725A0639	Cover frame 3gang white - Busch-Duro 2000 SI	2513-212-506	1	piece
2CKA001725A1468	Cover frame 3gang white - Busch-Duro 2000 SI	2513-212-507	1	piece
2CKA001754A4502	Cover frame 3gang studio white - future linear	1723-184K-500	1	piece
2CKA001754A4319	Cover frame 3-gang(s) stainless steel - Pure Stainless Steel	1723-866K	1	piece
2CKA001730A0217	Cover frame 3-gang(s) alpine white - Allwetter 44 (IP 44)	2103-34	1	piece
2CKA001754A4175	Cover frame 3gang studio white - future	1723-184	1	piece
2CKA001754A4333	Cover frame 3gang studio white - Busch-axcent	1723-284	1	piece
2CKA001754A4439	Cover frame 3gang white glass - Busch-axcent pur	1723-280	1	piece
2CKA001754A4541	Cover frame 3-gang(s) studio white - solo	1723-84-500	1	piece
2CKA001754A4444	Cover frame 3-gang(s) white glass - carat	1723-811	1	piece
2CKA001754A4602	Cover frame 3-gang(s) ivory white - Busch-Dynasty	1723-832-500	1	piece
2CKA001725A1404	Cover frame 3-gang(s) alpine white - Basic55	2513-944-507	1	piece
2CKA001754A3021	Cover frame 3gang studio white - alpha exclusive	1723 KA-24G	1	piece
2CKA001754A4518	Cover frame 3gang studio white - alpha nea	1723-24G-500	1	piece
2CKA001754A3088	Cover frame 3gang studio white - alpha exclusive	1733 KA-24G	1	piece
2CKA001754A4069	Cover frame with labelling field, vertical 3gang studio white - alpha exclusive	1733 NSKA-24G	1	piece
2CKA001754A2734	Cover frame 3gang studio white - alpha nea	1733-24G	1	piece
2CKA001725A1541	Cover frame 3gang alpine white - Reflex SI Linear	2513-214K-102-500	1	piece
2CKA001725A1551	Cover frame 3gang white - Busch-Duro 2000 SI Linear	2513-212K-102-500	1	piece
2CKA001754A4232	Cover frame 3gang ivory white - future linear	1723-182K	1	piece
2CKA001754A4170	Cover frame 3gang ivory white - future	1723-182	1	piece
2CKA001754A4411	Cover frame 3gang black - Busch-axcent	1723-281	1	piece
2CKA001730A0274	Cover frame 3-gang(s) white - Allwetter 44 (IP 44)	2103-32	1	piece
2CKA001754A4802	Cover frame 3gang glass black - Busch-axcent pur	1723-245	1	piece
2CKA001754A4324	Cover frame 3-gang(s) glass black - carat	1723-825	1	piece
2CKA001754A4607	Cover frame 3-gang(s) anthracite - Busch-Dynasty	1723-831-500	1	piece
2CKA001725A1412	Cover frame 3-gang(s) white - Basic55	2513-922-507	1	piece
2CKA001754A3856	Cover frame 3gang ivory - alpha exclusive	1723 KA-22G	1	piece
2CKA001754A3807	Cover frame 3gang ivory - alpha nea	1723-22G	1	piece
2CKA001754A3872	Cover frame 3gang ivory - alpha exclusive	1733 KA-22G	1	piece
2CKA001754A3765	Cover frame 3gang ivory - alpha nea	1733-22G	1	piece
2CKA001754A4242	Cover frame 3gang anthracite - future linear	1723-181K	1	piece
2CKA001730A0279	Cover frame 3-gang(s) brown - Allwetter 44 (IP 44)	2103-31	1	piece
2CKA001754A4328	Cover frame 3-gang(s) chrome gloss - solo	1723-80G	1	piece
2CKA001754A4822	Cover frame 3-gang(s) porcelain anthracite - carat	1723-815	1	piece
2CKA001725A1481	Cover frame 3-gang(s) alpine white - Basic55	2513-94-507	1	piece
2CKA001754A4376	Cover frame 3gang platinum - alpha exclusive	1723 KA-20	1	piece

2CKA001754A4377	Cover frame 3gang platinum - alpha exclusive	1733 KA-20	1	piece
2CKA001730A0280	Cover frame 3-gang(s) aluminium silver - Allwetter 44 (IP 44)	2103-33	1	piece
2CKA001754A4540	Cover frame 3-gang(s) chrome matt - solo	1723-80-500	1	piece
2CKA001754A4256	Cover frame 3-gang(s) stainless steel - carat	1723-860	1	piece
2CKA001725A1486	Cover frame 3-gang(s) white - Basic55	2513-92-507	1	piece
2CKA001754A4385	Cover frame 3gang bronze - alpha exclusive	1723 KA-21	1	piece
2CKA001754A4386	Cover frame 3gang bronze - alpha exclusive	1733 KA-21	1	piece
2CKA001754A4533	Cover frame 3gang aluminium silver - future linear	1723-183K-500	1	piece
2CKA001730A0241	Cover frame 3-gang(s) anthracite - Allwetter 44 (IP 44)	2103-35	1	piece
2CKA001754A4362	Cover frame 3-gang(s) chrome - carat	1723-826-101	1	piece
2CKA001725A1533	Cover frame 3-gang(s) entrée grey - Basic55	2513-91-507	1	piece
2CKA001754A4127	Cover frame 3gang titanium - alpha exclusive	1723 KA-266	1	piece
2CKA001754A4128	Cover frame 3gang titanium - alpha exclusive	1733 KA-266	1	piece
2CKA001754A4416	Cover frame 3gang studio white matt - future linear	1723-884K	1	piece
2CKA001754A4358	Cover frame 3-gang(s) gold - carat	1723-823-101	1	piece
2CKA001725A1503	Cover frame 3-gang(s) champagne - Basic55	2513-93-507	1	piece
2CKA001754A4421	Cover frame 3gang black matt - future linear	1723-885K	1	piece
2CKA001754A4260	Cover frame 3-gang(s) bronze - carat	1723-821	1	piece
2CKA001725A1508	Cover frame 3-gang(s) château-black - Basic55	2513-95-507	1	piece
2CKA001725A1513	Cover frame 3-gang(s) chalet white - Basic55	2513-96-507	1	piece
2CKA001725A1518	Cover frame 3-gang(s) foyer red - Basic55	2513-97-507	1	piece
2CKA001754A4336	Cover frame 3gang yellow - Busch-axcent	1723-285	1	piece
2CKA001754A4777	Cover frame 3gang glass purple - Busch-axcent pur	1723-223	1	piece
2CKA001754A4562	Cover frame 3-gang(s) polished brass ivory white - Busch-Dynasty	1723-838-500	1	piece
2CKA001725A1523	Cover frame 3-gang(s) bistro-blue - Basic55	2513-98-507	1	piece
2CKA001754A1637	Cover frame 3gang platinum - alpha nea	1723-20	1	piece
2CKA001754A1678	Cover frame 3gang platinum - alpha nea	1733-20	1	piece
2CKA001754A4339	Cover frame 3gang green - Busch-axcent	1723-286	1	piece
2CKA001754A4762	Cover frame 3gang glass sun - Busch-axcent pur	1723-225	1	piece
2CKA001754A4572	Cover frame 3-gang(s) polished brass decor ivory white - Busch-Dynasty	1723-836-500	1	piece
2CKA001725A1528	Cover frame 3-gang(s) maison-beige - Basic55	2513-99-507	1	piece
2CKA001754A1728	Cover frame 3gang bronze - alpha nea	1723-21	1	piece
2CKA001754A1769	Cover frame 3gang bronze - alpha nea	1733-21	1	piece
2CKA001754A4342	Cover frame 3gang red - Busch-axcent	1723-287	1	piece
2CKA001754A4772	Cover frame 3gang glass avocado - Busch-axcent pur	1723-226	1	piece
2CKA001754A4567	Cover frame 3-gang(s) polished brass anthracite - Busch-Dynasty	1723-835-500	1	piece
2CKA001754A4394	Cover frame 3gang titanium - alpha nea	1723-266	1	piece
2CKA001754A4395	Cover frame 3gang titanium - alpha nea	1733-266	1	piece
2CKA001754A4345	Cover frame 3gang blue - Busch-axcent	1723-288	1	piece
2CKA001754A4767	Cover frame 3gang glass coral - Busch-axcent pur	1723-227	1	piece
2CKA001754A4577	Cover frame 3-gang(s) polished brass decor anthracite - Busch-Dynasty	1723-833-500	1	piece
2CKA001754A4757	Cover frame 3gang glass ocean - Busch-axcent pur	1723-228	1	piece
2CKA001754A4782	Cover frame 3gang glass oyster - Busch-axcent pur	1723-229	1	piece

2CKA001754A4690	Cover frame 3gang platinum - Busch-axcent pur	1723-270-500	1	piece
2CKA001754A4582	Cover frame 3-gang(s) antique brass ivory white - Busch-Dynasty	1723-848-500	1	piece
2CKA001754A4710	Cover frame 3gang black matt - Busch-axcent pur	1723-275-500	1	piece
2CKA001754A4592	Cover frame 3-gang(s) antique brass decor ivory white - Busch-Dynasty	1723-846-500	1	piece
2CKA001754A4700	Cover frame 3gang titanium - Busch-axcent pur	1723-276-500	1	piece
2CKA001754A4587	Cover frame 3-gang(s) antique brass anthracite - Busch-Dynasty	1723-845-500	1	piece
2CKA001754A4597	Cover frame 3-gang(s) antique brass decor anthracite - Busch-Dynasty	1723-843-500	1	piece
2CKA001754A4792	Cover frame 3gang paper brown - Busch-axcent pur	1723-243	1	piece
2CKA001754A4787	Cover frame 3gang paper blue - Busch-axcent pur	1723-248	1	piece
2CKA001754A4807	Cover frame 3gang slate grey - Busch-axcent pur	1723-290	1	piece
2CKA001754A4797	Cover frame 3gang concrete grey - Busch-axcent pur	1723-298	1	piece
2CKA001754A4314	Cover frame 3-gang(s) ivory - impuls	1723-72	1	piece
2CKA001754A4135	Cover frame 3-gang(s) chrome - impuls	1723-726	1	piece
2CKA001754A2437	Cover frame 3-gang(s) alpine white - impuls	1723-74	1	piece
2CKA001754A4433	Cover frame 3-gang(s) studio white matt - impuls	1723-774	1	piece
2CKA001754A4426	Cover frame 3-gang(s) black matt - impuls	1723-775	1	piece
2CKA001754A2536	Cover frame 3-gang(s) champagne metallic - impuls	1723-79	1	piece
2CKA001754A4118	Cover frame 3gang palladium - alpha exclusive	1723 KA-260	1	piece
2CKA001754A4119	Cover frame 3gang palladium - alpha exclusive	1733 KA-260	1	piece
2CKA001725A1090	Cover frame 3gang black - Reflex SI	2513-215	1	piece
2CKA001754A3708	Cover frame with labelling field, vertical 3gang white - Busch-Duro 2000 SI	1723 NS-212	1	piece
2CKA001754A3716	Cover frame with labelling field, horizontal 3gang white - Busch-Duro 2000 SI	1733 NS-212	1	piece
2CKA001754A4366	Cover frame with labelling field, vertical 3gang studio white - future linear	1723-184 NSK	1	piece
2CKA001754A4369	Cover frame with labelling field, horizontal 3gang studio white - future linear	1733-184 NSK	1	piece
2CKA001754A4068	Cover frame with labelling field, horizontal 3gang studio white - alpha exclusive	1723 NSKA-24G	1	piece
2CKA001754A3724	Cover frame with labelling field, vertical 3gang alpine white - Reflex SI	1723 NS-214	1	piece
2CKA001754A3732	Cover frame with labelling field, horizontal 3gang alpine white - Reflex SI	1733 NS-214	1	piece
2CKA001754A4061	Cover frame with labelling field, vertical 3gang alpine white - Reflex SI Linear	1723 NSKA-214	1	piece
2CKA001754A4062	Cover frame with labelling field, horizontal 3gang alpine white - Reflex SI Linear	1733 NSKA-214	1	piece
2CKA001754A4096	Cover frame with labelling field, vertical 3gang white - Busch-Duro 2000 SI Linear	1723 NSKA-212	1	piece
2CKA001754A4097	Cover frame with labelling field, horizontal 3gang white - Busch-Duro 2000 SI Linear	1733 NSKA-212	1	piece
2CKA001725A1543	Cover frame 4gang alpine white - Reflex SI	2514-214-500	1	piece
2CKA001725A0647	Cover frame 4gang white - Busch-Duro 2000 SI	2514-212-500	1	piece
2CKA001754A4238	Cover frame 4gang studio white - future linear	1724-184K	1	piece
2CKA001754A4320	Cover frame 4-gang(s) stainless steel - Pure Stainless Steel	1724-866K	1	piece

2CKA001754A4176	Cover frame 4gang studio white - future	1724-184	1	piece
2CKA001754A4346	Cover frame 4gang studio white - Busch-axcent	1724-284	1	piece
2CKA001754A4440	Cover frame 4gang white glass - Busch-axcent pur	1724-280	1	piece
2CKA001754A4112	Cover frame 4-gang(s) studio white - solo	1724-84	1	piece
2CKA001754A4445	Cover frame 4-gang(s) white glass - carat	1724-811	1	piece
2CKA001754A4603	Cover frame 4-gang(s) ivory white - Busch-Dynasty	1724-832-500	1	piece
2CKA001725A1401	Cover frame 4-gang(s) alpine white - Basic55	2514-944-507	1	piece
2CKA001754A4155	Cover frame 4gang studio white - alpha exclusive	1724 KA-24G	1	piece
2CKA001754A2908	Cover frame 4gang studio white - alpha nea	1724-24G	1	piece
2CKA001754A4156	Cover frame 4gang studio white - alpha exclusive	1734 KA-24G	1	piece
2CKA001754A2809	Cover frame 4gang studio white - alpha nea	1734-24G	1	piece
2CKA001725A1497	Cover frame 4gang alpine white - Reflex SJ Linear	2514-214K-102	1	piece
2CKA001725A1492	Cover frame 4gang white - Busch-Duro 2000 SJ Linear	2514-212K-102	1	piece
2CKA001754A4233	Cover frame 4gang ivory white - future linear	1724-182K	1	piece
2CKA001754A4171	Cover frame 4gang ivory white - future	1724-182	1	piece
2CKA001754A4412	Cover frame 4gang black - Busch-axcent	1724-281	1	piece
2CKA001754A4803	Cover frame 4gang glass black - Busch-axcent pur	1724-245	1	piece
2CKA001754A4325	Cover frame 4-gang(s) glass black - carat	1724-825	1	piece
2CKA001754A4608	Cover frame 4-gang(s) anthracite - Busch-Dynasty	1724-831-500	1	piece
2CKA001725A1402	Cover frame 4-gang(s) white - Basic55	2514-922-507	1	piece
2CKA001754A4151	Cover frame 4gang ivory - alpha exclusive	1724 KA-22G	1	piece
2CKA001754A3815	Cover frame 4gang ivory - alpha nea	1724-22G	1	piece
2CKA001754A4152	Cover frame 4gang ivory - alpha exclusive	1734 KA-22G	1	piece
2CKA001754A3773	Cover frame 4gang ivory - alpha nea	1734-22G	1	piece
2CKA001754A4243	Cover frame 4gang anthracite - future linear	1724-181K	1	piece
2CKA001754A4329	Cover frame 4-gang(s) chrome gloss - solo	1724-80G	1	piece
2CKA001725A1482	Cover frame 4-gang(s) alpine white - Basic55	2514-94-507	1	piece
2CKA001754A4378	Cover frame 4gang platinum - alpha exclusive	1724 KA-20	1	piece
2CKA001754A4379	Cover frame 4gang platinum - alpha exclusive	1734 KA-20	1	piece
2CKA001754A4107	Cover frame 4-gang(s) chrome matt - solo	1724-80	1	piece
2CKA001754A4257	Cover frame 4-gang(s) stainless steel - carat	1724-860	1	piece
2CKA001725A1487	Cover frame 4-gang(s) white - Basic55	2514-92-507	1	piece
2CKA001754A4387	Cover frame 4gang bronze - alpha exclusive	1724 KA-21	1	piece
2CKA001754A4388	Cover frame 4gang bronze - alpha exclusive	1734 KA-21	1	piece
2CKA001754A4309	Cover frame 4gang aluminium silver - future linear	1724-183K	1	piece
2CKA001754A4363	Cover frame 4-gang(s) chrome - carat	1724-826-101	1	piece
2CKA001725A1534	Cover frame 4-gang(s) entrée grey - Basic55	2514-91-507	1	piece
2CKA001754A4129	Cover frame 4gang titanium - alpha exclusive	1724 KA-266	1	piece
2CKA001754A4130	Cover frame 4gang titanium - alpha exclusive	1734 KA-266	1	piece
2CKA001754A4417	Cover frame 4gang studio white matt - future linear	1724-884K	1	piece
2CKA001754A4359	Cover frame 4-gang(s) gold - carat	1724-823-101	1	piece
2CKA001725A1504	Cover frame 4-gang(s) champagne - Basic55	2514-93-507	1	piece
2CKA001754A4422	Cover frame 4gang black matt - future linear	1724-885K	1	piece
2CKA001754A4261	Cover frame 4-gang(s) bronze - carat	1724-821	1	piece
2CKA001725A1509	Cover frame 4-gang(s) château-black - Basic55	2514-95-507	1	piece

2CKA001725A1514	Cover frame 4-gang(s) chalet white - Basic55	2514-96-507	1	piece
2CKA001725A1519	Cover frame 4-gang(s) foyer red - Basic55	2514-97-507	1	piece
2CKA001754A4348	Cover frame 4gang yellow - Busch-axcent	1724-285	1	piece
2CKA001754A4778	Cover frame 4gang glass purple - Busch-axcent pur	1724-223	1	piece
2CKA001754A4563	Cover frame 4-gang(s) polished brass ivory white - Busch-Dynasty	1724-838-500	1	piece
2CKA001725A1524	Cover frame 4-gang(s) bistro-blue - Basic55	2514-98-507	1	piece
2CKA001754A1645	Cover frame 4gang platinum - alpha nea	1724-20	1	piece
2CKA001754A1686	Cover frame 4gang platinum - alpha nea	1734-20	1	piece
2CKA001754A4350	Cover frame 4gang green - Busch-axcent	1724-286	1	piece
2CKA001754A4763	Cover frame 4gang glass sun - Busch-axcent pur	1724-225	1	piece
2CKA001754A4573	Cover frame 4-gang(s) polished brass decor ivory white - Busch-Dynasty	1724-836-500	1	piece
2CKA001725A1529	Cover frame 4-gang(s) maison-beige - Basic55	2514-99-507	1	piece
2CKA001754A1736	Cover frame 4gang bronze - alpha nea	1724-21	1	piece
2CKA001754A1777	Cover frame 4gang bronze - alpha nea	1734-21	1	piece
2CKA001754A4352	Cover frame 4gang red - Busch-axcent	1724-287	1	piece
2CKA001754A4773	Cover frame 4gang glass avocado - Busch-axcent pur	1724-226	1	piece
2CKA001754A4568	Cover frame 4-gang(s) polished brass anthracite - Busch-Dynasty	1724-835-500	1	piece
2CKA001754A4396	Cover frame 4gang titanium - alpha nea	1724-266	1	piece
2CKA001754A4397	Cover frame 4gang titanium - alpha nea	1734-266	1	piece
2CKA001754A4354	Cover frame 4gang blue - Busch-axcent	1724-288	1	piece
2CKA001754A4768	Cover frame 4gang glass coral - Busch-axcent pur	1724-227	1	piece
2CKA001754A4578	Cover frame 4-gang(s) polished brass decor anthracite - Busch-Dynasty	1724-833-500	1	piece
2CKA001754A4758	Cover frame 4gang glass ocean - Busch-axcent pur	1724-228	1	piece
2CKA001754A4783	Cover frame 4gang glass oyster - Busch-axcent pur	1724-229	1	piece
2CKA001754A4691	Cover frame 4gang platinum - Busch-axcent pur	1724-270-500	1	piece
2CKA001754A4583	Cover frame 4-gang(s) antique brass ivory white - Busch-Dynasty	1724-848-500	1	piece
2CKA001754A4711	Cover frame 4gang black matt - Busch-axcent pur	1724-275-500	1	piece
2CKA001754A4593	Cover frame 4-gang(s) antique brass decor ivory white - Busch-Dynasty	1724-846-500	1	piece
2CKA001754A4701	Cover frame 4gang titanium - Busch-axcent pur	1724-276-500	1	piece
2CKA001754A4588	Cover frame 4-gang(s) antique brass anthracite - Busch-Dynasty	1724-845-500	1	piece
2CKA001754A4598	Cover frame 4-gang(s) antique brass decor anthracite - Busch-Dynasty	1724-843-500	1	piece
2CKA001754A4793	Cover frame 4gang paper brown - Busch-axcent pur	1724-243	1	piece
2CKA001754A4788	Cover frame 4gang paper blue - Busch-axcent pur	1724-248	1	piece
2CKA001754A4808	Cover frame 4gang slate grey - Busch-axcent pur	1724-290	1	piece
2CKA001754A4798	Cover frame 4gang concrete grey - Busch-axcent pur	1724-298	1	piece
2CKA001754A4315	Cover frame 4-gang(s) ivory - impuls	1724-72	1	piece
2CKA001754A4136	Cover frame 4-gang(s) chrome - impuls	1724-726	1	piece
2CKA001754A3641	Cover frame 4-gang(s) solar gold - impuls	1724-73	1	piece

2CKA001754A2445	Cover frame 4-gang(s) alpine white - impuls	1724-74	1	piece
2CKA001754A4224	Cover frame 4-gang(s) alpine white - impuls	1724-74-507	1	piece
2CKA001754A4434	Cover frame 4-gang(s) studio white matt - impuls	1724-774	1	piece
2CKA001754A4435	Cover frame 4-gang(s) studio white matt - impuls	1724-774-507	1	piece
2CKA001754A4427	Cover frame 4-gang(s) black matt - impuls	1724-775	1	piece
2CKA001754A2544	Cover frame 4-gang(s) champagne metallic - impuls	1724-79	1	piece
2CKA001754A4223	Cover frame 4-gang(s) champagne metallic - impuls	1724-79-507	1	piece
2CKA001754A4120	Cover frame 4gang palladium - alpha exclusive	1724 KA-260	1	piece
2CKA001754A4121	Cover frame 4gang palladium - alpha exclusive	1734 KA-260	1	piece
2CKA001754A4367	Cover frame with labelling field, vertical 4gang studio white - future linear	1724-184 NSK	1	piece
2CKA001754A4370	Cover frame with labelling field, horizontal 4gang studio white - future linear	1734-184 NSK	1	piece
2CKA001754A4063	Cover frame with labelling field, vertical 4gang, alpine white - Reflex SI Linear	1724 NSKA-214	1	piece
2CKA001754A4064	Cover frame with labelling field, horizontal 4gang alpine white - Reflex SI Linear	1734 NSKA-214	1	piece
2CKA001754A4098	Cover frame with labelling field, vertical 4gang, white - Busch-Duro 2000 SI Linear	1724 NSKA-212	1	piece
2CKA001754A4099	Cover frame with labelling field, horizontal 4gang white - Busch-Duro 2000 SI Linear	1734 NSKA-212	1	piece
2CKA001725A0969	Cover frame 5gang alpine white - Reflex SI	2515-214	1	piece
2CKA001725A0654	Cover frame 5gang white - Busch-Duro 2000 SI	2515-212-500	1	piece
2CKA001725A1467	Cover frame 5gang white - Busch-Duro 2000 SI	2515-212-507	1	piece
2CKA001754A4517	Cover frame 5gang studio white - future linear	1725-184K-500	1	piece
2CKA001754A4321	Cover frame 5-gang(s) stainless steel - Pure Stainless Steel	1725-866K	1	piece
2CKA001754A4177	Cover frame 5gang studio white - future	1725-184	1	piece
2CKA001754A4347	Cover frame 5gang studio white - Busch-axcent	1725-284	1	piece
2CKA001754A4441	Cover frame 5gang white glass - Busch-axcent pur	1725-280	1	piece
2CKA001754A4113	Cover frame 5-gang(s) studio white - solo	1725-84	1	piece
2CKA001754A4604	Cover frame 5-gang(s) ivory white - Busch-Dynasty	1725-832-500	1	piece
2CKA001725A1408	Cover frame 5-gang(s) alpine white - Basic55	2515-944-507	1	piece
2CKA001754A4157	Cover frame 5gang studio white - alpha exclusive	1725 KA-24G	1	piece
2CKA001754A2932	Cover frame 5gang studio white - alpha nea	1725-24G	1	piece
2CKA001754A4158	Cover frame 5gang studio white - alpha exclusive	1735 KA-24G	1	piece
2CKA001754A2833	Cover frame 5gang studio white - alpha nea	1735-24G	1	piece
2CKA001725A1498	Cover frame 5gang alpine white - Reflex SI Linear	2515-214K-102	1	piece
2CKA001725A1493	Cover frame 5gang white - Busch-Duro 2000 SI Linear	2515-212K-102	1	piece
2CKA001754A4234	Cover frame 5gang ivory white - future linear	1725-182K	1	piece
2CKA001754A4172	Cover frame 5gang ivory white - future	1725-182	1	piece
2CKA001754A4413	Cover frame 5gang black - Busch-axcent	1725-281	1	piece
2CKA001754A4804	Cover frame 5gang glass black - Busch-axcent pur	1725-245	1	piece
2CKA001754A4609	Cover frame 5-gang(s) anthracite - Busch-Dynasty	1725-831-500	1	piece
2CKA001725A1406	Cover frame 5-gang(s) white - Basic55	2515-922-507	1	piece
2CKA001754A4153	Cover frame 5gang ivory - alpha exclusive	1725 KA-22G	1	piece

2CKA001754A3823	Cover frame 5gang ivory - alpha nea	1725-22G	1	piece
2CKA001754A4154	Cover frame 5gang ivory - alpha exclusive	1735 KA-22G	1	piece
2CKA001754A3781	Cover frame 5gang ivory - alpha nea	1735-22G	1	piece
2CKA001754A4244	Cover frame 5gang anthracite - future linear	1725-181K	1	piece
2CKA001754A4330	Cover frame 5-gang(s) chrome gloss - solo	1725-80G	1	piece
2CKA001725A1483	Cover frame 5-gang(s) alpine white - Basic55	2515-94-507	1	piece
2CKA001754A4380	Cover frame 5gang platinum - alpha exclusive	1725 KA-20	1	piece
2CKA001754A4381	Cover frame 5gang platinum - alpha exclusive	1735 KA-20	1	piece
2CKA001754A4108	Cover frame 5-gang(s) chrome matt - solo	1725-80	1	piece
2CKA001725A1488	Cover frame 5-gang(s) white - Basic55	2515-92-507	1	piece
2CKA001754A4389	Cover frame 5gang bronze - alpha exclusive	1725 KA-21	1	piece
2CKA001754A4390	Cover frame 5gang bronze - alpha exclusive	1735 KA-21	1	piece
2CKA001754A4310	Cover frame 5gang aluminium silver - future linear	1725-183K	1	piece
2CKA001754A4131	Cover frame 5gang titanium - alpha exclusive	1725 KA-266	1	piece
2CKA001754A4132	Cover frame 5gang titanium - alpha exclusive	1735 KA-266	1	piece
2CKA001754A4418	Cover frame 5gang studio white matt - future linear	1725-884K	1	piece
2CKA001725A1505	Cover frame 5-gang(s) champagne - Basic55	2515-93-507	1	piece
2CKA001754A4423	Cover frame 5gang black matt - future linear	1725-885K	1	piece
2CKA001725A1510	Cover frame 5-gang(s) château-black - Basic55	2515-95-507	1	piece
2CKA001725A1515	Cover frame 5-gang(s) chalet white - Basic55	2515-96-507	1	piece
2CKA001754A4349	Cover frame 5gang yellow - Busch-axcent	1725-285	1	piece
2CKA001754A4779	Cover frame 5gang glass purple - Busch-axcent pur	1725-223	1	piece
2CKA001754A4564	Cover frame 5-gang(s) polished brass ivory white - Busch-Dynasty	1725-838-500	1	piece
2CKA001725A1525	Cover frame 5-gang(s) bistro-blue - Basic55	2515-98-507	1	piece
2CKA001754A1652	Cover frame 5gang platinum - alpha nea	1725-20	1	piece
2CKA001754A1694	Cover frame 5gang platinum - alpha nea	1735-20	1	piece
2CKA001754A4351	Cover frame 5gang green - Busch-axcent	1725-286	1	piece
2CKA001754A4764	Cover frame 5gang glass sun - Busch-axcent pur	1725-225	1	piece
2CKA001754A4574	Cover frame 5-gang(s) polished brass decor ivory white - Busch-Dynasty	1725-836-500	1	piece
2CKA001725A1530	Cover frame 5-gang(s) maison-beige - Basic55	2515-99-507	1	piece
2CKA001754A1744	Cover frame 5gang bronze - alpha nea	1725-21	1	piece
2CKA001754A1785	Cover frame 5gang bronze - alpha nea	1735-21	1	piece
2CKA001754A4353	Cover frame 5gang red - Busch-axcent	1725-287	1	piece
2CKA001754A4774	Cover frame 5gang glass avocado - Busch-axcent pur	1725-226	1	piece
2CKA001754A4569	Cover frame 5-gang(s) polished brass anthracite - Busch-Dynasty	1725-835-500	1	piece
2CKA001754A4398	Cover frame 5gang titanium - alpha nea	1725-266	1	piece
2CKA001754A4399	Cover frame 5gang titanium - alpha nea	1735-266	1	piece
2CKA001754A4355	Cover frame 5gang blue - Busch-axcent	1725-288	1	piece
2CKA001754A4769	Cover frame 5gang glass coral - Busch-axcent pur	1725-227	1	piece
2CKA001754A4579	Cover frame 5-gang(s) polished brass decor anthracite - Busch-Dynasty	1725-833-500	1	piece
2CKA001754A4759	Cover frame 5gang glass ocean - Busch-axcent pur	1725-228	1	piece
2CKA001754A4784	Cover frame 5gang glass oyster - Busch-axcent pur	1725-229	1	piece
2CKA001754A4692	Cover frame 5gang platinum - Busch-axcent pur	1725-270-500	1	piece

2CKA001754A4584	Cover frame 5-gang(s) antique brass ivory white - Busch-Dynasty	1725-848-500	1	piece
2CKA001754A4712	Cover frame 5gang black matt - Busch-axcent pur	1725-275-500	1	piece
2CKA001754A4594	Cover frame 5-gang(s) antique brass decor ivory white - Busch-Dynasty	1725-846-500	1	piece
2CKA001754A4702	Cover frame 5gang titanium - Busch-axcent pur	1725-276-500	1	piece
2CKA001754A4589	Cover frame 5-gang(s) antique brass anthracite - Busch-Dynasty	1725-845-500	1	piece
2CKA001754A4599	Cover frame 5-gang(s) antique brass decor anthracite - Busch-Dynasty	1725-843-500	1	piece
2CKA001754A4794	Cover frame 5gang paper brown - Busch-axcent pur	1725-243	1	piece
2CKA001754A4789	Cover frame 5gang paper blue - Busch-axcent pur	1725-248	1	piece
2CKA001754A4809	Cover frame 5gang slate grey - Busch-axcent pur	1725-290	1	piece
2CKA001754A4799	Cover frame 5gang concrete grey - Busch-axcent pur	1725-298	1	piece
2CKA001754A4316	Cover frame 5-gang(s) ivory - impuls	1725-72	1	piece
2CKA001754A4137	Cover frame 5-gang(s) chrome - impuls	1725-726	1	piece
2CKA001754A3690	Cover frame 5-gang(s) solar gold - impuls	1725-73	1	piece
2CKA001754A2452	Cover frame 5-gang(s) alpine white - impuls	1725-74	1	piece
2CKA001754A4436	Cover frame 5-gang(s) studio white matt - impuls	1725-774	1	piece
2CKA001754A4428	Cover frame 5-gang(s) black matt - impuls	1725-775	1	piece
2CKA001754A2551	Cover frame 5-gang(s) champagne metallic - impuls	1725-79	1	piece
2CKA001754A4122	Cover frame 5gang palladium - alpha exclusive	1725 KA-260	1	piece
2CKA001754A4123	Cover frame 5gang palladium - alpha exclusive	1735 KA-260	1	piece
2CKA001754A4408	Cover frame 5gang palladium - alpha nea	1735-260	1	piece

Categories

Low Voltage Products and Systems → Wiring Accessories - Light Switch Ranges → Flush Mounted Inserts → Electronic Inserts

Low Voltage Products and Systems → Wiring Accessories - StandAlone Electronics → Indoor Motion Detector → Professional Series

