



 PRODUCT-DETAILS

8596.24 CM

Rocker switch Scene symbol for Switch/push button, Two-part button Green - Sky Niessen



General Information

Extended Product Type	8596.24 CM
Product ID	2CLA859624A1901
EAN	8427238226927
Catalog Description	Rocker switch Scene symbol for Switch/push button, Two-part button Green - Sky Niessen
Long Description	Sky Niessen ,Color: Comodoro Rocker scene 2 channel

Installation

Instructions and Manuals	2CLX810109A1001
Type of Fastening	Clamp

Environmental

Ambient Air Temperature	Operation -5 ... +35 °C Storage -5 ... +50 °C
-------------------------	--

Degree of Protection	IP20
Environmental Information	9AKK108466A4737

Technical

Data Sheet, Technical Information	9AKK107046A0356
Application	Switch/push button
Number of Batteries	0

Design

Design Range	Sky Niessen
Surface Finishing	Decor Matt
Material	Plastic Thermoplastic
Legend	Scene symbol
Color	Green

Dimensions

Product Net Width	0.152 m
Product Net Height	0.055 m
Product Net Depth / Length	0.313 m

Material Compliance

Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363
---	-----------------

Certificates and Declarations

Declaration of Conformity - CE	No declaration needed
--------------------------------	-----------------------

Popular Downloads

Marketing Video	9AKK108468A9589 9AKK106930A1594 9AKK108468A9590
-----------------	---

Classifications

ETIM 9	EC000011 - Control element/cover plate for domestic switching devices
UNSPSC	39121704
WEEE Category	5. Small Equipment (No External Dimension More Than 50 cm)
WEEE B2C / B2B	Business To Consumer

Categories

Low Voltage Products and Systems → Wiring Accessories - Light Switch Ranges → Cover Plates and Control Elements → Mechanical Controls

