




DE	Sensortaster Originalbetriebsanleitung	EL	κουμπί αισθητήρα Πρωτότυπες οδηγίες χρήσης	PL	Przełącznik dotykowy Oryginalna instrukcja obsługi
EN	Sensor Switch Original Operating Instructions	ET	Sensoriüliti Originaal-kasutusjuhend	RO	Buton cu senzor Instrucțiuni originale de utilizare
FR	Poussoir faible-effort Instructions de service originales	FI	Anturipainike Alkuperäinen käyttöohje	SK	Senzorový vypínač Originálny návod na obsluhu
ES	Pulsador tipo sensor Instructivo original	HR	Senzorni prekidač Originalne upute za uporabu	SL	Senzorsko stikalo Originalno navodilo za obratovanje
IT	Pulsante a sensore Istruzioni operative originali	HU	Érzékelőkapcsoló Eredeti üzemeltetési útmutató	SV	Sensorknapp Originalbruksanvisning
PT	Botão sensor Instruções de Serviço Originais	LT	Sensorinis jungiklis Originali eksploatacijos instrukcija	TR	Sensörlü buton Orijinal İşletme Kılavuzu
BG	сензорен бутон Оригинално ръководство за експлоатация	LV	Sensora taustiņš Oriģinālā lietošanas pamācība	PY	сенсорный выключатель Оригинальное руководство по эксплуатации
CS	Senzorové tlačítko Originální návod k obsluze	NL	Sensortoets Originele handleiding	中文	感应开关 原始操作说明
DA	Sensortast Original brugsanvisning				



3SU1200-1SK10-2SA0



SIEMENS AG

Technical Support <https://support.industry.siemens.com>

Support Request <https://support.industry.siemens.com/My/ww/en/requests>



107542462



