



## CT45/CT50 and CT50P Renewal Parts

This document contains a list of renewal parts for CT45/50 RTP drives (1395-B68, Series B) and CT50P RTP drives (1395-B70, Series B). Refer to this information when ordering renewal parts from your local Allen-Bradley representative.

*Note: For renewal part information for series A 1395 RTP drives, consult the Allen-Bradley Drive's Support webpage*

*(<http://www.ab.com/support/abdrives>).*

	Description	Part Number	Quantity per Drive
<b>BOARDS, MAIN CONTROL</b>	With Firmware 9.30	196259	1
<b>BOARDS, DIGITAL REFERENCE ADAPTER FOR RTP</b>	With EPROM revision 4.02	164325	1
	Programmed EPROM kit	164318	1
	Wire harness	133340	1
<b>BOARDS, OTHER</b>	Encoder Driver Board for RTP	133341	1
	PSI / Switcher Board	194954	1
	Power Board	173172	1
<b>CONTACTORS</b>	2-pole	123148	1
	Normally Open Auxiliary	111307	1
	Coil	119487	1
	Suppressor	151643	1
	9A AC, 3-pole, 120V coil (CO, DR,OP)	300642	3
	24A AC, 120V, 50/60Hz coil, Cat#104-C23D22, APCS/MPCS, mounted in cabinet (MF - MR)	300652	1
<b>DOCUMENTATION</b>	RTP System Binder	1395-RTP	-
	RTP Adapter User Manual	1395-RTP-5.1	-
	Digital Reference Adapter for RTP Applications User Manual	1395-RTP-5.2	-
	1395 Digital DC Drive User Manual	1395-5.40	-
<b>FUSES</b>	AC Line Fuse for 240-480V AC	140054	3
	1/2A, FRN-R (120V, MPCS only)	118300	1
	1.5A, AGC, (F1 on PSI/SW)	106937	1
	1A, MDL, (F2 on PSI/SW)	128458	1
	5A, MDX, (F3 on PSI/SW)	113829	1
	9A, FRS-R-9, 600V (4F, 5F, 6F)	136275	3
	12A, KTK-R, (F1 and F2 on Power Board)	117033	1
	250V, 10A	101690	1
	250V, 15A, FRN-R (1F)	101723	1
	250V, 1A, FRN-R (7F)	101687	1

	Description	Part Number	Quantity per Drive
<b>FUSES (Continued)</b>	250V, 3-2/10A (3F)	101718	1
	250V, 5A, FRN-R (2F)	101661	1
	500V, 1-1/8A	101744	3
	600V, 10A	101721	3
<b>OVERLOAD</b>	6.0-10A, thermal, Cat# 193-TAC10	303320	1
<b>POWER SUPPLY</b>	24V DC, 1.2A, MPCS	134149	1
<b>RELAYS</b>	120V, 60Hz, 4PDT, 5A, 14 Blade, Cat #700-HC24A1	101215	1
	24V DC, 3PDT, 10A (1CR)	125119	1
	24V DC, 4PDT, 1A, MPCS (10CR)	144854	1
	120V, 4PDT, 1A, MPCS (2CR-9CR)	144853	8
<b>SCRs</b>	Armature (CT45/CT50)	192704	6
	Armature (CT50P)	192706	6
	Field, 240-480V AC	145415	1
<b>THERMOSWITCH</b>	Heatsink	112929	1
<b>USER INTERFACE</b>	Handheld terminal	155187	1

[www.rockwellautomation.com](http://www.rockwellautomation.com)

**Corporate Headquarters**

Rockwell Automation, 777 East Wisconsin Avenue, Suite 1400, Milwaukee, WI, 53202-5302 USA, Tel: (1) 414.212.5200, Fax: (1) 414.212.5201

**Headquarters for Allen-Bradley Products, Rockwell Software Products and Global Manufacturing Solutions**

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe: Rockwell Automation SA/NV, Vorstlaan/Boulevard du Souverain 36-BP 3A/B, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

**Headquarters for Dodge and Reliance Electric Products**

Americas: Rockwell Automation, 6040 Ponders Court, Greenville, SC 29615-4617 USA, Tel: (1) 864.297.4800, Fax: (1) 864.281.2433

Europe: Rockwell Automation, Brühlstraße 22, D-74834 Elztal-Dallau, Germany, Tel: (49) 6261 9410, Fax: (49) 6261 17741

Asia Pacific: Rockwell Automation, 55 Newton Road, #11-01/02 Revenue House, Singapore 307987, Tel: (65) 351 6723, Fax: (65) 355 1733

**U.S. Allen-Bradley Drives Technical Support**

Tel: (1) 262.512.8176, Fax: (1) 262.512.2222, Email: support@drives.ra.rockwell.com, Online: [www.ab.com/support/abdrives](http://www.ab.com/support/abdrives)