

Wiser Energy Load Center Addendum to NVE87841 Pages 4, 5, 9 and 10

Retain for future use.

Introduction

The following instructions are an addendum to pages 4, 5, 9, and 10 of instruction bulletin no. NVE87841 for the Wiser Energy load center.

Current Transformer Installation General Guidelines

Follow these general guidelines when installing the current transformers:

- Remove the current transformer from the packaging.
- In order to comply with the National Electric Code, make sure that the current transformers, along with any wiring, do not exceed 75% of the available cross-sectional area in any wiring space.
- Do not install the current transformers on an area where they will block ventilation openings.
- Do not install the current transformers in area of circuit breaker arc venting.
- Secure the current transformer and route the conductors that the conductors do not directly contact the live terminals or the bus.

Note: Please refer to the individual miniature circuit breaker instruction bulletin.

Note: Shortening the current transformer's wire is not recommended. Special tools and equipment would be required to correctly install the current transformer connector.

Precautions

▲ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices. See NFPA 70E, CSA Z462 or NOM-029-STPS.
- This equipment must only be installed and serviced by qualified electrical personnel.
- This equipment must be effectively grounded per all applicable codes. Use an equipment-grounding conductor to connect this equipment to the power system ground.
- Disconnect all power supplying this equipment before working on or inside equipment.
- Always use a properly rated voltage sensing device to confirm power is off.
- Replace the barrier and the doors and covers before turning on power to this equipment.

Failure to follow these instructions will result in death or serious injury.

Installation

WE1EMSHMBRT

1. Read the safety precautions on pages 4 and 5 of the instruction bulletin, NVE87841, supplied with the equipment. Turn OFF all power before working on or inside the enclosure and load center.
2. Remove the cover screws (A) and remove the load center cover (B). See NVE87841, Figure 1 on page 9.
3. Measure the voltage from each line to neutral and from line to line to confirm that the power is OFF. See NVE87841, Figure 2 on page 10.

4. Remove the wired Wiser Energy monitoring hub from the Wiser Energy monitoring hub mounting device.
5. Remove the Wiser Energy monitoring hub mounting device screws (one for HOM2448L125PGCMR, HOM4080L225PCMR, HOM4080M200PCMR, QO124L125PGCMR and QO142M200PCMR, or two for SC3042M200PFMR).
6. Place the new Wiser energy monitoring hub mounting device and tighten the screw(s) to 25–45 lb-in. (2.8–5.1 N·m).
7. Replace the wired Wiser Energy monitoring hub in the Wiser Energy monitoring hub mounting device.
8. Replace the load center cover (B) and screws (A) and tighten to 20 lb-in. (2.3 N·m).

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

Schneider Electric and Square D are trademarks owned by Schneider Electric Industries SAS or its affiliated companies. All other trademarks are the property of their respective owners

Schneider Electric USA, Inc.
800 Federal Street
Andover, MA 01810 USA
888-778-2733
www.schneider-electric.us

Solamente el personal calificado deberá instalar, hacer funcionar y prestar servicios de mantenimiento al equipo eléctrico. Schneider Electric no asume responsabilidad alguna por las consecuencias emergentes de la utilización de este material.

Schneider Electric y Square D son marcas comerciales de Schneider Electric Industries SAS o sus compañías afiliadas. Todas las otras marcas comerciales son propiedad de sus respectivos propietarios.

Importado en México por:
Schneider Electric México, S.A. de C.V.
Av. Ejército Nacional No. 904
Col. Palmas, Polanco 11560 México, D.F.
55-5804-5000
www.schneider-electric.com.mx

Seul un personnel qualifié doit effectuer l'installation, l'utilisation, l'entretien et la maintenance du matériel électrique. Schneider Electric n'assume aucune responsabilité des conséquences éventuelles découlant de l'utilisation de cette documentation.

Schneider Electric et Square D sont des marques commerciales de Schneider Electric Industries SAS ou de ses compagnies affiliées. Toutes les autres marques commerciales utilisées dans ce document sont la propriété de leurs propriétaires respectifs.

Schneider Electric Canada, Inc.
5985 McLaughlin Road
Mississauga, ON L5R 1B8 Canada
800-565-6699
www.schneider-electric.ca