


Installation Guide

Danfoss React™ RA Click Valve + Lockshield / 015G5348 015G5349

Danfoss React™ RA Click

with RA-N & RLV-S





Danfoss React™ RA Click with RA-N & RLV-S

Presetting table | Voreinstelltabelle | Tableau de préréglage | Tabla de preajuste $\triangle T$ 10K 15K 20K ~Watt 250 100 200 1 250 400 550 2 **Code Number:** 850 400 650 3 **Danfoss React™** 015G5348 650 950 1300 4 015G5349 900 1350 1800 5 1150 1750 2300 6 2050 1350 2750 7 1900 2900 3850 Ν

△p=10kPa

SENSOR Installation | Montage | Installation | Instalación 1. 2. 3. ⇒® click

Danfoss A/S

Climate Solutions • danfoss.com • +45 7488 2222

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product.

All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.