


SD 77J04H01-01E


Unit: mm

### External Dimensions



### Mounting Dimensions


<Mounting Dimensions>



Note:

- When mounting the units close together, leave a space of at least 5 mm between them.
- Use the supplied spacer to keep a space of 5 mm for DIN rail mounting.

### Terminal Assignments



1	Output (+)
2	Output (-)
3	Input (+)
4	Input (-)
5	Do not use
6	GND
7	Supply (L+)
8	Supply (N-)